



Integrated Development Environment for RX Family

Migration to New Integrated Development Environment “CubeSuite+”: Emulator

Renesas Electronics Corporation

MCU Business Unit

MCU Software Division

MCU Tool Product Marketing Department

February 13, 2012

Revision 1.01

R20UT2056EJ0101

©2012. Renesas Electronics Corporation, All rights reserved.

Introduction

This document describes how to migrate the High-performance Embedded Workshop for RX Family to CubeSuite+ and how to operate E1 and E20 emulators in the CubeSuite+ environment, on the basis of CubeSuite+ V1.01.00.

For toolchains, refer to *Integrated Development Environment for RX Family Migration to Integrated Development Environment “CubeSuite+”: Build*. Also refer to the tutorial guide provided by CubeSuite+ for how to use tools. The tutorial guide is available by selecting [Help] -> [Tutorial] from the CubeSuite+ menu.



Tutorial Guide

Contents

1. Opening a Workspace of High-performance Embedded Workshop by using CubeSuite+
2. Changing the Debugger (E1/E20 Emulator or Simulator)
3. Changing the MCU
4. Where Do We Make Settings when Connecting an Emulator?
5. Connecting an Emulator
6. Disconnecting the Emulator
7. Starting an Emulator with Hot Plug-in
8. Entering an ID Code
9. Downloading a Program
10. Registering Additional Download Files
11. Starting/Stopping a Program
12. Setting the Start/Stop Function
13. Setting Trace Acquisition Conditions
14. Setting Trace Start/Stop Conditions
15. Setting Trace Extraction Conditions
16. Viewing/Changing Memory Data and Variables While the Program is Running


Contents

- 17. Automatically Updating Memory Data and Variables While the Program is Running
- 18. Setting Breakpoints
- 19. Causing a Break on Access to a Variable
- 20. Using the Performance-Measurement (Timer) Function
- 21. Filling Memory
- 22. Saving Memory Data
- 23. RAM Monitoring (When the E20 is Used)

1. Opening a Workspace of High-performance Embedded Workshop by CubeSuite+

The CubeSuite+ can open a workspace created by the High-performance Embedded Workshop. Perform the following procedure to open a workspace.


(1) Click the [Start] button at the upper left of the toolbar to open the start panel.



[Start] button

1. Opening Workspace of High-performance Embedded Workshop by Using CubeSuite+

(2) Click the [GO] button to the left of [Open Existing CubeSuite/High-performance Embedded Workshop/PM+ Project].



Open Existing CubeSuite/High-performance Embedded Workshop/PM+ Project

The new project can be created from the CubeSuite, High-performance Embedded Workshop and PM+ projects by opening.


Supported High-performance Embedded Workshop project version is 4.07.00 and later for RX.

Supported PM+ project version is 6.00 and later for V850/78K0R/78K0.

The new projects are also created for each project group.

The created project files are saved to the original project folder.

(3) The [Open Project] dialog box opens. Select [Workspace File for HEW(*.hws)] for file type, specify a workspace created by the HEW, and click the [Open] button.




File name: demo.hws


Files of type: Workspace File for HEW (*.hws)

1. Opening Workspace of High-performance Embedded Workshop by Using CubeSuite+

(4) If the HEW workspace contains multiple sessions, the [Select Session] dialog box opens. Select the session you want to use and click the [OK] button.



(5) Then the [Select Device] dialog box opens. Select the name of the device you want to use and click the [OK] button. The HEW workspace is converted to a CubeSuite+ project.




Once a device has been set, it can no longer be changed. For how to change the device, see “3. Changing the MCU.”

2. Changing the Debugger (E1/E20 Emulator or Simulator)

The HEW allowed users to select a debugger (E1/E20 emulator or simulator) in the process of changing the debug session or the target shown in the [Debug Settings] dialog box.

The CubeSuite+, on the other hand, allows users to select a debugger on the project tree. The procedure to change the debugger is described on the following pages.




Selecting a Debugger (E1/E20 Emulator or Simulator) in the HEW

2. Changing the Debugger (E1/E20 Emulator or Simulator)


(1) The debug tool name (debug tool) on the project tree panel indicates the currently selected debugger.

The following example shows that the RX simulator is selected:



2. Changing the Debugger (E1/E20 Emulator or Simulator)

(2) To change the debugger, right-click the debug tool name (debug tool) to open a pop-up menu. Select [Using Debug Tool] from the pop-up menu to select the debug tool you want to use.




3. Changing the MCU

The CubeSuite+ does not allow changing of the MCU for a project that has already been created.

To change the MCU, a new project must be created based on an existing project. Perform the following procedure to create a project:

- (1) Click the [Start] button at the upper left of the toolbar to open the start panel.
- (2) Click the [GO] button on the left of the [Create New Project] field.




3. Changing the MCU

- (3) The [Create Project] dialog box opens. Select the name of the MCU you want to use in [Using microcontroller].
- (4) Select the [Pass the file composition of an existing project to the new project] checkbox, select the original project, and then select the [Copy composition files in the diverted project folder to a new project folder] checkbox.

The screenshot shows the 'Create Project' dialog box in CubeSuite+. The 'Microcontroller:' dropdown is set to 'RX'. The 'Using microcontroller:' section is expanded, showing a list of microcontrollers. 'R5F56107VxFP(144pin)' is selected and circled in red. A yellow callout bubble points to it with the text 'Select MCU name.'. Below this, the 'Kind of project:' is 'Empty Application(CC-RX)', 'Project name:' is 'newproject', and 'Place:' is 'C:\WorkSpace\demo'. The 'Pass the file composition of an existing project to the new project' checkbox is checked and circled in red. Below it, 'Project to be passed:' is set to 'C:\WorkSpace\demo\demo\demo.mtpj' and circled in red. A yellow callout bubble points to it with the text 'Select original project.'. The 'Copy composition files in the diverted project folder to a new project folder.' checkbox is also checked and circled in red. At the bottom are 'Create', 'Cancel', and 'Help' buttons.

3. Changing the MCU

(5) Specify [Kind of project] and [Project name] and click the [Create] button. The newly created project is based on the original project but the MCU has been changed.



Select [Empty Application (CC-RX)].




Enter project name.

Click [Create] button.

4. Where Do We Make Settings when Connecting an Emulator?

In the HEW, the [Initial Settings] and [Configuration Properties] dialog boxes open to make settings when connecting an emulator. In the CubeSuite+, on the other hand, you need to make settings on the [Properties] panel **before connecting an emulator** by taking the following procedure.

Double-click the debug tool name (debug tool) on the [Project Tree] panel to open the Properties window of the debug tool.



4. Where Do We Make Settings when Connecting an Emulator?

The following figures show the correspondence between settings on the HEW's [Initial Settings] and [Configuration Properties] dialog boxes and settings on the [Properties] panel of the CubeSuite+.

(1) [Device] page of the [Initial Settings] dialog box in the HEW

The image shows two windows from the CubeSuite+ software. The left window is the 'Initial Settings' dialog box, and the right window is the 'Property' dialog box for 'RX E1(JTAG) Property'. Red boxes and blue arrows highlight the correspondence between settings in the two windows.

Initial Settings Dialog Box (Left):

- MCU group: RX610 Group
- Device: R5F56108
- Mode: Debugging mode (selected)
- Power supply: Power target from the emulator. (MAX 200mA)
- Communication: Emulator Serial No.: E1: 2AS012555

Property Dialog Box (Right):

Property	Value
Clock	
Main clock source	EXTAL
Main clock frequency[MHz]	
Allow changing of the clock source on writing internal flash memory	No
Connection with Emulator	
Emulator serial No.	E1: 2AS012555
Connection with Target Board	
Power target from the emulator.(MAX 200mA)	Yes
Supply voltage	3.3V
Communications method	JTAG
JTAG clock[MHz]	16.5
Flash	
Input Mode of ID code	Specify the ID code as a 32-digit hexadecimal
ID code	HEX FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF
Work RAM start address	HEX 1000
Work RAM size[bytes]	1024
Operating Modes of CPU	
Size of internal ROM[KBytes]	
Size of the internal ROM	



At the bottom of the Property dialog box, the 'Connect Settings' tab is circled in red. Other tabs include 'Debug Tool Settings', 'Download File Settings', and 'Hook Transaction Settings'.

Note: It is not possible to change the device on the CubeSuite+.

For how to change the device, see "3. Changing the MCU."

4. Where Do We Make Settings when Connecting an Emulator?

(2) [Startup and Communication] page of the [Initial Settings] dialog box in the HF/W



4. Where Do We Make Settings when Connecting an Emulator?

(3) [MCU] page of the [Configuration Properties] dialog box in the HEW

The image shows two screenshots from the High-performance Embedded Workshop (HEW) software. The left screenshot is the 'Configuration Properties' dialog box, with the 'MCU' tab selected. The right screenshot is the 'RX E1(JTAG) Property' dialog box.

Configuration Properties (MCU Tab):

- Operating mode: Mode: Single-chip mode, Endian: Little endian
- External memory areas: Table with columns Area, Endian, BUS Width
- Writing internal flash memory by the emulator debugger:
 - Allow to change the clock source on writing internal flash memory.
 - Work RAM start address (0x400 bytes used): 1000



RX E1(JTAG) Property:

- Clock:**
 - Main clock source: EXTAL
 - Main clock frequency(MHz): 12.5000
 - Allow changing of the clock source on writing internal flash memory: Yes
- Connection with Emulator:** Emulator serial No.: E1: 2AS012555
- Connection with Target Board:** Power target from the emulator.(MAX 200mA): Yes, Supply voltage: 3.3V, Communications method: JTAG, JTAG clock(MHz): 16.5
- Flash:** Input Mode of ID code: Specify the ID code as a 32-digit hexadecimal, ID code: [HEX] FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF
- Work RAM start address: [HEX] 1000
- Work RAM size(bytes): 1024
- Operating Modes of CPU:** Main clock frequency(MHz): When EXTAL is selected for "Main clock source", specify the EXTAL frequency.

Buttons at the bottom of the RX E1(JTAG) Property dialog: **Connect Settings** (circled), Debug Tool Settings, Download File Settings, Hook Transaction Settings.

4. Where Do We Make Settings when Connecting an Emulator?

(4) [System] page of the [Configuration Properties] dialog box in the HEW



4. Where Do We Make Settings when Connecting an Emulator?

(5) [Internal flash memory overwrite] page of the [Configuration Properties] dialog box in the HEW

The image shows two screenshots from the High-performance Embedded Workshop (HEW) software. The left screenshot displays the 'Configuration Properties' dialog box, with the 'Internal flash memory overwrite' page selected. A red circle highlights the 'Internal flash memory overwrite' tab, and a red rectangle highlights the 'Start Address' and 'End Address' columns. A blue arrow points from this rectangle to the right screenshot. The right screenshot shows the 'Download File Settings' page of the 'RX E1(JTAG) Property' dialog box. A red rectangle highlights the 'Erase flash ROM before download' setting, which is set to 'No'. The 'Download File Settings' tab is also circled in red at the bottom of the dialog box.

Configuration Properties

MCU System
Internal flash memory overwrite External flash memory

Start Address	End Address
---------------	-------------

Add...

Delete

Add address ranges which are over-written on downloading. If the download data does not overlap, the original values of the specified area are kept, and the values of not-specified area are just erased.

OK Cancel

Do not show this dialog box again.

Property

RX E1(JTAG) Property

Download

Download files	[1]
CPU Reset after download	Yes
Erase flash ROM before download	No
Automatic change method of event setting position	Suspend event

Debug Information

Execute to the specified symbol after CPU Reset	Yes
Specified symbol	_main
Specify the debugged overlay section	No

Download files

Specifies the file to be downloaded. The download file dialog box is opened by pressing the [...] button. In the download file to be downloaded.

Connect Settings Debug Tool Settings **Download File Settings** Hook Transaction Settings

Note: The erasing and overwriting settings are made for the entire flash area, and cannot be made for each block.

4. Where Do We Make Settings when Connecting an Emulator?

(6) [External flash memory] page of the [Configuration Properties] dialog box in the HEW

The screenshot shows the 'Configuration Properties' dialog box in the High-performance Embedded Workshop (HEW). The 'System' tab is selected, and the 'External flash memory' sub-tab is active. The 'Flash memory' section contains a table with columns 'Address', 'USD File', and 'USD File Path'. Below the table are 'Add...', 'Remove', and 'Detail...' buttons. The 'External flash memory' sub-tab is circled in red. An arrow points from this sub-tab to a detailed view of the 'External Flash' settings page in CubeSuite+. This page shows a list of 'External flash definition file' entries, with the first entry selected and circled in red. Below the list is a section titled 'External flash definition file' with a description and a button to add a new definition. At the bottom of the page, the 'Connect Settings' tab is circled in red.

Note: USD files used in the HEW can be registered as as they are.

They do not need to be modified even if a pre-download execution script and a post-download execution script have been registered.

5. Connecting an Emulator

Select [Debug] -> [Connect to Debug Tool] from the CubeSuite+ menu to establish connection to the selected emulator (debug tool).




Upon completion of the connection, the debug tool name appears on the status bar at the bottom right of the window.

The screenshot shows the CubeSuite+ application window. The 'Debug' menu is open, and 'Connect to Debug Tool' is highlighted. A yellow callout bubble points to this menu item with the text 'Select [Connect to Debug Tool].'. Below the menu, the 'External flash definition file' section is visible, showing a list of registered files. The 'Output' window displays an error message: 'Error (E0204001) : Download failed.' and '[Direct Error Cause] The value of the main clock frequency is incorrect. (E1891713)'. The status bar at the bottom right shows 'DISCONNECT' before the connection and 'RX E1(JTAG)' after the connection.

Note: If an ID code has been written in the MCU, set an ID code in advance according to “8. Entering an ID Code.”

6. Disconnecting the Emulator

To disconnect the emulator, select [Disconnect from Debug Tool] from the menu or click the  button on the debug toolbar.




[Disconnect from Debug Tool] button


7. Starting an Emulator with Hot Plug-In

The following describes a procedure to connect an emulator by using the hot plug-in facility.

(1) Select [Debug] -> [Hot Plug-in] from the CubeSuite+ menu.






(2) The following message appears. Connect the emulator to the target board and then click the [OK] button to start up the emulator.



Note: If an ID code has been written in the MCU, set an ID code in advance according to “8. Entering an ID Code.”

8. Entering an ID Code

In the HEW, the [ID Code verification] dialog box opens at startup if an ID code has been written in the MCU. In CubeSuite+, on the other hand, an ID code must be set on the [Properties] panel **before the emulator is started up**. Set an ID code by referring to the following figures:





9. Downloading a Program

Selecting [Debug] -> [Download] from the menu or clicking the  button on the debug toolbar starts downloading specified files.

Selecting [Debug] -> [Build & Download] from the menu or clicking the  button on the debug toolbar builds a project and then starts downloading the specified files.

If no debug tool is connected, connection to a debug tool must be established before downloading.



Download



Build & Download

10. Registering Additional Download Files

Add download files in the [Download File Settings] sheet on the [Properties] panel.

(1) Select [Download files] and click [...] on the right.

(2) The [Download Files] dialog box opens. Click the [Add] button.

Select [Download files] and click [...].

Click [Add] button.


The screenshot shows the CubeSuite+ interface. On the left, the 'Download File Settings' panel is visible, with the 'Download files' section selected. A red circle highlights the '...' button next to the 'Download files' section. On the right, the 'Download Files' dialog box is open, showing a list of download files with '62T.abs' selected. A red circle highlights the 'Add' button at the bottom of the dialog box. The dialog box also shows 'Download file property' information and 'Download file information' details.

Download file information	
File	Debug\62T.abs
File type	Load module file
Download object	Yes
Download symbol info	Yes
Specify the PIC/PID	No

Download file property:	
File	Debug\62T.abs
File type	Load module file
Download object	Yes
Download symbol info	Yes
Specify the PIC/PID	No

10. Registering Additional Download Files



(3) Specify the file name and file type in the [Download file information] field and then click the [OK] button.



Note: When downloading is performed, all of the registered files are downloaded. To download only desired files, set [Download object] and [Download symbol information] to “Yes” in this window only for files you want to download.

11. Starting/Stopping a Program

You can start or stop a program and reset the CPU from the menu or toolbar in the same way as the HEW (see below).



CubeSuite+ menu

Debug Tool Window Help		
	Download	
	Build & Download	F6
	Connect to Debug Tool	
	Hot Plug-in	
	Upload...	
	Disconnect from Debug Tool	Shift+F6
	Stop	Shift+F5
	Go	F5
	Ignore Break and Go	F8
	Step In	F11
	Step Over	F10
	Return Out	Shift+F11
	CPU Reset	Ctrl+F5
	Restart	

12. Setting the Start/Stop Function

You can set the Start/Stop function in the [Debug Tool Settings] sheet on the [Properties] panel (see below).

The image shows two screenshots from the CubeSuite+ software. On the left is a dialog box titled "Start/Stop function setting". It contains two options, each with a checkbox and a text field for a starting address:

- The specified routine is executed immediately before execution of the user's program. Starting address(S):
- The specified routine is executed immediately after the stop of the user's program. Starting address(E):



Buttons for "OK" and "cancel" are at the bottom. On the right is the "RX E1(JTAG) Property" panel. The "System" section is expanded, showing several properties:

Debug the program re-writing the on-chip PROGRAM ROM	No
Debug the program re-writing the on-chip DATA FLASH	Yes
Execute the specified routine immediately before execution	Yes
Routine to run immediately before execution starts	
Execute the specified routine immediately after the user program stops	Yes
Routine to run immediately after execution stops	

The "Debug Tool Settings" tab is circled in red at the bottom of the panel. A yellow note at the bottom of the panel reads: "Execute the specified routine immediately after the user program stops. When there is a routine to be executed immediately after the user program stops, select 'Yes' and specify 'Routine to run immediately after execution stops' property".

13. Setting Trace Acquisition Conditions



You can set trace acquisition conditions in the [Debug Tool Settings] sheet on the [Properties] panel (see below).



Note: CubeSuite+ V1.01.00 does not support advanced settings (including timestamps). The next and subsequent versions will support advanced settings.


14. Setting Trace Start/Stop Conditions

14.1 You can use the editor panel to specify an address where trace acquisition will start or stop (see below).




14. Setting Trace Start/Stop Conditions

- (1) Right-click the event area of the line at which you want to start or stop tracing. This opens a pop-up menu.
- (2) Select [Set Trace Start Event] or [Set Trace End Event].



Right-click here.

45	ffff8756	z += 1;
46	ffff8768	if (i == 25)
47	ffff8770	z = 0;



Select start or stop.

43	ffff8748	for(i=0; i<50; i++){
44		// printf("a[%d]=%l
45	ffff8756	z += 1;
46	ffff8768	if (i == 25)
47	ffff8770	z = 0;

- (3)  is displayed in the line for which [Set Trace Start Event] has been set, and  is displayed in the line for which [Set Trace Stop Event] has been set.


14. Setting Trace Start/Stop Conditions

14.2 You can use the watch or editor panel to start or stop tracing on data access.

(1) On the watch or editor panel, right-click the variable that you want to start or stop tracing when it is accessed. This opens a pop-up menu.


(2) Select [Trace Output] (or [Trace Settings] on the editor panel) and select [Record Start R/W Value] or [Record End R/W Value].

(3) Enter a value to set a data condition.




14. Setting Trace Start/Stop Conditions

All conditions that have been set can be checked on the event panel.



15. Setting Trace Extraction Conditions

You can set trace extraction conditions on the watch or editor panel (see below).



15. Setting Trace Extraction Conditions

- (1) On the watch or editor panel, right-click the variable that you want to use as a trace extraction condition. This opens a pop-up menu.
- (2) Select [Trace Output] (or [Trace Settings] on the editor panel) and select a trace extraction condition.



The screenshot illustrates the steps to set trace extraction conditions. It shows two panels: a Watch panel and a code editor panel.

Watch Panel: A table with columns 'Watch', 'Value', and 'Type (Byte)'. The row for variable 'z' has a value of '2146513710...' and type 'int (4)'. A red circle highlights the 'z' variable, and a yellow callout bubble points to it with the text 'Right-click here.'


Code Editor Panel: Shows C code with line numbers 19-23. Line 19 contains 'int z = 0;'. A red circle highlights this line, and a red arrow points from it to the 'Trace Output' option in the context menu.

Context Menu: A right-click menu is open over the watch panel. The 'Trace Output' option is highlighted with a red circle and a yellow callout bubble that says 'Select [Trace Output] or [Trace Settings]'. Other options in the menu include 'Record Reading Value', 'Record Writing Value', 'Record R/W Value', 'Record Start R/W Value', 'Record End R/W Value', 'Trace', 'Access Break', 'Timer Settings', 'Periodic Updating', 'Refresh', 'Force Read Value', and 'Add New Watch'. A yellow callout bubble points to the 'Record Reading Value' option with the text 'Select a trace extraction condition.'

16. Viewing/Changing Memory Data and Variables While the Program Is Running

To view or change memory data and variables while the program is running in CubeSuite+, make settings on the [Properties] panel by using the following procedure:

- (1) Open the [Debug Tool Settings] sheet on the [Properties] panel of the debug tool.
- (2) Set [Access by stopping execution] in the [Access Memory While Running] field to [Yes]. Memory data and variables can be viewed while the program is running.



Change this to [Yes].

If [No] is selected, "***" is displayed on the memory panel while the program is running.

17. Automatically Updating Memory Data and Variables While the Program Is Running

To automatically update memory data and variables via CubeSuite+, make settings on the [Properties] panel by using the following procedure:

- (1) Open the [Debug Tool Settings] sheet on the [Properties] panel of the debug tool.
- (2) Set [Access by stopping execution] and [Update the display during execution] in the [Access Memory While Running] field to [Yes].

Information displayed on the memory and watch panels is automatically updated while the program is running.

To change the update interval, modify the [Update interval] value.

The screenshot shows the CubeSuite+ interface. The 'Debug Tool Settings' panel is open, with the 'Access Memory While Running' section highlighted in red. A yellow callout bubble points to the 'Update the display during execution' checkbox, which is checked, and the 'Update interval[ms]' field, which is set to 500. Another yellow callout bubble points to the 'Update interval[ms]' field with the text 'Set update interval.'. To the right, the 'Watch1' panel is shown with a table of watch variables. A yellow callout bubble points to the 'Watch1' panel with the text 'Variables registered in the watch panel and memory data in the memory panel are automatically updated while the program is running.'.


Watch	Value	Type (Byt
z	24	int (4)

18. Setting Breakpoints

(1) You can set breakpoints in the main area (enclosed by a red line in the figure below) on the editor panel of CubeSuite+.


Single-clicking a line with an address sets a breakpoint.

Single-clicking a line for which a breakpoint has been set deletes the breakpoint.



18. Setting Breakpoints

(2) Select a breakpoint type (software break or hardware break) for [Type of breakpoints to be preferentially used] in the [Debug Tool Settings] sheet on the [Properties] panel. (Hardware break is selected in the example below.)



The screenshot shows the CubeSuite+ interface with the 'Debug Tool Settings' panel open. The 'Break' section is highlighted with a red box, and the 'Type of breakpoints to be preferentially used' is set to 'Hardware break'. A yellow callout bubble points to this setting with the text 'Set a breakpoint type to be preferentially used.' The 'Debug Tool Settings' tab is also circled in red at the bottom of the panel.

Section	Property	Value
Memory	Memory mappings	[21]
	Verify on writing to memory	Yes
	Access Memory While Running	
	Access by stopping execution	Yes
	Update the display during execution	Yes
	Update interval[ms]	500
Break	Type of breakpoints to be preferentially used	Hardware break
	System	
	Type of breakpoints to be preferentially used	Specify the type of breakpoints to be preferentially used when setting breakpoints for a source line or address.


(3) If the number of breakpoints of the selected type exceeds the limit, the other type of breakpoints are used.

Event marks indicate the types of breakpoints.

 : Software break  : Hardware break

18. Setting Breakpoints

(4) You can check the breakpoint setting on the [Event] panel. Select [View] -> [Event] from the CubeSuite+ menu to open the [Event] panel. Unnecessary breakpoints can be deleted or disabled on the [Event] panel.



19. Causing a Break on Access to a Variable

You can use the watch or editor panel to make a setting to cause a break on access to a specific variable.

(1) On the watch or editor panel, right-click the variable that you want to cause a break when it is accessed. This opens a pop-up menu.

(2) Select [Access Break] (or [Break Settings] on the editor panel) and select [Set Read Combination Break to], [Set Write Combination Break to], or [Set R/W Combination Break to].

The image shows a screenshot of the CubeSuite+ IDE. On the left, the 'Watch' window displays a table with a variable 'z' selected. On the right, the code editor shows the declaration 'int z = 0;'. A context menu is open over the code, with 'Access Break' selected. Three yellow callout boxes provide instructions: 'Right-click the variable to open a pop-up menu.' (pointing to the code), 'Select [Access Break].' (pointing to the menu item), and 'Select a break condition (read, write, or read/write).' (pointing to the sub-menu options). Red circles highlight the variable 'z' in the watch window, the code 'int z = 0;', the 'Access Break' menu item, and the sub-menu options.


```
15
16 #include <math.h>
17 #include <stdlib.h>
18
19 int z = 0;
```

Watch	Value	Type (Byte)
z	2146513710...	int (4)

- Set Read Combination Break to
- Access Break**
- Set Write Combination Break to
- Set R/W Combination Break to
- Timer Settings

19. Causing a Break on Access to a Variable

(3) Enter a value to set a data condition (or leave the box blank if no data condition is needed).




Note: Enter a decimal number here. When entering a hexadecimal number, add “0x” to the head (e.g. 0xAA).

19. Causing a Break on Access to a Variable

You can also specify masking of data conditions in the [Detailed Settings of Access Events] dialog box.

(4) Select [View] -> [Event] from the menu to open the event panel. Click the “+” mark to the left of [Combination Break] for expansion.

(5) Select and right-click the event you want to modify in the [Detail] field to open a pop-up menu. Select [Edit Condition] from the pop-up menu.




19. Causing a Break on Access to a Variable

(6) The [Detailed Settings of Access Events] dialog box opens. Set [Specify the data mask] in the [Data Condition] field to [Yes].

(7) Setting of a mask value is enabled. Enter a mask value.

The bits of the data value for which a mask value “0” has been specified is treated as “Don’t Care”.



Set this item to [Yes].

Enter a mask value in hexadecimal.
This example shows masking (Don't care)
of bytes other than the lowest 1 byte.

This dialog box allows settings for masking address conditions, specifying a range, access type, access size, comparison data, and pass count for data conditions in addition to masking data conditions.

20. Using the Performance-Measurement (Timer) Function

While the HEW can measure program execution time with the performance-measurement function, the CubeSuite+ allows measurement of program execution time by the timer.

Measurement results can be viewed on the [Event] panel (opened by selecting [View] -> [Event] from the menu).

No	Condition	Time (h:m:s.ms.us.ns)	Count (Decimal)
1	Executi...	00:00:00.000.001.400	35
2	Not use	--:--:--.--.--.--.--	-




Performance Window

Name	Detail			
<input checked="" type="checkbox"/> Unconditional Trace				
<input checked="" type="checkbox"/> Timer Result1	Total :5520 ns...			
Total	Pass Count	Average	Max	Min
552...	0	0 ns	0 ns	0 ns
Detail				
Start After Execution 62T.c#54 0xffff879e				
End After Execution 62T.c#67 0xffff8831				
Name	Detail			
<input checked="" type="checkbox"/> Run-Break Timer	Total:200000 ns			
<input checked="" type="checkbox"/> Break0001	Before Execution...			

[Event] Panel

20. Using the Performance-Measurement (Timer) Function

20.1 You can set measurement start/stop conditions on the editor panel. The procedure is described on the next page.



Note: Start/stop conditions cannot be registered through function names in CubeSuite+.

20. Using the Performance-Measurement (Timer) Function

Set measurement start/stop conditions by using the following procedure.

- (1) On the [Editor] panel, right-click the event area of the line at which you want to start or stop measurement. This opens a pop-up menu.
- (2) Select [Set Timer Start Event] or [Set Timer End Event].
- (3) If two channels are provided, select a timer (Timer 1 or Timer 2) to be used for measurement.

The screenshot shows the CubeSuite+ IDE with a C program open. The code is as follows:

```
20 void main(void);
21 void sort(long *a);
22 void change(long *a);
23
24 #fff8704 void main(void)
25 {
26     long a[10];
27     long j;
28     int i;
29
30     // printf("### Data Input ###\n");
31
32     for( i=0; i<10; i++){
33         #fff8707 j = rand();
34         #fff8713         #fff8711         if(j < 0){
35             #fff8723             j = -j;
36         }
37         #fff872b         a[i] = j;
38         // printf("a[%d]=%ld\n",i,a[i]);
39     }
40     #fff8744     sort(a);
41     // printf("### Sorting results ###\n");
42     #fff874c     for( i=0; i<10; i++){
43         #fff8756         #fff8768         printf("a[%d]=%ld\n",i,a[i]);
44         #fff8770         z += 1;
45         #fff8768         if (z == 25)
46             z = 0;
47     }
48 }
49
50 #fff878a change(a);
51 #fff878e while(1);
52
53 }
```

The event area of line 45 is highlighted with a red box. A red arrow points from this box to a zoomed-in view of the event area, which shows the memory addresses and the code snippet:

45	ffff8756	z += 1;
46	ffff8768	if (i == 25)
47	ffff8770	z = 0;

A yellow callout bubble points to the event area with the text "Right-click here."

The zoomed-in view shows a context menu with the following options:


- Set Timer Start Event
- Set Timer End Event
- Set Trace Start Event
- Set Trace End Event
- Register Action Event...

The "Set Timer Start Event" option is circled in red. A yellow callout bubble points to it with the text "Select timer start or stop."

The "Set Timer 1" option is also circled in red. A yellow callout bubble points to it with the text "Select Timer 1 or Timer 2."

20. Using the Performance-Measurement (Timer) Function

(4) Upon completion of the setting,  appears in the line for which [Set Timer Start Event] has been set, and  appears in the line for which [Set Timer End Event] has been set.



The screenshot shows the CubeSuite+ interface with a code editor. The code is as follows:

```
43      ffff8749  for( i=0; i<50; i++ ){
44      //      printf("a[%d]=%i
45      ffff8756      z += 1;
46      ffff8768      if (i == 25)
47      ffff8770       z = 0;
```

The code is enclosed in a red box. The start event icon is on line 43 and the end event icon is on line 47. The code is as follows:

20. Using the Performance-Measurement (Timer) Function

20.2 You can set [Measurement item] and [Execution only once] on the [Detailed Settings of Timer Measurement] dialog box.

(1) Right-click [Timer Result1] on the [Event] panel to open a pop-up menu. Selecting [Edit Condition] from the pop-up menu opens the [Detailed Settings of Timer Measurement] dialog box.

The image shows a sequence of three screenshots from the CubeSuite+ software interface, illustrating the steps to configure a timer measurement.

Top Left Screenshot: Performance Configuration Dialog
This dialog box is titled "Performance" and contains several sections. A red box highlights the "Condition:" dropdown menu, which is currently set to "Not use". Another red box highlights the checkbox "Measure the performance only once." at the bottom of the dialog.

Top Right Screenshot: Events Panel
This panel shows a list of events. A red oval highlights the "Timer Result1" event. A yellow callout bubble points to this event with the text "Right-click here to open a pop-up menu." Below the event list, a "Detail" section shows "Start After Execution 62T.c#43 0xffff8749" and "End After Execution 62T.c#47 0xffff8770".

Bottom Right Screenshot: Context Menu
A context menu is open over the "Timer Result1" event. A red box highlights the "Edit Condition..." option. A yellow callout bubble points to this option with the text "Select [Edit Condition]."

Bottom Center Screenshot: Detailed Settings of Timer Measurement Dialog
This dialog box is titled "Detail" and contains a "Measurement Setting" section. A red box highlights the "Measurement item" dropdown (set to "Execution cycle") and the "Execution only once" checkbox. A yellow callout bubble points to these settings with the text "Set conditions."

Arrows indicate the flow of the process: from the "Events" panel to the "Performance" dialog, and from the "Context Menu" to the "Detail" dialog.

20. Using the Performance-Measurement (Timer) Function

20.3 You can set [Display the cycle as time span] and [Use 64 bit counter] in the [Debug Tool Settings] sheet on the [Properties] panel.

The image shows two software windows. The left window is titled 'Performance' and contains several sections. At the bottom, there are two red-bordered boxes: one containing the checkbox 'Display the cycle as time span.' with a value of '0.0001 [MHz]' and another containing the checkbox 'Use 64 bit counter'. The right window is titled 'CubeSuite+' and shows a 'Trace' section with a table of settings. Below it is a 'Timer' section with a table of settings. The 'Timer' table has two rows: 'Use 64bit counter' with value 'No' and 'Operating frequency[MHz]' with value '100.0000'. Both rows are highlighted with a red border. Below the 'Timer' section is a yellow 'Access Memory While Running' section. At the bottom of the 'CubeSuite+' window, the 'Debug Tool S...' button is circled in red. Two blue arrows point from the 'Debug Tool S...' button to the two red-bordered boxes in the 'Performance' window.

Trace	
Usage of trace function	Trace
Operation after trace memory is full	Overwrite trace memory and continue execution
Trace data type	Branch


Timer	
Use 64bit counter	No
Operating frequency[MHz]	100.0000

Access Memory While Running

Connect Settings | **Debug Tool S...** | Download File S... | Hook Transacti... |

20. Using the Performance-Measurement (Timer) Function

20.4 When all settings have been made, execute the program. The time measurement result is displayed at a break.



The screenshot shows the CubeSuite+ Events window. The window title is "Events". The main area displays a table with the following data:

Name	Detail
Timer Result1	Total :5660 ns..

Below the table, there is a summary table with the following data:

Total	Pass Count	Average	Max	Min
5660 ns	0	0 ns	0 ns	0 ns

Below the summary table, there is a "Detail" section with the following data:

Start After Execution 62T.c#43 0xffff8749
End After Execution 62T.c#47 0xffff8770

21. Filling Memory

Memory can be filled (batch change) via the [Memory Initialize] dialog box.

(1) Right-click on the [Memory] panel to open a pop-up menu, and select [Fill] from the pop-up menu.

(2) The [Memory Initialize] dialog box opens. Enter addresses (start address and end address) you want to initialize and initialization data, and then click the [OK] button.

The image shows the CubeSuite+ interface. On the left, the Memory panel displays a memory dump with addresses from 00000000 to 00000090. A right-click context menu is open over the memory panel, with the 'Fill...' option highlighted in red. A yellow callout bubble points to this menu with the text: "Right-click here to open a pop-up menu and select [Fill].".


On the right, the 'Memory Initialize' dialog box is shown. It has three input fields: 'Start address/symbol:' containing '0x0000', 'End address/symbol:' containing '0xff', and 'Initialize data:' containing 'HEX 0xaa'. Each of these fields is enclosed in a red box. A yellow callout bubble points to the dialog box with the text: "Enter a start address, end address, and initialization data. This example shows filling 0x000 to 0xFFf with 0xAA.". The 'OK' button at the bottom of the dialog is also circled in red.

Note: Enter decimal numbers here. When entering hexadecimal numbers, add "0x" to the head of each number.

22. Saving Memory Data

[Data Save] dialog box is used to save memory data via CubeSuite+. Select [Debug] -> [Upload...] from the menu.

The [Data Save] dialog box opens. Specify the file name, type, and range of memory data you want to save, and then click the [Save] button.




Note: Enter decimal numbers here. When entering hexadecimal numbers, add “0x” to the head of each number.

23. RAM Monitoring (When the E20 is Used)

CubeSuite+ provides the RRM (Real-time RAM Monitor) function that is equivalent to the HEW's RAM monitoring. The following describes how to use the RRM function:

23.1 Set [Usage of trace function] in the [Debug Tool Settings] sheet on the [Properties] panel of the debug tool to [Real-time RAM monitor].




Set Usage of trace function to [Real-time RAM monitor].

23. RAM Monitoring (When the E20 is Used)

23.2 In the [Debug Tool Settings] sheet, set [Access by stopping execution] to [No], [Update the display during execution] to [Yes], and [Enable the automatic update of realtime display] to [Yes].

Set a desired update interval for [Update interval].



Make the following settings:
[Access by stopping execution]: No
[Update the display during execution]: Yes
[Update interval]: Desired update interval
[Enable the automatic update of realtime display]: Yes

Note: If [Access by stopping execution] is set to [Yes], the RRM function is not usable.

23. RAM Monitoring (When the E20 is Used)

23.3 Open the area you want to view with real-time RAM monitoring on the [Memory] panel, and then execute the program. Memory data is displayed by the RRM function.



	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+a	+b	+c	+d	+e	+f
000014c0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
000014d0	00	00	00	00	18	00	00	00	91	91	FF	FF	9D	91	FF	FF
000014e0	A9	91	FF	FF	00	00	00	00	D8	14	00	00	D0	10	00	00
000014f0	01	08	00	00	34	15	00	00	35	15	00	00	34	15	00	00
00001500	34	15	00	00	34	15	00	00	34	15	00	00	14	15	00	00
00001510	00	00	00	00	00	00	00	00	34	15	00	00	34	15	00	00
00001520	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00001530	00	00	00	00	00	00	00	00	1A	08	01	01	7C	15	00	00
00001540	7D	15	00	00	7C	15	00	00	7C	15	00	00	7C	15	00	00
00001550	7C	15	00	00												


Example of display by the RRM function

-  : Read/fetch
-  : Write
-  : Read/write
-  : No access
-  : Loss of data
- ** : An area other than the real-time display update area was specified while the program is running or acquisition of memory data failed

23. RAM Monitoring (When the E20 is Used)

23.4 Troubleshooting

(1) Values on the [Memory] panel are updated, but the background color remains white.



	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+a	+b	+c
000014c0	00	00	00	00	00	00	00	00	00	00	00	00	00
000014d0	00	00	00	00	18	00	00	00	91	91	FF	FF	91
000014e0	A9	91	FF	FF	00	00	00	00	D8	14	00	00	D1
000014f0	01	08	00	00	34	15	00	00	35	15	00	00	34
00001500	34	15	00	00	34	15	00	00	34	15	00	00	15
00001510	00	00	00	00	00	00	00	00	34	15	00	00	34
00001520	00	00	00	00	00	00	00	00	00	00	00	00	00

Values are updated, but background color remains white.

The RRM function is disabled.

If [Access by stopping execution] in the [Debug Tool Settings] sheet on the [Properties] panel is set to [Yes], the RRM function is not usable.

Set [Access by stopping execution] to [No].




Access Memory While Running
Access by stopping execution: **No**

Set this item to [No] if the RRM function is to be used.

23. RAM Monitoring (When the E20 is Used)

23.4 Troubleshooting

(2) “**” is displayed on the [Memory] panel.



The displayed area is not covered by the RRM function.

The RRM function covers an area of up to 4096 bytes (1024 bytes × 4) that is automatically allocated according to the data on the open [Watch] and [Memory] panels. If the amount of data displayed on the [Memory] panel is larger than the area allocated for the RRM function, the RRM function is not usable.

In that case, perform the following:

- Reduce the number of variables registered in the [Watch] panel or close the [Watch] panel.
- Open only the [Memory] panel on which you want to use the RRM function.



Renesas Electronics Corporation

©2012. Renesas Electronics Corporation, All rights reserved.