

QCIOT-RRQ61051EVZ

Wi-Fi 6 and Bluetooth LE PMOD™ and Click Board

Description

The QCIOT-RRQ61051EVZ is a Wi-Fi 6 and Bluetooth® Low Energy (LE) combo module board featuring PMOD™ connector and possibility to add extended headers converting this board to MikroElektronika Click interface compatible solution. This evaluation board is built on a RRQ61051 module which contains the RA6W1 MCU featuring an Arm® Cortex®-M33 processor. It also includes a dual-band 802.11a/b/g/n/ac/ax Wi-Fi subsystem, on-chip memory, flexible peripheral interfaces, and advanced power management capabilities. The module integrates 8MB of Flash, a 40MHz crystal, RF matching components, and offers three antenna options for design flexibility. This module offers a standalone, single-chip solution that supports complex, low-power IoT applications requiring both Wi-Fi and Bluetooth LE connectivity.

Board Contents

- QCIOT-RRQ61051EVZ Wi-Fi 6 and BLE combo evaluation board
- Click Board connectors, which can be soldered if required.

Features

- Arm Cortex-M33: 160MHz
- 704kB SRAM
- Wi-Fi 6, 802.11a/b/g/n/ac/ax 2.4/5GHz, 1x1, 20MHz, MCS9 115Mbps, OFDMA, TWT
- Bluetooth LE 5.1
- WPA/WPA2- Enterprise/Personal, WPA2 SI, WPA3 SAE, and OWE
- 8Mbyte QSPI Flash
- QSPI PSRAM controller
- 2x SPI, 3x UART, 2x I2C, SDIO 3.0 (Device)
- 12-bit ADC, I2S, PDM, PWM
- True Random Number Generator (TRNG)
- Worldwide certified module
- Encryption: AES, DES/3DES, CHACHA, SHA1/224/256, RSA, DH, ECC
- Operating temperature range -40°C to 85°C
- PMOD and Click interface compatible board




Figure 1. Board Image

Contents

1. Functional Description	3
1.1 Board Operation	3
1.2 Connectors	4
1.2.1 PMOD Connector	4
1.2.2 Click Connector	4
1.2.3 Serial Debug Interface	4
1.3 Solder Bridges	5
1.4 Test Points	5
1.5 Setup and Configuration	5
2. Board Design	6
2.1 Hardware Design	6
2.2 Schematic Diagrams	7
2.3 Bill of Materials	9
2.4 Board Layout	10
3. Firmware Image Programming	11
3.1 Renesas Flash Programmer GUI	11
3.1.1 Setting up Renesas Flash Programmer	11
3.2 Flash Downloader	13
3.2.1 Program Firmware Image for Windows	14
3.2.2 Program Firmware Images for Linux	16
4. AT Command Interface	17
5. Terms and Definitions	23
6. References	24
7. Ordering Information	24
8. Revision History	24

1. Functional Description

The board contains one key component and acts as a carrier board for the RRQ61051-008 module (see Figure 2).





Figure 2. QCIOT-RRQ61051EVZ Block Diagram

Three connectors are on the board. The pinout is described in the Connectors section.

- Digilent PMOD Type 3A
- Mikroelektronika Click board compatible interface
- Debug headers for WiFi module debugging

1.1 Board Operation

The board acts as a simple MCU supervised solution where all the network stacks are running on the QCIOT-RRQ61051EVZ board while the MCU hosts the user application. A simplified block diagram is shown in Figure 3.



- Simple provisioning/config API
- Host used mainly for supervision (configuration of RA6W3)
- The entire connectivity stack including cloud connectivity, networking and Wi-Fi/BLE are running on RA6W3

Figure 3. MCU Supervised Application Block Diagram

1.2 Connectors

1.2.1 PMOD Connector

The default communication interface is the PMOD Connector. The Connection diagram and pinout are shown in Figure 4.




Figure 4. PMOD Type 3A Connector

1.2.2 Click Connector

The click connector is a Mikroelektronika Click board compatible connector. The pinout is shown in Figure 5.




Figure 5. Clicker Connectors Pinout

Note: By default, the P2 and P3 connectors are not assembled. SPI and UART share the same pins that are selected using solder bridges (see the Solder Bridges section). For more detail, review the figures in the Schematic Diagrams section.

1.2.3 Serial Debug Interface

The Serial Debug interface is used to trace log messages, configure the board, or for firmware updates. The pinout is described in Table 1. For more detail, review the figures in the Schematic Diagrams section.

Table 1. Serial Debug Interface Pinout

PIN	Signal	Description
GND	Ground	-
1	RX	Receive signal from the host to the module
2	TX	Transmit signal from the module to the host

1.3 Solder Bridges

There are eight solder bridges that allow SPI signals to be routed to the Click interface. The default interface on the board is UART; it is connected to the PMOD connector. The same interface supporting image is flashed to the board after production. Explanations for the solder bridges are provided in Table 2.

Table 2. Solder Bridges

Designator	Default State	Function
SB1	OPEN	P0.08 is connected to P2.6
SB3	OPEN	P0.05 is connected to P2.3
SB5	OPEN	P0.12 is connected to P2.4
SB7	OPEN	P0.09 is connected to P2.5
SB2	CLOSED	P0.08 is connected to P1.1
SB4	CLOSED	P0.05 is connected to P1.2 and P3.5
SB6	CLOSED	P0.12 is connected to P1.3 and P3.6
SB8	CLOSED	P0.09 is connected to P1.4

1.4 Test Points

The RRQ61051-008 module has BLE functionality. To monitor and debug communication between the RA6W1 and BLE chips, there are test points placed on the bottom of the board (see Table 3).

Table 3. Test Points Description

Designator	Signal	Description
TP1	BLE_UART_TX	BLE chip UART TX signal
TP2	BLE_UART_RX	BLE chip UART RX signal
TP3	BLE_HW_RST	BLE chip reset signal
TP4	BLE_UART_RTS	BLE chip UART RTS signal
TP5	BLE_UART_CTS	BLE chip UART CTS signal
TP6	COEX_iBtAct	WIFI and BLE Coexistence control signal
TP7	RFSW1	RF Switch control signal
TP8	RFSW2	RF Switch control signal

1.5 Setup and Configuration

The board setup and configuration are completed using a PMOD interface over the UART with an AT command interface.

It is possible to upload different firmware images supporting different interfaces. Before proceeding, review the board schematic in the Schematic Diagrams section and firmware documentation.

2. Board Design

Figure 6 shows the top and bottom board images.




Figure 6. QCIOT-RRQ61051EVZ, Wi-Fi 6 and Bluetooth LE PMOD and Click Board (Top and Bottom)

2.1 Hardware Design

The board is designed with the PMOD connector as the primary interface. The Click connector is optional. Before using the Click headers, refer to the schematics in the following section, because some interfaces share the same pins. To avoid crosstalk, these signals are routed using solder bridges, as described in the Solder Bridges section.

2.2 Schematic Diagrams





Figure 7. Board Schematic



Title: MOSFET Based Level Shifter	
Project: QCIOT-RRQ61051EVZ	
Size: A3	Sheet: 2 of 2
Variant: [No variations]	Drawn by: JK
	Date: 10/7/2025

Figure 8. Level Shifter Schematic

2.3 Bill of Materials

Qty	Reference Designator	Description	Manufacturer	Manufacturer Part Number
2	C1, C2	CAP CER 1μF 10V X6S 0402	Würth Elektronik	885012105012
2	C3, C4	CAP CER 0.1μF 50V X7R 0402	Würth Elektronik	885012205092
2	C5, C6	CAP CER 10PF 50V C0G/NP0 0402	Würth Elektronik	885012005074
2	C7, C8	CAP CER 10μF 10V X5R 0402	Murata	GRT155R61A106ME13J
1	C9	CAP CER 1000PF 50V X7R 0402	Würth Elektronik	885012205061
3	C10, C11, C12	CAP CER 3.9PF 50V ±0.25pF C0G/NP0 0402	Würth Elektronik	885392005047
1	D1	Led, Green, 360Mcd, 525Nm Rohs Compliant	Würth Elektronik	155060GS73200
1	D2	Led, Blue, 145Mcd, 470Nm Rohs Compliant	Würth Elektronik	155060BS73200
1	D3	Led, Red, 150Mcd, 624Nm Rohs Compliant	Würth Elektronik	155060RS73200
1	D4	Diode Array Schottky 30V SOT523	Diodes Inc.	BAT54ST-7-F
1	P1	CONN header R/A 12POS 2.54MM	Würth Elektronik	61301221021
2	P2, P3	CONN RCPT 8POS 2.54 PCB	Samtec	SSQ-108-03-G-S
1	P4	CONN header 3POS 2.54MM	Würth Elektronik	61300311121
1	Q1	Small Signal MOSFET, 20 V, 540 mA, Dual N-Channel, 6-Pin SOT-563, Pb-Free, Tape and Reel	onsemi	NTZD3154NT1G
3	R1, R2, R11	RES 10kΩ 1% 1/16W 0402	Yageo Group	RC0402FR-0710KP
5	R3, R5, R6, R7, R10	RES 2.7kΩ 1% 1/16W 0402	Yageo Group	RC0402FR-072K7L
3	R4, R15, R16	RES 0Ω JUMPER 1/16W 0402	Yageo Group	RC0402JR-070RL
2	R8, R9	RES 5.1kΩ 1% 1/16W 0402	Yageo Group	RC0402FR-075K1L
1	R12	RES 510Ω 1% 1/16W 0402	Yageo Group	RC0402FR-07510RL
1	R13	RES 1kΩ 1% 1/16W 0402	Yageo Group	RC0402FR-071KP
1	R14	RES 698Ω 1% 1/16W 0402	Yageo Group	RC0402FR-07698RL
1	SW1	SMT Tact Switch 4.7x3.5 mm side push	Würth Elektronik	434331045822
1	U1	Renesas Wi-Fi + Bluetooth® LE Combo Module	Renesas Electronics	RRQ61051-008
1	Y1	830066431 WE-XTAL Quartz Crystal	Würth Elektronik	830066431

2.4 Board Layout




Figure 9. Top Layer




Figure 10. Bottom Layer




Figure 11. Int1 Layer




Figure 12. Int2 Layer

3. Firmware Image Programming

Firmware images can be programmed with the Renesas Flash Programmer GUI using J-Link, which is described in the Renesas Flash Programmer GUI section, or it can be programmed by using the flash downloader and UART (see the Setting up Renesas Flash Programmer section).

3.1 Renesas Flash Programmer GUI

The Renesas Flash Programmer can be downloaded here [Renesas Flash Programmer \(Programming GUI\) | Renesas](#).

Using the Renesas Flash Programmer, the firmware image is flashed using the J-Link interface that is connected to the board using needle adapters. The J-Link interface pads are on both sides of the board (see Figure 13).




Figure 13. J-Link Interface

The J-Link can be connected to the board using the Tag-Connect or Segger 6 pin Needle adapter. Figure 14 shows a 6-pin Tag-Connect Plug-of-Nails™ connector and a TC2030-CLIP.



Figure 14. J-Link Connection Using Tag-Connect Needle Adapter

After the J-Link is connected to the board, configure the Renesas Flash Programmer.

3.1.1 Setting up Renesas Flash Programmer

The following are the initial steps for configuring the Renesas Flash Programmer (see Figure 15).

1. Click **File > New Project**.
2. Select **RA6W1, RA6W2** Microcontroller Family.
3. Enter a project name and click **Connect**.




Figure 15. Setting up Renesas Flash Programmer

A successfully established connection is noted in the Status window with “Operation completed” in green (see Figure 16).

Next, the following procedure selects the firmware image.

1. Click on **Add/Remove Files**.
2. Select **Add File(s)** and browse for the firmware image
3. Set **Address/Offset** to 0h.
4. Click **OK**.




Figure 16. Selecting Firmware Image

After the project has been configured to flash the module, click **Start**. The result is displayed in the Status window. The entire procedure is about 2 minutes.

3.2 Flash Downloader

Programming the firmware image with the UART-Flash Downloader application is required. The flash downloader (`flash_img_downloader.zip`) is provided with the binary images (see Figure 17).

Name	Date modified	Type
binaries	4/15/2024 2:27 PM	File folder
flash_img_downloader_jtag.bat	4/15/2024 11:09 AM	Windows Batch f
flash_img_downloader_jtag_ble.bat	4/15/2024 11:09 AM	Windows Batch f
flash_img_downloader_uart.bat	4/15/2024 11:09 AM	Windows Batch f
flash_img_downloader_uart.sh	4/15/2024 11:09 AM	Shell Script
flash_img_downloader_uart_ble.bat	4/15/2024 11:09 AM	Windows Batch f
flash_img_downloader_uart_ble.sh	4/15/2024 11:09 AM	Shell Script
readme.txt	4/15/2024 11:09 AM	Text Document

Figure 17. Flash Downloader

The following are system requirements for the flash downloader:

- OS (Windows 10 64 bit/Ubuntu 20.04 LTS 64 bit)
- Python 3.12.x and pycryptodome package

The following is helpful for installing Python:

- Install the mandatory python library: `pycryptodome`
 - For Windows: Open a Windows command prompt and enter the following commands:
`python -m pip install pycryptodome`
 - For Linux OS: Open a terminal window and enter the following commands:
`python -m pip install pycryptodome`
- Check the python version: `python -version`
 - Python 3.1.X

The following are options for programming the firmware image with UART:

- For Windows, use the `flash_img_downloader_uart.bat` batch file.
- For Linux, use the `flash_img_downloader_uart.sh` shell script file.
- Hardware: QCIOT-RRQ1EVZ, see Figure 18
- Software: Flash Downloader for UART

Note: This tool is for both Windows and Linux and the programming can be done automatically.




Figure 18. QCIOT-RRQ61051EVZ Board DEBUG UART

3.2.1 Program Firmware Image for Windows

Complete the following steps to program the firmware image using Windows.

1. Execute the batch script in the Windows command prompt.
 - Usage: flash_img_downloader_uart.bat [img full path]
 - Example:
`flash_img_downloader_uart.bat C:\image\8_0_2_5_vndm_wlan_ble_coex_app_at_uart.img`
2. Enter the COM port that should be used.




Figure 19. Run Flash Downloader Over UART

Note: Before running flash downloader with UART, close any existing instances of this COM.




Figure 20. Enter COM Port for the UART

3. If prompted, to start programming the firmware, press the **RST** (Reset) button on the board



Figure 21. Reset QCIOT-RRQ61051EVZ Board

- a. After the script finishes programming the procedure, there are similar message as in Figure 22.




Figure 22. Finished Programming Firmware Image

- b. The whole programming procedure takes about 2 minutes and 30 seconds.
4. After firmware programming is complete, open the Terminal Emulator and configure Tera Term Serial Terminal Application for Windows.
5. Press the **RST** button on the EVB.
6. Check the booting status using the UART.




Figure 23. Debug Interface after New Boot

3.2.2 Program Firmware Images for Linux

Complete the following steps to program the firmware image using Linux:

1. Execute the shell script in the Terminal.
 - Usage: `flash_img_downloader_uart.sh [img full path]`
 - Example: `flash_img_downloader_uart.sh <full_path>/r_wifi_b_ba_e2s.img`

```
LAPW0126:~$ sudo /home/dev/flash_img_downloader/flash_img_downloader_uart.sh /home/dev/flash_img_downloader/r_wifi_b_ba_e2s.img
```

Figure 24. Run Flash Downloader on Linux

Note: While programming, ensure the port of RA6W1 interface is `/dev/ttyUSB0`. Also, close any other minicom instances of this port to ensure port availability.

2. If prompted to start programming the firmware, press the **RST** (Reset) button on the QCIOT-RRQ61051EVZ board.

```
Setting serial port baud rate to 115200.
Connecting to device...
Press RESET.
```

Figure 25. Reset QCIOT-RRQ61051EVZ Board

- a. The script finishes programming the firmware image with UART.

```
Writing to address: 0x00000000 offset: 0x001cb000 chunk size: 0x00001000
Writing to address: 0x00000000 offset: 0x001cc000 chunk size: 0x00001000
Writing to address: 0x00000000 offset: 0x001cd000 chunk size: 0x00001000
Writing to address: 0x00000000 offset: 0x001ce000 chunk size: 0x00001000
Writing to address: 0x00000000 offset: 0x001cf000 chunk size: 0x00001000
Writing to address: 0x00000000 offset: 0x001d0000 chunk size: 0x000001cc
done.
end
.....
.. FINISHED!
.....
```

Figure 26. Finished Programming

3. After the firmware programming is completed, open the Terminal Emulator.
4. Press the **RST** button on the board.
5. Check the boot status and version on the terminal screen.

```
WakeUp source is 0x4

*****
*                               *
*          RRQ61000 SDK Information          *
* ----- *
* *
* - CHIP Name       : RRQ61000 (D3095B)
* - CPU Type        : Cortex-M33 (160MHz)
* - Kernel Version  : FreeRTOS V11.1.0+
* - SFLASH Type     : 8 MB (Renesas AT25SL)
* - SDK Version     : V6.0.5.0.1
* - F/W Version     : RRQ61000-e6fb4822aa-2-e2studio
* - F/W Build Time  : Feb  9 2025 08:52:07
* *
*****

System Mode : Station Only (0)
Network init...OK
>>> Renesas RRQ61x wpa_supplicant 2.10 - Sep/2023
>>> MAC address (sta0) : ec:9f:0d:9f:ff:08
>>> Start STA mode...
```

Figure 27. Boot Status after the Firmware Update

4. AT Command Interface

In Table 4 there is a list of AT commands supported by the module.

Table 4. AT Command List

#	AT Command	Description
1	AT+TRTS=<ip_type>, <local_port>[,<max allowed peers>]	Configure the local port number for TCP server
2	AT+TRTC=<svr_ip>,<svr_port>(<local_port>	Configure the information for TCP client
3	AT+TRUSE=<ip_type>,<local_port>	Open UDP socket
4	AT+TRUR=<remote_ip>,<remote_port>	Configure the IP_addr and port number of UDP client
5	AT+TRPRT=<cid>	Display session information by CID
6	AT+TRPALL	Display all session
7	AT+TRTRM=<cid>[,<remote_ip>,<remote_port>]	Close session by CID
8	AT+TRTALL	Close all session
9	AT+TRSAVE	Save current status of all session
10	AT+TCPDATAMODE=<mode>	Convert received TCP data to hex string. mode(0 1)
11	AT+TRSSLINIT=<role>	Initialize the SSL module
12	AT+TRSSLCFG=<cid>,<conf_id>,<conf_value>	Configure SSL connection
13	AT+TRSSLCO=<cid>,<server_ip>,<server_port>	Connect to an SSL server
14	AT+TRSSLCL=<cid>	Close SSL connection.
15	AT+TRSSLPRT=[<cid>]	Get SSL session
16	AT+TRSSLCERTLIST=<certificate type>	List certificates of list of CA data available
17	AT+TRSSLCERTDELETE=<certificate type>,<name>	Delete a certificate or CA list data
18	AT+TRSSLSAVE	Save current status of all TLS session
19	AT+TRSSLDELETE	Delete saved TLS session
20	AT+PRODGPIOSET=<Port Num>,<Pin Num>,<mode>,<val>	Set the GPIO status to High or Low
21	AT+PRODGPIOGET=<Port Num>,<Pin Num>	Get the GPIO status, which should be high(1) or low(0)
22	AT+PROD_GPIO_RUN <none>	Display GPIO RUN Test
23	AT+XTAL32K_OUT=<on off>	Set XTAL32K CLK OUT to GPIO
24	AT+PRODQSPI=<none>	Check if the QSPI flash is initialized and try to erase/write/read/compare some data. If all tests are done, erase the written data and send OK (result).
25	AT+PRODPWRIL=<Select Power Rail>	Select power rail
26	AT+PRODSLEEP=<mode>,<time>	Set into sleep mode.
27	AT+UOTPWRASC=<offset>,<data>	Write OTP data
28	AT+UOTPRDASC=<address>,<cnt>	Read OTP data
29	AT+TCSMACWR=<mac>,<check_option>	Write MaRc address
30	AT+TCSMACRD <none>	Read Mac Address
31	AT+TCSXTALWR=<X-TAL_trim>,<check_option>	Write XTAL TRIM value
32	AT+TCSXTALRD <none>	Read X-TAL trim value
33	AT+TCSWAFERRD <none>	Read WAFER value on TCS
34	AT+XTALWR=<X-TAL_trim>	Write xtal trim
35	AT+XTALRD	read xtal trim.
36	AT+TCSADD=<tcs_data>	Add tcs data
37	AT+GPIOSET=<Port Num>,<Pin Num>,<mode>,<val>	Set the GPIO status to High or Low
38	AT+GPIOGET=<Port Num>,<Pin Num>	Get the GPIO status, which should be high(1) or low(0).
39	AT+SETCONFIG=<action>,<wake_source>,<port>,<pin>[,<edge_type>]	Set / Clear (1: Set, 2: Clear) wake source (0: RTC, 1: GPT, 2: GPIO, 3: ADC, 4: WIFI, 5: BLE) for port, pin and edge type

#	AT Command	Description
40	AT+GETCONFIG	Query the status of wake-up pins
41	AT+PMGRDPMKA=<period>	Set DPM Kepp-Alive Period (msec: 0 .. 600000)
42	AT+PMGRIPCOND=<ip_condition>	Set IP Condition to enter PMGR_LLD_DPM (1: IPv4, 2: IPv6, 3: Both)
43	AT+PMGRDPMTIMWU=<count>	Set DPM TIM Wakeup Time (DTIM count : 1 .. 6000)
44	AT+PMGRDPMUSERWU=<time>	Set DPM User Wakeup Time (msec : 0 .. 86400000)
45	AT+PMGRCONSTRAINT	Add or Remove PMGR constraint
46	AT+PMGRMCUWUDONE	Notification that MCU is ready
47	AT+PMGRWAKESRC=<action>,<wake_source>	Set / Clear action (1: Set, 2: Clear) PMGR wake source (0: RTC, 1: GPT, 2: GPIO, 3: ADC, 4: WIFI, 5: BLE)
48	AT+PMGRFORCE	Force sleep mode for the specified time
49	AT+NWOTADWSTART=<fw_type>,<uri>,<mcu_fw_name>	Start OTA download
50	AT+NWOTADWSTOP	Stop OTA download
51	AT+NWOTADWPROG=<fw_type>	Get OTA download progress
52	AT+NWOTARENEW	Replace with downloaded FW
53	AT+NWOTASETADDR=<sflash_addr>	Set SFLASH address to store downloaded data from the server
54	AT+NWOTAGETADDR=<fw_type>	Get SFLASH address to store downloaded data from the server
55	AT+NWOTAREADFLASH=<sflash_addr>,<size>	Read SFLASH as much as the input address and length
56	AT+NWOTAERASEFLASH=<sflash_addr>,<size>	Erase SFLASH as much as the input address and length
57	AT+NWOTACOPYFLASH=<dest_sflash_addr>,<src_sflash_addr>,<size>	Copy as much as the length from SFLASH address src_addr to dest_addr
58	AT+NWOTATLSAUTH=<tls_auth_mode>	Set mbedtls_ssl_conf_authmode
59	AT+NWOTAALPN=<alpn_count>,<alpn_1>,<alpn_2>,<alpn_3>	Configure TLS ALPN protocol name
60	AT+NWOTASNI=<sni>	Configure TLS SNI
61	AT+NWOTAALPNDEL	Delete ALPN
62	AT+NWOTASNIDEL	Delete SNI
63	AT+NWOTATLSVER=<tls_version>	Set TLS version
64	AT+NWOTASETIDX=<boot_index>	Set boot index (0 or 1)
65	AT+NWOTAGETIDX	Get boot index
66	AT+NWOTAFWNAME	Get downloaded MCU FW name in User Sflash area
67	AT+NWOTAFWSIZE	Get downloaded MCU FW size in User Sflash area
68	AT+NWOTAFWCRC	Get downloaded MCU FW CRC in User Sflash area
69	AT+NWOTAREADFW=<sflash_addr>,<size>	Read downloaded MCU FW in User Sflash area
70	AT+NWOTATRANSFW	Transfer downloaded MCU FW in User Sflash area
71	AT+NWOTAERASEFW	Erase downloaded MCU FW in User Sflash area
72	AT+NWOTABYMCU=<fw_type>,<size>	Receive RA6W1/RA6W2 RTOS from MCU
73	AT+TMLMACINIT=<none>	Initialize and start the LMAC task.
74	AT+RFTX=<freq>,<BW>,<numFrames>,<frameLen>,<txRate>,<txPower>	RF TX test
75	AT+RFTXSTOP <none>	RF TX stop

#	AT Command	Description
76	AT+RFCWTEST=<freq>,<power>	RF CW test
77	AT+RFCWSTOP <none>	RF CW stop
78	AT+RFRXSTART <none>	RF RX test start
79	AT+RFRXSTATISTICS <none>	RF Display PER
80	AT+RFRXSTATISTICSRESET <none>	Reset PER
81	AT+RFRXSTOP <none>	RF RX test stop
82	AT+RFCONTSTART=<freq>,<power>,<txRate>	RF TX continuous
83	AT+RFCONTSTOP <none>	RF TX continuous stop
84	AT+RFCHANNEL=<channel>,<band>	Change RF channel frequency
85	AT+RFFREQ=<freq>	Change RF frequency
86	AT+RFVER <none>	Display RF driver version
87	AT+RFTXPKT=<freq>,<BW>,<txRate>,<txPower>,<ccaThreshold>,<ccaTimeOut>,<timeOut>,<data-ASCII encoded>	RF TX Packet test
88	AT+RFSCALEMODE=<scale mode> for set command, <none> for get command	RF scale mode get/set
89	AT+NWHTC=<uri>,<option>(<msg>)	HTTP Client Operation (get post put)
90	AT+NWHTCSTLSVER=<tls_version>	Set TLS version
91	AT+NWHTCSNI=<sni>	Configure TLS SNI
92	AT+NWHTCSNIDEL	Delete SNI
93	AT+NWHTCALPN=<alpn_count>,<alpn_1>,<alpn_2>,<alpn_3>	Configure TLS ALPN protocol name
94	AT+NWHTCALPNDEL	Delete ALPN
95	AT+NWHTCTLSAUTH=<tls_auth_mode>	Set TLS auth mode
96	AT+NWHTS	Enable/Disable HTTP Server
97	AT+NWWSC=<operation>,<uri>[<msg>]	Websocket Client Operation(connect disconnect send)
98	AT+NWMQBR=<ip><port>	Configure IP address and Port number for MQTT Broker
99	AT+NWMQQOS=<qos>	Configure MQTT QoS level (0-2)
100	AT+NWMQTLS=<tls>	Enable/Disable tls mode for MQTT
101	AT+NWMQTLSVER=<tls_ver>	0 (1.2) 1 (1.3) 2 (1.2 and 1.3)
102	AT+NWMQALPN=<#><tls_alpn 1>...	Configure TLS ALPN protocol name
103	AT+NWMQSNL=<sni>	Configure TLS SNI
104	AT+NWMQCSUIT=<cipher suit 1><cipher suit 2>...	Configure cipher suits
105	AT+NWMQTS=<#><topic#n>...	Set topics for MQTT Subscriber
106	AT+NWMQATS=<topic>	Add a topic for MQTT Subscriber
107	AT+NWMQDTS=<topic>	Delete a topic for MQTT Subscriber
108	AT+NWMQUTS=<topic>	Unsubscribe from the specified topic
109	AT+NWMQTP=<topic>...	Topics for MQTT Publisher
110	AT+NWMQPING=<period>	Configure MQTT ping period
111	AT+NWMQV311=<use_v311>	Use MQTT protocol v3.1.1. default is v3.1
112	AT+NWMQCID=<client_id>	MQTT Client ID
113	AT+NWMQLI=<name><pw>	Login information for MQTT operation
114	AT+NWMQWILL=<topic><msg><qos>	Will information for MQTT
115	AT+NWMQDEL	Initialize MQTT Configurations
116	AT+NWMQCL=<mqtt_client>	Enable/Disable MQTT Client
117	AT+NWMQMSG=<msg>(<topic>)	Send message by MQTT Publisher
118	AT+NWMQTT=<ip><port><sub_topic><pub_topic><qos><tls>(<username><password>)	MQTT Client (Subscriber/Publisher) Operation
119	AT+NWMQAUTO=<auto>	Configure MQTT Auto Start
120	AT+NWMQTLSEBUFIN=<size>	Set MQTT TLS INCOMING buffer size
121	AT+NWMQTLSEBUFOUT=<size>	Set MQTT TLS OUTGOING buffer size

#	AT Command	Description
122	AT+NWMQTLAUTH=<authmode>	Set MQTT TLS AUTHMODE
123	AT+NWMQCS=<clean_session>	set clean session mode for MQTT
124	AT+NWIIP=<iface>,<ip_addr>,<netmask>,<gw>	Setting for IP Address
125	AT+NWDNS=<dns_ip>	Setting for DNS
126	AT+NWDNS2=<dns_2nd_ip>	Setting for 2nd DNS
127	AT+NWHOHOST=<name>	Get Host IP Address By Name
128	AT+NWPING=<iface>,<dst_ip_addr>,<count>	Ping test
129	AT+NWDHCH=<dhcpc>	Enable/Disable DHCP Client
130	AT+NWDHCHN=<hostname>	Save User DHCP client hostname
131	AT+NWDHCHNDEL	Remove User DHCP client hostname
132	AT+NWDHR=<start_ip>,<end_ip>	Configure IP address range of DHCP Server
133	AT+NWDHLT=<lease_time>	Lease time of DHCP Server
134	AT+NWDHS=<dhcpcd>(<start_ip>,<end_ip>,<lease_time>)	Enable/Disable DHCP Server
135	AT+NWDHIP	Read Clients IP info
136	AT+NWSNS=<server_ip>	Configure IP address for Time Server
137	AT+NWSNS1=<server_ip>	Configure IP address for Time Server1
138	AT+NWSNS2=<server_ip>	Configure IP address for Time Server2
139	AT+NWSNUP=<period>	Configure update period of SNTP Client
140	AT+NWSNTP=<sntp>[,<server_ip>,<period>]	Enable/Disable SNTP Client service
141	AT+NWSNTP1=<sntp>(<server_ip>,<period>)	Enable/Disable SNTP Client service
142	AT+NWSNTP2=<sntp>[,<server_ip>,<period>]	Enable/Disable SNTP Client service
143	AT+NWCRT=<module>	Check if Certificates exist for the module specified
144	AT+NWCRT=<module>	Delete Certificates of the module specified
145	AT+WFMODE=<mode>	Set Wi-Fi Operation Mode
146	AT+WFMAC=<mac>	Current MAC_addr Setting/Inquiry
147	AT+WFSPP=<mac>	MAC Spoofing for Station (set only)
148	AT+WFOPT	OTP MAC (set only)
149	AT+WFOSTAT	Get Wi-Fi profile
150	AT+WFOSTA	Get STA status
151	AT+WFOPBC	Push WSC Button
152	AT+WFOPIN=<pin>	Enter WSC PIN/Generate PIN
153	AT+WFOCWPS	Stop WPS Operation
154	AT+WFOCC=<code>	Set Country Code
155	AT+WFOSCAN=<band>	[STA] Get Scan Results. If <band> is specified : 2(2GHz), 5(5GHz)
156	AT+WFORSSI	Get current RSSI
157	AT+WFOJAP=<ssid>,<auth>,<enc>,<key>[,<hidden>]	[STA] Connect to AP
158	AT+WFOJAPA=<ssid>[,<key>][,<hidden>]	[STA] Connect to WPA/WPA2-AP with SSID/PSK only
159	AT+WFOJAPA3=<wpa3_flag>,<ssid>[,<key>][,<hidden>]	[STA] Connect to WPA/WPA2/WPA3-AP with SSID/PSK only
160	AT+WFOCAP	[STA] Connect to AP configured currently
161	AT+WFOQAP	[STA] Disconnect from AP
162	AT+WFOROAP=<roam>	[STA] Run/Stop STA Roaming
163	AT+WFOROTH=<rsssi>	[STA] Set Roaming threshold RSSI value
164	AT+WFODIS=<disabled>	[STA] Set Wi-Fi Profile Disabled(1) or Enable(0)
165	AT+WFOENTAP=<ssid>,<auth>,<enc>,<phase1>[,<phase2>][,<hidden>]	[STA] Set Enterprise AP profile
166	AT+WFOENTLI=<id>[,<pw>]	[STA] Set Enterprise Log-in ID/PWD
167	AT+WFOASAP=<ssid>,<auth>,<enc>,<key>,<ch>,<country>	[AP] Operation Soft-AP mode

#	AT Command	Description
168	AT+WFOAP	[AP] Operate Soft-AP
169	AT+WFTAP	[AP] Stop Soft-AP
170	AT+WFRAP	[AP] Restart Soft-AP
171	AT+WFLCST	[AP] Get Connected STA List
172	AT+WFAPWM=<mode>	[AP] Set Wi-Fi mode
173	AT+WFAPCH=<ch>	[AP] Set Wi-Fi channel (0:auto)
174	AT+WFAPBI=<interval>	[AP] Set Beacon Interval
175	AT+WFAPUI=<timeout>	[AP] Set User inactivity timeout value (30 ~ 86400)
176	AT+WFAPRT=<threshold>	[AP] Set RTS threshold (1 ~ 2347)
177	AT+WFAPDE=<mac>	[AP] Send Deauth packet to a specific STA
178	AT+WFAPDI=<mac>	[AP] Send Disassoc packet to a specific STA
179	AT+WFMM=<wmm>	[AP] WMM on/off
180	AT+WFMP=<wmmps>	[AP] WMM-PS on/off
181	AT+WFFP2P	[P2P] Find P2P devices
182	AT+WFSP2P	[P2P] Stop the P2P Find operation
183	AT+WFCP2P=<mac>,<wps>,<join>	[P2P] Connect to the peer P2P device
184	AT+WFDP2P	[P2P] Disconnect from P2P device
185	AT+WFPP2P	[P2P] Read P2P Peers information
186	AT+WFPLCH=<ch>	[P2P] Set listen channel value <0 1 6 11>
187	AT+WFPOCH=<ch>	[P2P] Set operation channel value <0 1 6 11>
188	AT+WFPGL=<intent>	[P2P] Set GO Intent (0~15)
189	AT+WFPFT=<timeout>	[P2P] Set P2P Find timeout value (1 ~ 86400 sec.)
190	AT+WFPDN=<name>	[P2P] Set P2P Device Name
191	AT+WFSMSAVE=<run_mode>	[CON] Save Switching system run-mode (0,1)
192	AT+WFPSMODE=<ps_mode>	Set/Get ps mode
193	AT+WFMODESWTCH	[CON] Switch system run-mode
194	AT+WFSETBAND=<band>	Set setband param
195	AT+WFINIT=[<?>]	Run the Wi-Fi init or query the Wi-Fi init status
196	AT+WFINITMODE=<flag>	Set the Wi-Fi initialization enabled
197	AT+HOSTINITDONE	Customer MCU Init
198	?	Commands list with brief and usage
199	HELP=<command>	Print help message
200	AT	Attention command
201	AT+	List available commands
202	ATZ	AT command initialize
203	ATF	Restore to Factory mode (NVRAM clean)
204	ATE=[<?>]	Command echo
205	ATQ=[<?>]	Result Codes On/Off
206	ATB=<baudrate>[[,<databits>],[,<parity>],[,<stopbits>],[,<flow_ctrl>]]	Setting UART parameters
207	AT+RESTART	System Restart
208	AT+CHIPNAME	Chipset Name (RA6W1/RA6W2)
209	AT+VER	FW Version info
210	AT+SDKVER	SDK Version info
211	AT+TIME=<date>,<time>	Set current time
212	AT+RLT	System Runtime Inquiry
213	AT+TZONE=<sec>	Set Timezone (GMT; -43200 ~ 43200)
214	AT+DEFAP <boot>	Factory setting(AP mode) --- SSID:<CHIPNAME>_XXXXXX, Auth:WPA2/CCMP, IP:10.0.0.1, Enable DHCP

#	AT Command	Description
215	AT+DEFCCRNT <boot>	Factory setting(Concurrent mode) --- SSID:<CHIPNAME>_XXXXXX, Auth:WPA2/CCMP, IP:10.0.0.1, Enable DHCP

5. Terms and Definitions

Table 5. Terms and Definitions

AP	Access Point
API	Application Program Interface
Arm	Advanced Risc Machine
Bluetooth LE	Bluetooth® Low Energy
COM	Communication Port
CPU	Central Processing Unit
DPM	Dynamic Power Management
GDB	GNU Debugger
EVB	Evaluation Board
EVK	Evaluation Kit
FSP	Flexible Software Package
GCC	GNU Compiler Collection
GPIO	General-Purpose Input/Output
IDE	Integrated Development Environment
IC	Integrated Circuit
MCU	Micro Controller Unit
PMGR	Power Manager
PXP	Proximity Profile
QSPI	Quad Serial Peripheral Interface
RAM	Random Access Memory
ROM	Read Only Memory
RTC	Real Time Clock
RTOS	Real Time Operating System
RX	Receiver
SD	Secure Digital
SDK	Software Development Kit
SMA	SubMiniature Version A
SoC	System on Chip
SPI	Serial Peripheral Interface
SPS	Serial Port Service
TX	Transmit
UART	Universal Asynchronous Receiver/Transmitter
UDP	User Datagram Protocol
WLCSP	Wafer Level Chip Scale Package
WSL	Windows Subsystem for Linux

6. References

- [RA6W1 Datasheet, Renesas Electronics.](#)
- [RRQ61051 Datasheet, Renesas Electronics](#)

Note: References are for the latest published version, unless otherwise indicated.

7. Ordering Information

Part Number	Description
QCIOT-RRQ61051EVZ	RRQ61051 PMOD Board

8. Revision History

Revision	Date	Description
1.00	Apr 17, 2026	Initial release.

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity.

Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems.

The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

IMPORTANT NOTICE AND DISCLAIMER

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES (“RENESAS”) PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES “AS IS” AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD-PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers who are designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only to develop an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third-party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising from your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use of any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

(Disclaimer Rev.1.01)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit www.renesas.com/contact-us/.