

EU036 Multisensorboard

Software User's Guide

Contents

1. Overview.....	2
1.1 Prerequisites.....	2
1.2 Tools and software versions required	2
1.3 Boards and modules required	2
2. Integration of the external ZMOD libraries.....	3
2.1 ZMOD4410.....	3
2.2 ZMOD4510.....	5
3. Demo1 – Multisensorboard + Y-ASI4U-V5-DB (ASi-5 Slave)	7
4. Demo2A – Multisensorboard + EK-RA6M3 for Cloud by ethernet	8
4.1 IO Adafruit account creation and configuration.....	9
4.2 Cloud connection configuration.....	12
4.3 Boards connection.....	12
5. Demo2B – Multisensorboard + SK-S7G2 TFT and RL78 BLE.....	13
5.1 Boards connection and jumper configuration.....	14
5.2 IDTSense App for smartphones.....	15
6. Demo 3 – Multisensorboard + RL78 BLE PMOD	16
6.1 RL78 BLE PMOD connection.....	17
7. Demo 4 – Multisensorboard + EK-RA6M3 + WINC1500 PMOD for Cloud by WiFi	18
7.1 WiFi configuration.....	19
References.....	20
Revision History	21

1. Overview

In this document some demos, based on the Multisensorboard, will be shown.

The purpose is to demonstrate several ways to distribute the sensors' data through wired and wireless protocols:

1. Demo1: data sent to ASi5 board.
2. Demo2A: data sent to the cloud, using the ethernet connection available on the EK-RA6M3 board.
3. Demo2B: data shown on a display and transmitted via BLE using a SK-S7G2 board.
4. Demo3: data transmitted via BLE using a RL78 BLE PMOD.
5. Demo4: data sent to the cloud, using a WiFi connection with an EK-RA6M3 board and a WINC1500 PMOD module.

For the Multisensorboard the RA FSP platform is used, while the other boards also make use of the Synergy SSP and the RL78 BLE Framework.

For more detailed information, refer also to the Hardware User's Guide [1] and the Quick Start Guide [2].

1.1 Prerequisites

This guide assumes you have some experience with the Renesas e² studio ISDE together with the Flexible Software Package (FSP) and the Synergy Software Package (SSP). Before you perform the procedure in this application note, follow the procedures in the FSP and SSP User Manuals to build and run the **Blinky** projects. Doing so enables you to become familiar with the e² studio and the software packages, to ensure that the debug connection to your board functions properly. In addition, this application note assumes you have some knowledge on BLE and its communication protocols.

1.2 Tools and software versions required

- e² studio ISDE v7.8.0 or greater
- Flexible Software Package (FSP) 1.0.0 using the GCC ARM Embedded Toolchain 9.2.1.20191025
- RA WiFi WINC1500 pack version 1.0.0
- Synergy Software Package (SSP) 1.7.5 using the GCC ARM Embedded Toolchain 7.2.1.20170904
- Segger J-Link USB driver
- IDTSense (Android App and iOS, see section 5.2)
- (optional – needs NDA) ZMOD4410 Indoor Air Quality eCO₂ Firmware ver. 20200205
- (optional – needs NDA) ZMOD4510 Outdoor Air Quality Firmware ver. 20191014

1.3 Boards and modules required

- Y-MULTISENSORBOARD1
- SK-S7G2 (<https://www.renesas.com/us/en/products/synergy/hardware/kits/sk-s7g2.html>)
- EK-RA6M3 (<https://www.renesas.com/kr/en/products/software-tools/boards-and-kits/eval-kits/ek-ra6m3.html>)
- WINC1500 PMOD (<http://www.reloc.it/products/pmod-wi-fi-atwinc1500/>)
- RL78 BLE PMOD (<https://www.renesas.com/kr/en/products/software-tools/boards-and-kits/eval-kits/rl78-g1d-ble-module-expansion-board.html>)

2. Integration of the external ZMOD libraries

The ZMOD4410 and ZMOD4510 air quality sensors are distributed together with a closed source library that provides the interface API for getting the measures from the sensors.

These libraries require to sign an NDA (Non-Disclosure Agreement) with Renesas so they are not included into the projects. Contact the **Sales Support** (<https://idt.na4.teamsupport.com/createticket>) on the ZMOD product page for more information:

- <https://www.idt.com/us/en/products/sensor-products/gas-sensors/zmod4410-indoor-air-quality-sensor-platform>
- <https://www.idt.com/us/en/products/sensor-products/gas-sensors/zmod4510-outdoor-air-quality-sensor-platform>

In this section the integration of ZMOD libraries is explained. The projects are distributed with these sensors disabled as default.

2.1 ZMOD4410

In Figure 1 all the files required for the ZMOD4410 drivers are listed. The zmod4410 folder is located, in each project of the Multisensorboard, at this address:

```
<project_name>\src\drivers\zmod4410
```




Figure 1: ZMOD4410's driver folder with the Library files under NDA indicated.

The files indicated with a red star are part of the library under NDA and must be copied from the downloaded archive "IDT_ZMOD4410-Air-Quality-eCO2-Firmware_SWR_20200205.zip". In details:

1. "eco2.h" from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\eco2_arm"
2. "iaq.h" from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\iaq_arm"
3. "r_cda.h" from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\r_cda_arm"
4. "tvoc.h" from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\tvoc_arm"

5. "zmod4410_calibration.h" from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\zmod4410_calibration_co_arm"
6. "zmod44xx_cleaning.h" from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\zmod44xx_cleaning_arm"
7. "libarm_cortex-m23_eco2.a"¹ from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\eco2_arm\lib"
8. "libarm_cortex-m23_iaq.a"¹ from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\iaq_arm\lib"
9. "libarm_cortex-m23_r_cda.a"¹ from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\r_cda_arm\lib"
10. "libarm_cortex-m23_tvoc.a"¹ from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\tvoc_arm\lib"
11. "libarm_cortex-m23_zmod4410_calibration_co.a"¹ from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\zmod4410_calibration_co_arm\lib"
12. "libarm_cortex-m23_zmod44xx_cleaning.a"¹ from the folder
"ZMOD4410-standard-firmware\gas-algorithm-libraries\ARM\zmod44xx_cleaning_arm\lib"
13. "zmod_44xx_config.h" from the folder
"ZMOD4410-standard-firmware\zmod44xx-api-example_1.5.0\src"
14. "zmod_44xx_types.h" from the folder
"ZMOD4410-standard-firmware\zmod44xx-api-example_1.5.0\src"
15. "zmod_44xx.c" from the folder
"ZMOD4410-standard-firmware\zmod44xx-api-example_1.5.0\src"
16. "zmod_44xx.h" from the folder
"ZMOD4410-standard-firmware\zmod44xx-api-example_1.5.0\src"

¹ Rename the library extension from ".lib" to ".a"

Once copied all the files, the libraries must be included in the project as shown in Figure 2.




Figure 2: ZMOD4410 compiled libraries added to the project (the highlighted only).

Lastly, the ZMOD4410 driver must be enabled defining a new symbol “ENABLE_ZMOD4410” in the “GNU ARM Cross C Compiler/Preprocessor” project settings, as indicated in Figure 2.

2.2 ZMOD4510

Similarly, to the ZMOD4410, in Figure 3 all the files required for the ZMOD4510 drivers are listed. The zmod4510 folder is located, in each project of the Multisensorboard, at this address:

`<project_name>\src\drivers\zmod4510`




Figure 3: ZMOD4510's driver folder with the Library files under NDA indicated.

The files indicated with a red star are part of the library under NDA and must be copied from the downloaded archive “IDT_ZMOD4510-OAQ-Firmware_SWR_20191014.zip”. In details:

1. “oaq.h” from the folder
“ZMOD4510-oaq-firmware\oaq-libraries_4.0.0\ARM\oaq_arm”

2. "libarm_cortex-m23_oaq.a"² from the folder
"ZMOD4510-oaq-firmware\oqa-libraries_4.0.0\ARM\oqa_arm\lib"
3. "zmod_45xx_config.h" from the folder
"ZMOD4510-oaq-firmware\ZMOD45xx_example_2.0.0\src"
4. "zmod_45xx_types.h" from the folder
"ZMOD4510-oaq-firmware\ZMOD45xx_example_2.0.0\src"
5. "zmod_45xx.c" from the folder
"ZMOD4510-oaq-firmware\ZMOD45xx_example_2.0.0\src"
6. "zmod_45xx.h" from the folder
"ZMOD4510-oaq-firmware\ZMOD45xx_example_2.0.0\src"

Once copied all the files, the libraries must be included in the project as shown in Figure 4 and, lastly, the ZMOD4510 driver must be enabled defining a new symbol "ENABLE_ZMOD4510" in the "GNU ARM Cross C Compiler/Preprocessor" project settings, as indicated in Figure 4.




Figure 4: ZMOD4510 compiled libraries added to the project (the highlighted only).

² Rename the library extension from ".lib" to ".a"

3. Demo1 – Multisensorboard + Y-ASI4U-V5-DB (ASi-5 Slave)

VERY IMPORTANT: Remove jumpers J27 and J9 before connecting the two boards.

The goal of this demo is to use the Multisensorboard in combination with the Y-ASI4U-V5-DB in order to easily evaluate the new industrial fieldbus protocol: **Actuator Sensor Interface 5 (ASi-5)**.

Both **Simple and Complex Slave** configurations are supported by the Multisensorboard and are described in the following document:

- Y-ASI4U-V5-DB_software_application_note.pdf

This document also describes how to build a minimalist ASi-5 Master/Slave network in order to transfer the sensor's data from the Multisensorboard to the ASi-5 Master.

Connect the Y-ASI4U-V5-DB with the Multisensorboard using the custom parallel provided cable. Additionally, make sure to connect the longest wire of the cable to pin 4 of the connector J39.



Figure 5: Demo1 connections.

The project to load on the boards is “**Demo1_RSB_ASi5**”. The Y-ASI4U-V5-DB software configuration is described in the Y-ASI4U-V5-DB_software_application_note.pdf.

4. Demo2A – Multisensorboard + EK-RA6M3 for Cloud by ethernet

NOTE: The default jumper configuration [1] is used for this demo.

Aim of this demo is to send some sensors data to the IO Adafruit cloud using the ethernet connection available on the EK-RA6M3 board.




Figure 6: Demo2A connections.

Because of the IO Adafruit Free account limitation, only 4 values (temperature, humidity, ambient light and proximity) are sent each 10 seconds. Moreover, it is possible to control LED1 on the EK-RA6M3 board for testing the subscription channel from the cloud. The result is shown in Figure 7.




Figure 7: Demo2A Dashboard on the IO Adafruit cloud.

The different sensors measurements are collected from the Multisensorboard and sent through a UART bus to the EK-RA6M3. Those values are written in an internal database on the RA6M3 that keeps an image of the latest data.

Asynchronously, the measures are sent to a MQTT server (**IO Adafruit** in this example) that allows to display and register the trend.

On the ethernet port a DHCP client is enabled so no network configurations are required.




Figure 8: Demo2A high-level block diagram.

The two projects to load on the boards are:

1. “**Demo2AB_RSB_R1D1**” on the Multisensorboard.
2. “**Demo2A_EKRA6M3_ETH_IOADA**” on the EK-RA6M3. This project must be modified in order to add the IO Adafruit account information. In the next sections the complete procedure will be explained.

4.1 IO Adafruit account creation and configuration

1. Open the IO Adafruit webpage <https://io.adafruit.com/> and sign up a new account.
2. Create Feeds (Figure 9): Click on the Feeds menu, create 5 new Feeds and name it as:
 - a. als
 - b. humidity
 - c. proximity
 - d. temperature
 - e. EK-LED1
3. Create a Dashboard (Figure 10): Click on the Dashboard menu and create a new dashboard.
4. Configure the Dashboard:
 - a. Create 4 Line Graphs linked to the first 4 feeds created above (Figure 11, Figure 12 and Figure 14).
 - b. Create a Toggle Button linked to the EK-LED1 feed and configure it as shown in Figure 14.
 - c. It is possible to rearrange the objects on the dashboard (Figure 13).





Figure 9: Create feeds.




Figure 10: Create a new Dashboard.




Figure 11: Create a new Line Chart in the Dashboard.




Figure 13: Complete Dashboard view.
 The red arrow indicates the configuration button used to reorganize the blocks.
 The white arrow indicates the key menu location.




Figure 12: Select the Feed to display on the Line Chart.




Figure 14: Line Chart and Toggle Button settings.

4.2 Cloud connection configuration

Only two values must be configured for the IO Adafruit connection:

1. The username.
2. The Adafruit IO Key.

It is possible to find them clicking on the Adafruit IO Key button indicated by the white arrow in Figure 13.

This information must be copied in the file "new_thread0_entry.c". See Figure 15.

```

new_thread0_entry.c
84  /* Adafruit IO */
85  /*
86   Set up an Adafruit IO account.
87
88   In feeds, create the feeds "temperature", "humidity", "als", "proximity", "ek-led1".
89   Create a dashboard with 4 Line Charts and 1 Toggle Button linked to the above feeds.
90
91   Change the macros below to reflect the account name and IO key.
92
93   This demo requires an Ethernet network connection with a direct connection to the internet (no proxy, portals etc).
94  */
95  /* io.adafruit stuff */
96  #define IO_USERNAME .....
97  #define IO_KEY .....
98  #define TEMPERATURE_FEED ..... (IO_USERNAME "/feeds/temperature")
99  #define HUMIDITY_FEED ..... (IO_USERNAME "/feeds/humidity")
100 #define ALS_FEED ..... (IO_USERNAME "/feeds/als")
101 #define PROXIMITY_FEED ..... (IO_USERNAME "/feeds/proximity")
102 #define EK_LED1_FEED ..... (IO_USERNAME "/feeds/ek-led1")
103

```

Figure 15: IO Adafruit connection configuration.

4.3 Boards connection

The UART bus only requires a single connection (in addition to GND) between the two boards.

On the EK-RA6M3 board, the RX point is on pin 1 of J23 on the Arduino connector.

On the Multisensorboard, the TX pin is available in different locations, the user can choose the most convenient one:

- Pin 7 of J6 on the Arduino connector
- Pin 2 of J41 on the PMOD Host port
- Pin 3 of J43 on the PMOD Peripheral port

5. Demo2B – Multisensorboard + SK-S7G2 TFT and RL78 BLE

VERY IMPORTANT: Carefully read the section 5.1 before connecting the two boards.

In this demo, all the sensors' measurements are displayed on the SK-S7G2 LCD display. Moreover, the ZMOD4410 TVOC and eCO₂ are sent over BLE Advertising data. With the IDTSense app it is possible to read and plot the values, refer to section 5.2 for more information.




Figure 16: Complete Demo2B running and IDT Sense app.

The different sensors measurements are collected from the Multisensorboard and sent via the UART bus to the SK-S7G2 using the PMOD ports. Those measurements are written in an internal database that keeps an image of the latest data.

Asynchronously, the data is periodically refreshed on the display of the SK and sent using the BLE advertising payload.




Figure 17: Demo2B high-level block diagram.

The two projects to load on the boards are:

1. "Demo2AB_RSB_R1D1" on the Multisensorboard.
2. "Demo2B_SKS7G2" on the SK-S7G2.

5.1 Boards connection and jumper configuration

The two boards must be connected using the PMOD Peripheral port on the Multisensorboard and the PMODB on the SK-S7G2.

Using the PMOD port allows to power the Multisensorboard directly from the SK. Before connecting the boards, make sure that:

1. Verify that the J15 jumper on the SK-S7G2 is positioned on the 3V3 selection.
2. Move the J44 jumper on the Multisensorboard on the pins 2-3 in order to select the 3V3 voltage.
3. Open J9 on the Multisensorboard disabling the internal 3.3 V buck.

If this configuration is not respected the boards can be permanently damaged.




Figure 18: Power supply chain configuration for the Demo2B.




Figure 19: Position of the power supply jumper for the Demo2B.

5.2 IDTSense App for smartphones

This application is available for Android and for iOS:

- iOS: <https://apps.apple.com/us/app/idtsense/id1388222456>
- Android: <https://play.google.com/store/apps/details?id=com.idt.europe.idtsense>

Once the IDTSense App is opened, the Multisensorboard should appear on the screen (Figure 20 on the left).

Select it and tap on the “Start” button positioned in the lower right corner of the screen. The TVOC and the eCO₂ values, coming from the ZMOD4410, will be visualized and updated in real time (Figure 20 on the right).




Figure 20: IDTSense App connection to the Multisensorboard.

6. Demo 3 – Multisensorboard + RL78 BLE PMOD

NOTE: The default jumper configuration [1] is used for this demo.

Demo3 makes the same BLE advertising of ZMOD4410 data of the Demo2B. The difference is that a RL78 BLE PMOD is directly connected to the PMOD Host port of the Multisensorboard.




Figure 21: Demo3 connections and IDTSense app. In the picture on the left is shown the “UART 2-wire with branch connection”.

Only the ZMOD4410 sensor is initialized and used, its measurements are written in an internal database that keeps an image of the most updated values read. Asynchronously, the data is periodically sent using the BLE advertising payload.




Figure 22: Demo3 high-level block diagram.

The projects to load on the board is:

1. **“Demo3_RSB_R1D1”** on the Multisensorboard.

6.1 RL78 BLE PMOD connection

The RL78 BLE PMOD is connected to the PMOD Host port of the Multisensorboard; the latter is configured for providing a 3.3 V power supply (J42 closed on pins 2-3, as default configuration).

The RA2A1 and the RL78 are connected with a "UART 2-wire with branch connection", as described in [13].

The "branch" connection between the TX pin of the RA2A1 and the WAKEUP pin of the RL78 is made with an external wire: taking advantage of the PMOD Peripheral port of the Multisensorboard (that expose the same pins of the PMOD Host) a wire shorts the pins 1 and 3 as shown in Figure 21.




Figure 23: RL78 PMOD BLE Module "UART 2-wire with branch connection".

7. Demo 4 – Multisensorboard + EK-RA6M3 + WINC1500 PMOD for Cloud by WiFi

NOTE: The default jumper configuration [1] is used for this demo.

This demo is very similar to Demo2A: some sensor data is sent to the IO Adafruit cloud, to only difference is that a WiFi connection is used instead of the ethernet cable.




Figure 24: Demo 4 connections.

The WiFi module is a WINC1500 PMOD connected to the PMOD1 port of the EK-RA6M3.




Figure 25: Demo4 high-level block diagram.

The two projects to load on the boards are:

1. “**Demo2AB_RSB_R1D1**” on the Multisensorboard.
2. “**Demo4_EKRA6M3_WIFI_IOADA**” on the EK-RA6M3. This project must be modified in order to add the IO Adafruit account information and the WiFi configuration.
For the details about the cloud connection please refer to the section 3 of this document.

Moreover, the WINC1500 WiFi driver must be installed in the e2studio IDE: copy the file “Renesas.RA_wifi_winc1500.1.0.0.pack” into the folder:

```
<e2studio_install_dir>\internal\projectgen\ra\packs
```


7.1 WiFi configuration

The only information required are the Access Point SSID, the password and the security type.

This information must be written in this file:

```
src\config_files\aws_clientcredential.h
```

at lines 58, 64 and 74 (Figure 26).



```
aws_clientcredential.h
53  /*
54  .* @brief Wi-Fi network to join.
55  .*
56  .* @todo If you are using Wi-Fi, set this to your network name.
57  .*
58  #define clientcredentialWIFI_SSID....." "
59
60  /*
61  .* @brief Password needed to join Wi-Fi network.
62  .* @todo If you are using WPA, set this to your network password.
63  .*
64  #define clientcredentialWIFI_PASSWORD....." "
65
66  /*
67  .* @brief Wi-Fi network security type.
68  .*
69  .* @see WiFiSecurity_t.
70  .*
71  .* @note Possible values are eWiFiSecurityOpen, eWiFiSecurityWEP, eWiFiSecurityWPA,
72  .* eWiFiSecurityWPA2 (depending on the support of your device Wi-Fi radio).
73  .*
74  #define clientcredentialWIFI_SECURITY.....eWiFiSecurityWPA2
75
76  #endif /* !defined(__AWS_CLIENTCREDENTIAL_H__) */
77
```

Figure 26: WiFi configuration.

On the WiFi port a DHCP client is enabled so no other network information is necessary.

References

- [1] Renesas Electronics, "Multisensorboard – Hardware User's Guide".
- [2] Renesas Electronics, "Multisensorboard – Quick Start Guide".
- [3] Renesas Electronics, "Y-ASI4U-V5-DB – Software Application Note".
- [4] Renesas Electronics, "Renesas RA2A1 Group - User's Manual: Hardware" Oct. 2019 - R01UH0888EJ0100: [Link](#).
- [5] Renesas Electronics, "FS2012 Series Datasheet - High Performance Flow Sensor Module", Aug. 24, 2018: [Link](#).
- [6] Renesas Electronics (IDT), "HS300x Datasheet - High Performance Relative Humidity and Temperature Sensor", Aug. 6, 2018: [Link](#).
- [7] Renesas Electronics, "ISL29033 Datasheet - Ultra-Low Lux, Low Power, Integrated Digital Ambient Light Sensor with Interrupt Function", Rev 5.00 Sep. 28, 2016: [Link](#).
- [8] Renesas Electronics, "ISL29501 Datasheet - Time of Flight (ToF) Signal Processing IC", May. 5, 2017: [Link](#).
- [9] Renesas Electronics, "ISL29501 AN1724 – Firmware Routines", Rev 1.00 Mar. 31, 2017: [Link](#).
- [10] Renesas Electronics (IDT), "OB1203 Preliminary Datasheet - Digital RGB / Ambient Light, Proximity and Photoplethysmography Sensor", Mar. 6, 2019: [Link](#).
- [11] Renesas Electronics (IDT), "ZMOD4410 Datasheet - Gas Sensor Module for TVOC and Indoor Air Quality", Jul. 30, 2019: [Link](#).
- [12] Renesas Electronics (IDT), "ZMOD4510 Datasheet - Gas Sensor Module for Outdoor Air Quality", Sep. 9, 2019: [Link](#).
- [13] Renesas Electronics, "Bluetooth® Low Energy Protocol Stack – User's Manual", Mar 2018 - R01UW0095EJ0122: [Link](#).

Revision History

Rev.	Date	Description	
		Page	Summary
0.01	21 Mar 2020		Initial version.
0.02	25 Mar 2020		Renesas feedback corrections.
0.03	31 Mar 2020		ASi-5 project feedback
0.04	02 Apr 2020		
0.05	07 Apr 2020		Projects and documents updated to FSP 1.0.0
0.06	09 Apr 2020		Added notes on jumper setting for all demos. Added WiFi module driver installation note.
01.00	03 Sept, 2020		Added Document #R30AN0363ED0100

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity.

Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
 4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
 - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.
- Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
 7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
 9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
 11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.4.0-1 November 2017)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/.