

# USB Power Delivery Controller

## VIDWriter 1.2.1.0 Instruction Manual

---

### Introduction

VIDWriter 1.2.1.0 is an instructional tool that generates flash memory image data for Renesas USB Power Delivery turnkey solutions: RTK-G015-EPRSinkCharger.

### Target Device

140W USB Type-C® Charger or MAX 140W Power Bank: RTK-G015-EPRSinkCharger-140W

48V USB-C Port Controller (SPR/EPR TCPC): RAA489400

USB-C Port Manager (TCPM): R9A02G0151

On-Board Charger: RAA489118

### Target VIDWriter

VIDWriter 1.2.1.0 version: 1.2.1.0

**Related Document**

Use this document in combination with the following documents.

The related documents mentioned in this publication may include preliminary versions. However, preliminary versions are not marked as such.

- RAA489400 Data Sheet: R16DS0292EU
- R9A02G0151 Data Sheet: R19DS0101EJ
- E1 Emulator E20 Emulator User's Manual: R20UT0398EJ
- E2 Emulator Lite User's Manual: R20UT3240EJ
- E1/E20 Emulator, E2 Emulator Lite Additional Document for User's Manual (Notes on Connection of RL78): R20UT1994EJ
- Renesas Flash Programmer V3.13 Flash memory programming software User's Manual: R20UT5312EJ
  
- R9A02G015 RTK-G015-EPRSinkCharger Instruction Manual: R19AN0293EJ
  
- RAA489118 Short-Form Data Sheet: R16DO0024EU

## Contents

1. Overview.....	4
1.1 Functions.....	4
1.2 Operating Environment.....	4
1.2.1 Host PC.....	4
1.2.2 Supported OS.....	4
2. Operation Method.....	5
2.1 Setup the VIDWriter.....	5
2.2 View Description.....	5
2.3 Sourcing mode.....	10

## FIGURES

Figure 2-1 Main window for VIDWriter 1.2.1.0.....	5
Figure 2-2 Main window for VIDWriter 1.2.1.0 after Product Configuration.....	6
Figure 2-3 The Field E and the EVB setting vs “Board” configuration.....	7
Figure 2-4 The Field E and the EVB setting vs “BMS” configuration.....	7
Figure 2-5 The Field E and the EVB setting vs “Manual” configuration.....	8
Figure 2-6 Main window for VIDWriter when press Schematic Setting.....	9

## TABLES

Table 2-1 Evaluation boards for each project.....	6
Table 2-2 The supported maximum Type-C sourcing PD Power for Sourcing mode.....	11
Table 2-3 PDO list.....	11

## 1. Overview

### 1.1 Functions

- Change VID and PID parameters in FW if need.
- Generate Flash memory image data.
- Indicates the HW configuration required after feature selection.

### 1.2 Operating Environment

#### 1.2.1 Host PC

- Processor: 1 GHz or faster
- Main memory: At least 1 Gbyte
- Display: Resolution of 1024 x 768 or higher and 65,536 or more colors

#### 1.2.2 Supported OS

- Windows 10 (32-bit or 64-bit)
- Windows 11 (32-bit or 64-bit)

**Remark:**

Microsoft.NET Framework 4.6.1 or later has to be installed.

## 2. Operation Method


### 2.1 Setup the VIDWriter

- 1) Install Microsoft .NET Framework 4.6.1 or later.
- 2) Uses exe file including in this unzip directory.  
This tool can work without installation. DO NOT change directory structure in the unzipped data.

### 2.2 View Description

When you run VIDWriter 1.2.1.0, the window as shown Figure 2-1 will display.

Figure 2-1 Main window for VIDWriter 1.2.1.0




- 1) Menu Bar  
You can check Tool version and FW package version in “Help” -> “About”.
- 2) Field B to select the required feature  
Choose the features that match your required function in this field. Once selected, the recommended turnkey solution will be displayed in Field D and the possible configurations will be shown in Field E.
- 3) Field C to set VID/PID number.  
If you want to use your own hexadecimal VID and PID numbers instead of the default VID/PID(0xFFFF/0x0000) numbers set in this field, overwrite your own numbers to this field. Otherwise, leave VID: FFFF and PID: 0000.
- 4) Window for the Renesas recommended turnkey solution  
The appropriate RTK-G015-EPRSinkCharger will be displayed as Renesas recommended turnkey solution in Field D.

Table 2-1 Evaluation boards for each project

	Maximum power		
	~100 W	~ 140 W	~ 240 W
w/ Battery	RTK-251-SinkCharger-RAA489118 is supported by VIDWriter 1.1.x.x. RTK-251-SinkCharger-ISL9238C is supported by VIDWriter 1.0.x.x.	RTK-G015-EPRSinkCharger is supported by VIDWriter 1.2.1.0.	Under development
w/o Battery	JP214 / RTK-251-SinkAdapter is supported by VIDWriter 1.0.x.x	-	-

Figure 2-2 Main window for VIDWriter 1.2.1.0 after Product Configuration



5) Field E configures the turnkey solution recommended by Renesas. Field E is used to set the Full, Empty, Max Charging Current, and Max sourcing PDP (DRP mode). There are three operating modes: "Board", "BMS", and "Manual". The default firmware uses "Board" and "BMS" mode, in which the switches on the board configure the EVB parameters. "BMS" sets EVB parameters by battery status information from BMS. "Manual" can set EVB parameters directly using the VIDwriter. After setting in Field E, Field D indicates the appropriate physical settings on the EVB. Next, set the switches on the board according to this picture.

**Note:** In order to use "Board" DRP, or "BMS" DRP, "Manual" modes, FW on the board must be rewritten by this VIDWriter 1.2.1.0-generated FW. If operating mode is changed to "Board" from "BMS" or "Manual", FW on the board also must be rewritten by this VIDWriter 1.2.1.0-generated FW.

**Note:** The RTK-G015-EPRSinkCharger does not have a battery protection circuit on the board, so, Renesas strongly recommends using a battery module with Renesas' Battery Management System to avoid over-discharging under the power bank mode. RTK-G015-EPRSinkCharger can support power bank mode as long as the battery module uses protection circuit to avoid over-discharge, over-temperature, etc. However, this should be done at user's own risk.

**Figure 2-3 The Field E and the EVB setting vs “Board” configuration**

	Value
Cells Number SW	3
Config SW	0
Current Limit SW	3

“Full” indicates the maximum battery charging voltage. “Empty” indicates the voltage at which the charger will trickle charge the battery at a low current level if VBAT is below that value.

If the user wants to achieve power bank function with RTK-G015-EPRSinkCharger, please select DRP mode. Otherwise, select Sink only. In the sourcing mode of Power Bank operating, the user selects the sourcing PD Power from the drop-down list. Because default FW on board supports the maximum sourcing PD Power that board can support with current configuration, if the user wants to support other sourcing PD Power, the user should rewrite the FW on the board with this VIDWriter 1.2.1.0-generated FW. See Section 2.3 about how to set maximum sourcing PDP.

**Figure 2-4 The Field E and the EVB setting vs “BMS” configuration**

	Value
Cells Number SW	N/A
Config SW	0
Current Limit SW	7

In “BMS” setting, this EVB frequently retrieves battery related information from RAJ240100 Filefish EVM. In this operating mode, this EVB uses the information obtained from RAJ240100 Filefish EVM instead of SW1B value to configure the On-Board Charger.

If the user wants to achieve power bank function with RTK-G015-EPRSinkCharger, please select DRP mode. Otherwise, select Sink only. In this operating mode, the FW cannot recognize the MaxSysVol, MinSysVol, and Charging Current Limits until R9A02G0151 retrieves the battery information from BMS. So, VIDWriter 1.2.1.0 cannot define the true max sourcing PD Power under sourcing mode. Therefore, the user should set the appropriate Max sourcing PD Power that battery module can support. See Section 2.3 about how to set maximum sourcing PDP.

**Figure 2-5 The Field E and the EVB setting vs “Manual” configuration**

How to set battery information

Battery module configuration to connect

Cells in Series  Cells

Full:  mV/Cell

Empty:  mV/Cell

Full:  mV

Empty:  mV

Charging Current Limit  mA

USB Type-C Charger

Charging(Sink)/Discharging(Source)

Sink only  DRP mode

Sourcing PD Power:

	Value
Cells Number SW	N/A
Config SW	0
Current Limit SW	0

If there is no suitable charging current value on SW1 and/or user does not want to set “Full” and “Empty” as standard values, the user needs to set SW1 to SW position 0 and set the expected charging current value, “Full” and “Empty”. “Full” indicates the maximum battery charging voltage. “Empty” indicates the voltage at which the charger will trickle charge the battery at a low current level if VBAT is below.

If the user wants to achieve power bank function with RTK-G015-EPRSinkCharger, please select DRP mode. Otherwise, select Sink only. In the sourcing mode of Power Bank operating, the user selects the sourcing PD Power from the drop-down list. See Section 2.3 about the maximum sourcing PDP.

- 6) Press the "Schematic Setting Preview" F tab in field D and you will see the recommended turnkey schematics with appropriated parameters, such as Figure 2-6.

Figure 2-6 Main window for VIDWriter when press Schematic Setting

Setting	Value	Unit
Cells Number Setting Resistance	118	kΩ
Config Setting Resistance R1	DNP*	
Config Setting Resistance R2	0	Ω
Charging Current Limit Setting Resistance R3	1.5	kΩ
Charging Current Limit Setting Resistance R4	2.7	kΩ

7) Finally, when you press the "Create FW Data" button, a file save dialog will be displayed. The default storage location is the "My Documents" folder. You can change the save location and file name of the ROM image as you like. If you rewrite this ROM image to R9A02G0151 on the evaluation board, please use Renesas Flash Programmer V3 as programming software. Refer to the following documents.

- Renesas Flash Programmer V3.13 Flash memory programming software User’s Manual (R20UT5312EJ)
- List of MCUs supported by Renesas Flash Programmer V3 (R20UT3599EJ)
- On the development of flash memory programmer by user, refer to **RL78 microcontrollers (RL78 Protocol A) Programmer Edition Application Note (R01AN0815EJ)**.

## 2.3 Sourcing mode

**Note:** The RTK-G015-EPRSinkCharger does not have a battery protection circuit on the board, so, Renesas strongly recommends using a battery module with Renesas' Battery Management System to avoid over-discharging under the power bank mode. RTK-G015-EPRSinkCharger can support power bank mode as long as the battery module uses protection circuit to avoid over-discharge, over-temperature, etc. However, this should be done at user's own risk.

Under sourcing mode for Power Bank operating, RTK-G015-EPRSinkCharger supports standard max sourcing PD Power as shown in Table 2-2 based on following formula.

Available sourcing power = MinSysVol X Charging Current Limit X 2

The standard PD Power in FW for RTK-G015-EPRSinkCharger

= Max supply current (3 or 5A) X Standard supply voltage (SPR: 5, 9, 15, or 20V, EPR: 28V)  
= 15, 27, 45, or 60W (SPR and 3A cable), or 100W (SPR and 5A cable), or 140W (EPR)

The Max sourcing PD Power in FW  $\leq$  Available sourcing power

The max sourcing PDP is calculated by the MinSysVol value and Charging Current Limit value. For example, if the MinSysVol is 11.2V and the charging current limit is 2A, the available sourcing power is 44.8W. As a result, the maximum sourcing PDP of the FW is 27W. When the MinSysVol is 19.6V and the charging current limit is 4A, the available sourcing power is 156.8W. Therefore, the user can choose either 15, 27, 45, 60, 100, or 140W as the Max sourcing PDP. The Max sourcing PDP is calculated by the above formula even though MaxSysVol, MinSysVol, and Charging Current Limits are set manually.

When the operating mode is "BMS", the FW cannot recognize the MaxSysVol, MinSysVol, and Charging Current Limits until R9A02G0151 retrieves the battery information from BMS. Therefore, the user should set the appropriate Max sourcing PD Power that battery module can support.

The USB-PD PDO list, which is used on PD negotiation, will be generated by this Max sourcing PDP.

**Table 2-2 The supported maximum Type-C sourcing PD Power for Sourcing mode**

	2A	4A	6A	8A	10A	12A
2 Cells in series	15W	45W	60W	60W	100W <sup>2</sup>	100W <sup>2</sup>
3 Cells in series	27W	60W	100W <sup>2</sup>	100W <sup>2</sup>	140W <sup>1</sup>	140W <sup>1</sup>
4 Cells in series	45W	60W	100W <sup>2</sup>	140W <sup>1</sup>	140W <sup>1</sup>	140W <sup>1</sup>
5 Cells in series	45W	100W <sup>2</sup>	140W <sup>1</sup>	140W <sup>1</sup>	140W <sup>1</sup>	140W <sup>1</sup>
6 Cells in series	60W	100W <sup>2</sup>	140W <sup>1</sup>	140W <sup>1</sup>	140W <sup>1</sup>	140W <sup>1</sup>
7 Cells in series	60W	140W <sup>1</sup>				

<sup>1</sup> EPR cable is mandatory to realize this max PDP.

<sup>2</sup> EPR cable or 5A cable is mandatory to realize this max PDP.

**Table 2-3 PDO list**

	SPR PDO1	SPR PDO2	SPR PDO3	SPR PDO4	EPR PDO1	EPR PDO2
PDP 15W	5V/3A	-	-	-	-	-
PDP 27W	5V/3A	9V/3A	-	-	-	-
PDP 45W	5V/3A	9V/3A	15V/3A	20V/2.25A	-	-
PDP 60W	5V/3A	9V/3A	15V/3A	20V/3A	-	-
PDP 100W	5V/3A	9V/3A	15V/3A	20V/5A <sup>1</sup>	-	-
PDP 140W	5V/3A	9V/3A	15V/3A	20V/5A <sup>1</sup>	28V/5A <sup>2</sup>	28V AVS <sup>2</sup>

<sup>1</sup> When the connected cable does not have 5A capability, RTK-G015-EPRSinkCharger shall advertise 20V/3A PDO instead of 20V/5A PDO.

<sup>2</sup> When the connected cable does not have EPR capability, RTK-G015-EPRSinkCharger shall not advertise EPR PDO. So, MAX PDO will be 20V/5A PDO when the connected cable has 5A capability.

**Revision History**

Rev.	Date	Description	
		Page	Summary
1.00	Jun.11, 2024	-	Initial release
1.01	Sep.04, 2024	2	Changed document number of RAA489118 Short Form DS

# General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

## 1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity.

Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

## 2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

## 3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

## 4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

## 5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

## 6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between  $V_{IL}$  (Max.) and  $V_{IH}$  (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between  $V_{IL}$  (Max.) and  $V_{IH}$  (Min.).

## 7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

## 8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
  - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
  - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

## Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,  
Koto-ku, Tokyo 135-0061, Japan

[www.renesas.com](http://www.renesas.com)

## Trademarks

USB Type-C® and USB-C® are trademarks of USB Implementers Forum. Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

## Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:

[www.renesas.com/contact/](http://www.renesas.com/contact/).