
ITAR
U1
ISL70002SEH
PLACE THESE CAPS BETWEEN
THE PVINX AND PGNDX PINS ON THE IC ON THE BOTTOM
THESE SIGNALS SHOULD BE TOWARDSTHE LEFT SIDE
ON THE TOP AND BOTTOM OF THE BOARD
MINIMIZE ROUTING CAPACITANCE ON THESE LINES
DRAWN BY: KIRAN BERNARD
DATE: 06-23-2011
ENGINEER: STEVE SCHULTE
RELEASED BY:
UPDATED BY: TIM KLEMANN
DATE: 02/02/2012
TESTER
TITLE: ISL70002SEHEVAL1Z
SINGLE UNIT OPERATION
MASK#
HRDWR ID
REV. A
FILENAME: ~/ISL70002SEH/ISL70002SEHEVAL1ZA
SHEET 1 OF 1
intersil