**RENESAS** Code

Note

PLQP0080KD-A

## HLFQFP Mount Pad Dimensions



To ensure the amount of solder for pad area corresponding to the corner of heat spreader, we recommend set the area of solder resist or a silkscreen on PCB as preventing of solder outflow at reflow.