## Old Company Name in Catalogs and Other Documents

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: http://www.renesas.com

April 1<sup>st</sup>, 2010 Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (http://www.renesas.com)

Send any inquiries to http://www.renesas.com/inquiry.

#### Notice

- 1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anticrime systems; safety equipment; and medical equipment not specifically designed for life support.
  - "Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majorityowned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



# H8S/2400 Series

## DTC Data Transfer Initiated by IRQ Interrupt

## Introduction

This application note describes an example of 128-byte data transfer by using the data transfer controller (DTC). An IRQ interrupt initiates transfer by the DTC.

The DTC is capable of transferring one block (up to 128 bytes) of data in response to a single activation event without CPU intervention.

## Target Device

H8S/2472, H8S/2463, H8S/2462 Group

## Preface

This application note was prepared using the H8S/2472, H8S/2463, H8S/2462 Group, one of the devices on which operation has been confirmed, as the basis.

This program can be used with other H8S/2400 Series MCUs that have the same internal I/O registers as the devices on which operation has been confirmed. Check the latest version of the manual for any additions and modifications to functions.

Careful evaluation is recommended before using this application note.

#### Contents

1.	Specifications	2
2.	Conditions for Application	3
3.	Description of Modules Used	4
4.	Description of Operation	9
5.	Description of Software	10
6.	Documents for Reference	22



## 1. Specifications

In this application note, data in the on-chip ROM are transferred to the on-chip RAM by the DTC, which is activated by the IRQ3 interrupt.

Figure 1 is an overview of the operations, and the list below covers the specifications in detail.

- The DTC is initiated by the IRQ3 interrupt.
- The IRQ interrupt is detected as the falling edge of the signal on the  $\overline{\text{ExIRQ3}}$  pin.
- Set the DTC transfer mode as block transfer mode.
- Specify the number of bytes in a block for transfer as 128.
- The DTC transfers 128 bytes of data in response to a single IRQ3 interrupt request.
- The source area for transfer by the DTC is in the on-chip ROM at addresses H'004000 to H'00407F.
- The amount of data for transfer is 128 bytes, consisting of the following sequence of bytes: H'00, H'01,..., H'7F.
- The destination area for transfer by the DTC is in the on-chip RAM at addresses H'FF0800 to H'FF087F.
- The result (pass or fail) of verifying the data transferred by the DTC is stored in the on-chip RAM from within the IRQ3 interrupt processing routine at the end of transfer by the DTC.



Figure 1 Overview



## 2. Conditions for Application

## Table 1 Conditions for Application

Item	Contents			
Operating frequency	Input clock:	8 MHz		
	System clock (	32 MHz (8 MHz multiplied by 4)		
Operating voltage	3.3 V			
Operating mode	Mode 2 ( <u>MD2</u> = 1, MD	1 = 1)		
Integrated development environment	High-performance Eml	bedded Workshop Version 4.05.00.059		
Evaluation board	Renesas Technology			
	R0K402472D000BR			
C/C++ compiler	Renesas Technology			
	H8S,H8/300 C/C++ Co	ompiler (V.6.02.01.000)		
Compile options	-cpu=2600A:24 -optimize=1 -regparam=3			
	-speed=register,shift,s	truct, expression		
Optimizing linkage editor	Renesas Technology			
	Optimizing Linkage Ed	litor (V.9.04.01.000)		
Linker options	PResetPRG,PIntPRG/01000,			
	P,C,C\$DSEC,	C\$BSEC,D/01400, B,R/0FF0800, S/0FF9600		



## 3. Description of Modules Used

## 3.1 DTC Operation

The DTC stores register information in on-chip RAM. When activated, the DTC reads register information in on-chip RAM and transfers data. After the data transfer, the DTC writes updated register information back to on-chip RAM. The pre-storage of register information in memory makes it possible to transfer data over any required number of channels. The transfer mode can be specified as normal, repeat, or block transfer mode. Setting the CHNE bit in DTC Mode Register B (MRB) to 1 makes it possible to perform a number of transfers with a single activation source (chain transfer).

The 24-bit DTC Source Address Register (SAR) designates the DTC transfer source address, and the 24-bit DTC Destination Address Register (DAR) designates the transfer destination address. After each transfer, SAR and DAR are independently incremented, decremented, or left fixed depending on its register information.



Figure 2 DTC Operation

## 3.2 DTC Activation Sources

The DTC is activated by an interrupt request or by a write to DTC Vector Register (DTVECR) by software. The interrupt request source to activate the DTC is selected by DTC Enable Registers (DTCER). At the end of a data transfer (or the last consecutive transfer in the case of chain transfer), the interrupt flag that became the activation source or the corresponding DTCER bit is cleared. The activation source flag, in the case of RXI1, for example, is the RDRF flag in SCI\_1.

When an interrupt has been designated as a DTC activation source, the existing CPU mask level and interrupt controller priorities have no effect. If there is more than one activation source at the same time, the DTC operates in accordance with the default priorities. Figure 3 shows a block diagram of DTC activation source control.



Figure 3 Block Diagram of DTC Activation Source Control



## 3.3 Location of Register Information and DTC Vector Table

Locate the register information in the on-chip RAM (addresses: H'FFEC00 to H'FFEFF). Register information should be located at an address that is a multiple of four within the range. The method for locating the register information in address space is shown in figure 4 Locate DTC Mode Register A (MRA), SAR, MRB, DAR, DTC Transfer Count Register A (CRA), and DTC Transfer Count Register B (CRB), in that order, from the start address of the register information. In the case of chain transfer, register information should be located in consecutive areas as shown in figure 4, and the register information start address should be located at the vector address corresponding to the interrupt source in the DTC vector table. The DTC reads the start address of the register information from the vector table set for each activation source, and then reads the register information from that start address.

When the DTC is activated by software, the vector address is obtained from:  $H'0400 + (DTVECR[6:0] \times 2)$ . For example, if DTVECR is H'10, the vector address is H'0420.

The configuration of the vector address is a 2-byte unit. Specify the lower two bytes of the register information start address.



Figure 4 DTC Register Information Location in Address Space



#### Table 2 Interrupt Sources, DTC Vector Addresses, and Corresponding DTCEs

Activation		Vector	DTC Vector		
Source Origin	Activation Source	Number	Address	DTCE* <sup>1</sup>	Priority
Software	Write to DTVECR	DTVECR	H'0400 + (vector	—	High
			number × 2)		_ 1
External pins	IRQ0	16	H'0420	DTCEA7	_
	IRQ1	17	H'0422	DTCEA6	
	IRQ2	18	H'0424	DTCEA5	-
	IRQ3	19	H'0426	DTCEA4	-
A/D converter	ADI	28	H'0438	DTCEA3	-
EVC	EVENTI	29	H'043A	DTCEC4	-
IIC_2	IICI2	76	H'0498	DTCEB6	-
IIC_3	IICI3	78	H'049C	DTCED4	-
SCI_3	RXI3	81	H'04A2	DTCEC2	-
	TXI3	82	H'04A4	DTCEC1	-
SCI_1	RXI1	85	H'04AA	DTCEC0	-
	TXI1	86	H'04AC	DTCED7	-
SSU	RXIS	89	H'04B2	DTCED6	-
	TXIS	90	H'04B4	DTCED5	-
IIC_0	IICI0	94	H'04BC	DTCEB5	-
IIC_1	IICI1	98	H'04C4	DTCED3	-
LPC	ERRI	104	H'04D0	DTCEE3	-
	IBFI1	105	H'04D2	DTCEE2	-
	IBFI2	106	H'04D4	DTCEE1	-
	IBFI3	107	H'04D6	DTCEE0	-
USB (only in the	USBINT0	115	H'04E6	DTCEF7	-
H8S/2472)	USBINT1	118	H'04EC	DTCEF6	Low

Notes: \*1 DTCE bits with no corresponding interrupt are reserved, and the write value should always be 0.

## 3.4 Block Transfer Mode

In block transfer mode, one activation source transfers one block of data. Either the transfer source or the transfer destination is designated as a block area. Table 3 lists the register functions in block transfer mode. The block size can be between 1 and 256. When the transfer of one block ends, the initial state of the block size counter and the address register that is specified as the block area is restored. The other address register is then incremented, decremented, or left fixed according to the register information. From 1 to 65,536 transfers can be specified. Once the specified number of transfers has been completed, a CPU interrupt is requested.

#### Table 3 Register Functions in Block Transfer Mode

Name	Abbreviation	Function
DTC source address register	SAR	Transfer source address
DTC destination address register	DAR	Transfer destination address
DTC transfer count register AH	CRAH	Holds block size
DTC transfer count register AL	CRAL	Block size counter
DTC transfer count register B	CRB	Transfer counter



Figure 5 Memory Mapping in Block Transfer Mode



## 4. Description of Operation

Figure 6 shows the operation described in this application note.



Figure 6 Description of Operation



#### 5. Description of Software

#### 5.1 Symbolic Constants

#### Table 4 List of Symbolic Constants

Constant Name	Setting	Description	Used by Functions
TRINF	(*(volatile struct dtc_tag *)0xFFEC00)	DTC transfer information start address (H'FFEC00)	init

#### 5.2 ROM Variables

#### Table 5 List of ROM Variables

Туре	Variable Name	Setting	Description	Used by Functions
const unsigned char	datatable[128]	H'00 to H'7F	Transfer data	init, INT_IRQ3
const unsigned short	dtcad	(unsigned short)&TRINF.R_mr asar.R_mra	DTC transfer information start address	—

## 5.3 RAM Variables

#### Table 6List of RAM Variables

Туре	Variable Name	Description	Used by Functions
unsigned short	ramarea[128]	DTC transfer destination area	main, init, INT_IRQ3
unsigned char	dtcend	DTC transfer state determination flag	main, INT_IRQ3
		0: DTC transfer is in progress	
		1: DTC transfer verify error	
		2: DTC transfer normal completion	

## 5.4 Structure

#### Table 7 List of Structure

Structure Name	Туре	Variable Name	Туре	Variable Name	Number of bits	Description
struct dtc_tag	union	R_mrasar	unsigned char	R_mra	8	MRA setting value
			unsigned long	R_sar	32	SAR setting value
	union	R_mrbdar	unsigned char	R_mrb	8	MRB setting value
			unsigned long	R_dar	32	DAR setting value
	unsigned short	R_cra	—	_	16	CRA setting value
	unsigned short	R_crb		_	16	CRB setting value



## 5.5 List of Functions

#### Table 8 List of Functions

Function Name	Descriptions
PowerOn_Reset	<ul> <li>Initial settings function Initializes status pointer (SP), sets interrupt mask bits, sets uninitialized/initialized data, and calls main function.</li> </ul>
main	Main function     Calls init function. Determine DTC transfer end.
init	<ul> <li>I/O register initialization function</li> <li>Sets clock mode, module stop mode, IRQ3 interrupt, and DTC operation.</li> </ul>
INT_IRQ3	<ul> <li>IRQ3 interrupt processing IRQ3 interrupt request is set to disable. The result of verifying the data transferred by the DTC is stored in the on-chip RAM (dtcend).</li> </ul>



## 5.6 Functions

#### 5.6.1 **PowerON\_Reset Function**

(1) Functional overview

The PowerON\_Reset function initializes the status pointer (SP) and uses embedded functions and standard library functions to set interrupt mask bits and set uninitialized/initialized data. Then it calls the main function.

(2) Arguments

None

- (3) Returned values None
- (4) Description of internal I/O registers used None
- (5) Flowchart



Figure 7 Flowchart (PowerON\_Reset)



#### 5.6.2 main Function

(1) Functional overview

The main function calls the init function to detect the end of the DTC transfer.

- (2) Arguments
  - None
- (3) Returned values None
- (4) Description of internal I/O registers used

The internal I/O registers used by this function are shown below.

Note that the setting values shown are those used in this application note and differ from the initial values.

• Mo	ode Control Registe	r (MDCR)	Number o	f bits: 8 Address: H'FFFFC5
Bit	Bit Name	Setting	R/W	Descriptions
7	EXPE	0	R/W	Extended Mode Enable
				Specifies extended mode.
				0: Single-chip mode
				1: Extended mode
2	MDS2	*	R	Mode Select 2 and 1
1	MDS1	*	R	These bits indicate the input levels at mode pins (MD2 and MD1) (the current operating mode). Bits MDS2 and MDS1 correspond to MD2 and MD1, respectively. MDS2 and MDS1 are read-only bits and they cannot be written to. The mode pin (MD2 and MD1) input levels are latched into these bits when MDCR is read. These latches are canceled by a reset.

Note: \* The initial values are determined by the settings of the  $\overline{\text{MD2}}$  and MD1 pins.



(5) Flowchart



Figure 8 Flowchart

#### 5.6.3 init Function

(1) Functional overview

The init function sets the clock mode, module stop mode, IRQ3 interrupt, and DTC operation.

- (2) Arguments None
- (3) Returned values None
- (4) Description of internal I/O registers used

The internal I/O registers used by this function are shown below.

Note that the setting values shown are those used in this application note and differ from the initial values.

• Int	• Interrupt Control Registers A (ICRA)		Numbe	r of bits: 8 Address: H'FFFEE8
Bit	Bit Name	Setting	R/W	Descriptions
5	ICRA5	0	R/W	Interrupt Control Level
				0: Corresponding interrupt source (IRQ2 and IRQ3) is
				interrupt control level 0 (no priority)

#### • IRQ Status Registers (ISR) Number of bits: 8 Address: H'FFFEEB

Bit	Bit Name	Setting	R/W	Descriptions
3	IRQ3F	0	R/W	<ul> <li>[Setting condition]</li> <li>When the interrupt source selected by the ISCR registers occurs</li> <li>[Clearing conditions]</li> <li>When reading 1, then writing 0</li> <li>When interrupt exception handling is executed when low-level detection is set and IRQ3 or ExIRQ3 input is high</li> <li>When IRQ3 interrupt exception handling is executed when falling-edge, rising-edge, or both-edge detection is set</li> </ul>

• IRQ Sense Control Register L (ISCRL) Number of bits: 8 Address: H'FFFEED

Bit	Bit Name	Setting	R/W	Descriptions
7	IRQ3SCB	0	R/W	IRQ3 Sense Control B
6	IRQ3SCA	1	R/W	IRQ3 Sense Control A
				01: Interrupt request generated at falling edge of IRQ3 or ExIRQ3 input



• DTC Enable Register A (DTCERA) Number of bits: 8 Address: H'FFFEEE DTCER specifies DTC activation interrupt sources. DTCER is comprised of five registers: DTCERA to DTCERF. For DTCE bit setting, use bit manipulation instructions such as BSET and BCLR. Multiple DTC activation sources can be set at one time (only at the initial setting) by masking all interrupts and writing data after executing a dummy read on the relevant register.

Bit	Bit Name	Setting	R/W	Descriptions
4	DTCEA4	1	R/W	DTC Activation Enable
				Setting this bit to 1 specifies a relevant interrupt source as
				a DTC activation source.
				[Clearing conditions]
				<ul> <li>When data transfer has ended with the DISEL bit in MRB set to 1</li> </ul>
				<ul> <li>When the specified number of transfers have ended</li> </ul>
				These bits are not cleared when the DISEL bit is 0 and the
				specified number of transfers have not been completed

• IRQ Sense Port Select Register (ISSR) Number of bits: 8 Address: H'FFFEFD

Bit	Bit Name	Setting	R/W	Descriptions
3	ISS3	1	R/W	1: PA3/ExIRQ3 is selected

• Sta	• Standby Control Register (SBYCR)		Number	of bits: 8 Address: H'FFFF84
Bit	Bit Name	Setting	R/W	Descriptions
2	SCK2	0	R/W	System Clock Select 2 to 0
1	SCK1	0	R/W	Select a clock for the bus master in high-speed mode or
0	SCK0	0	R/W	medium-speed mode.
				000: High-speed mode

• Low-Power Control Register (LPWRCR) Number of bits: 8 Address: H'FFFF85

Bit	Bit Name	Setting	R/W	Descriptions
4	EXCLE	0	R/W	Subclock Input Enable
				Enables/disables subclock input from the EXCL pin.
				0: Disables subclock input from the EXCL pin

D'4	D'I Norre	0	D AA/		
Bit	Bit Name	Setting	R/W	Descriptions	
6	MSTP14	0	R/W	Data transfer controller (DTC)	
5	MSTP13	1	R/W	16-bit free-running timer (FRT)	
4	MSTP12	1	R/W	8-bit timers (TMR_0, TMR_1)	
3	MSTP11	1	R/W	14-bit PWM timer (PWMX)	
1	MSTP9	1	R/W	A/D converter	
0	MSTP8	1	R/W	8-bit timers (TMR_X, TMR_Y)	

# RENESAS

## H8S/2400 Series DTC Data Transfer Initiated by IRQ Interrupt

• Port A Data Direction Register (PADDR) Number of bits: 8 Address: H'FFFFAB

Bit	Bit Name	Setting	R/W	Descriptions
7	PA7DDR	0	W	When set to 1, the corresponding pins function as output
6	PA6DDR	0	W	port pins; when cleared to 0, function as input port pins.
5	PA5DDR	0	W	As the address of this register is the same as that of
4	PA4DDR	0	W	PAPIN, reading from this register indicates the state of
3	PA3DDR	0	W	port A.
2	PA2DDR	0	W	
1	PA1DDR	0	W	
0	PA0DDR	0	W	

Bit	Bit Name	Setting	R/W	Descriptions
3	IRQ3E	1	R/W	IRQ3 Enable
				The IRQ3 interrupt request is enabled when this bit is 1.

• System Control Register (SYSCR)			Number of bits: 8 Address: H'FFFFC4	
Bit	Bit Name	Setting	R/W	Descriptions
5	INTM1	0	R	These bits select the control mode of the interrupt
4	INTM0	0	R/W	controller.
				00: Interrupt control mode 0

• DTC Mode Register A (MRA) Number of bits: 8 (Cannot be directly accessed by the CPU)

Bit	Bit Name	Setting	R/W	Descriptions
7	SM1	1	_	Source Address Mode 1 and 0
6	SM0	0	—	These bits specify an SAR operation after a data transfer.
				10: SAR is incremented after a transfer
				(by +1 when $Sz = 0$ , by +2 when $Sz = 1$ )
5	DM1	1	_	Destination Address Mode 1 and 0
4	DM0	0	—	These bits specify a DAR operation after a data transfer.
				10: DAR is incremented after a transfer
				(by +1 when $Sz = 0$ , by +2 when $Sz = 1$ )
3	MD1	1	_	DTC Mode
2	MD0	0	—	These bits specify the DTC transfer mode.
				10: Block transfer mode
1	DTS	0	_	DTC Transfer Mode Select
				Specifies whether the source side or the destination side
				is set to be a repeat area or block area in repeat mode or
				block transfer mode.
				0: Destination side is repeat area or block area
0	Sz	0	_	DTC Data Transfer Size
				Specifies the size of data to be transferred.
				0: Byte-size transfer



• DTC Mode Register B (MRB) Number of			mber of bits	s: 8, (Cannot be directly accessed by the CPU)
Bit	Bit Name	Setting	R/W	Descriptions
7	CHNE	0	_	DTC Chain Transfer Enable
				When this bit is set to 1, a chain transfer will be performed.
				n data transfer with CHNE set to 1, determination of the end of the specified number of data transfers, clearing of the interrupt source flag, and clearing of DTCER are not performed.
6	DISEL	0	—	DTC Interrupt Select
				When this bit is set to 1, a CPU interrupt request is
				generated every time data transfer ends. When this bit is
				cleared to 0, a CPU interrupt request is generated only when the specified number of data transfer ends.

- DTC Source Address Register (SAR) Number of bits: 24, (Cannot be directly accessed by the CPU) SAR is a 24-bit register that designates the source address of data to be transferred by the DTC. For word-size transfer, specify an even source address. Setting: Start address of array datatable
- DTC Destination Address Register (DAR) Number of bits: 24, (Cannot be directly accessed by the CPU) DAR is a 24-bit register that designates the destination address of data to be transferred by the DTC. For word-size transfer, specify an even destination address. Setting: Start address of array ramarea
- DTC Transfer Count Register A (CRA) Number of bits: 16, (Cannot be directly accessed by the CPU) CRA is a 16-bit register that designates the number of times data is to be transferred by the DTC. In block transfer mode, the CRA is divided into two parts; the upper eight bits (CRAH) and the lower 8 bits (CRAL). CRAH holds the number of transfers while CRAL functions as an 8-bit transfer counter (1 to 256). CRAL is decremented by 1 every time data is transferred, and the contents of CRAH are sent when the count reaches H'00. Setting: H'8080 (When MRA.Sz = B'0 (specifying byte size transfer) and CRA = H'8080, a data block consists of 128 bytes.)
- DTC Transfer Count Register B (CRB) Number of bits: 16, (Cannot be directly accessed by the CPU) CRB is a 16-bit register that designates the number of times data is to be transferred by the DTC in block transfer mode. It functions as a 16-bit transfer counter (1 to 65536) that is decremented by 1 every time data is transferred, and transfer ends when the count reaches H'0000. Setting: H'0001



(5) Flowchart



Figure 9 Flowchart



#### 5.6.4 INT\_IRQ3 Function

(1) Functional overview

The IRQ3 interrupt processing routine disables the IRQ3 interrupt request, and stores the result of verifying the data transferred by the DTC in the on-chip RAM (dtcend).

- (2) Arguments None
- (3) Returned values
  - None
- (4) Description of internal I/O registers used

The internal I/O registers used by this function are shown below.

Note that the setting values shown are those used in this application note and differ from the initial values.

٠	IRQ Enable Registers (	Setting R/W Descriptions				
Bit	Bit Name	Setting	R/W	Descriptions		
3	IRQ3E	0	R/W	IRQ3 Enable		
				The IRQ3 interrupt request is enabled when this bit is 1.		



(5) Flowchart



Figure 10 Flowchart



## 6. Documents for Reference

- Hardware Manual H8S/2472, H8S/2463, H8S/2462 Group Hardware Manual (REJ09B0403) (The latest version can be downloaded from the Renesas Technology Web site.)
- Development Environment Manual H8S, H8/300 Series C/C++ Compiler, Assembler, Optimizing Linkage Editor Compiler Package Ver.7.00 User's Manual (REJ10J2039) (The latest version can be downloaded from the Renesas Technology Web site.)
- Technical News/Technical Updates (The latest information can be downloaded from the Renesas Technology Web site.)



## Website and Support

Renesas Technology Website <u>http://www.renesas.com/</u>

Inquiries

http://www.renesas.com/inquiry csc@renesas.com

## **Revision Record**

		Description			
Rev.	Date	Page	Summary		
1.00	Dec.28.09	—	First edition issued		

All trademarks and registered trademarks are the property of their respective owners.

#### Notes regarding these materials

- 1. This document is provided for reference purposes only so that Renesas customers may select the appropriate Renesas products for their use. Renesas neither makes warranties or representations with respect to the accuracy or completeness of the information contained in this document nor grants any license to any intellectual property rights or any other rights of Renesas or any third party with respect to the information in this document.
- Renesas shall have no liability for damages or infringement of any intellectual property or other rights arising out of the use of any information in this document, including, but not limited to, product data, diagrams, charts, programs, algorithms, and application circuit examples.
- 3. You should not use the products or the technology described in this document for the purpose of military applications such as the development of weapons of mass destruction or for the purpose of any other military use. When exporting the products or technology described herein, you should follow the applicable export control laws and regulations, and procedures required by such laws and regulations.
- 4. All information included in this document such as product data, diagrams, charts, programs, algorithms, and application circuit examples, is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas products listed in this document, please confirm the latest product information with a Renesas sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas such as that disclosed through our website. (http://www.renesas.com)
- 5. Renesas has used reasonable care in compiling the information included in this document, but Renesas assumes no liability whatsoever for any damages incurred as a result of errors or omissions in the information included in this document.
- 6. When using or otherwise relying on the information in this document, you should evaluate the information in light of the total system before deciding about the applicability of such information to the intended application. Renesas makes no representations, warranties or guaranties regarding the suitability of its products for any particular application and specifically disclaims any liability arising out of the application and use of the information in this document or Renesas products.
- 7. With the exception of products specified by Renesas as suitable for automobile applications, Renesas products are not designed, manufactured or tested for applications or otherwise in systems the failure or malfunction of which may cause a direct threat to human life or create a risk of human injury or which require especially high quality and reliability such as safety systems, or equipment or systems for transportation and traffic, healthcare, combustion control, aerospace and aeronautics, nuclear power, or undersea communication transmission. If you are considering the use of our products for such purposes, please contact a Renesas sales office beforehand. Renesas shall have no liability for damages arising out of the uses set forth above.
- 8. Notwithstanding the preceding paragraph, you should not use Renesas products for the purposes listed below:
  - (1) artificial life support devices or systems
  - (2) surgical implantations

*(ENESAS* 

- (3) healthcare intervention (e.g., excision, administration of medication, etc.)
- (4) any other purposes that pose a direct threat to human life

Renesas shall have no liability for damages arising out of the uses set forth in the above and purchasers who elect to use Renesas products in any of the foregoing applications shall indemnify and hold harmless Renesas Technology Corp., its affiliated companies and their officers, directors, and employees against any and all damages arising out of such applications.

- 9. You should use the products described herein within the range specified by Renesas, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas shall have no liability for malfunctions or damages arising out of the use of Renesas products beyond such specified ranges.
- 10. Although Renesas endeavors to improve the quality and reliability of its products, IC products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Please be sure to implement safety measures to guard against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other applicable measures. Among others, since the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 11. In case Renesas products listed in this document are detached from the products to which the Renesas products are attached or affixed, the risk of accident such as swallowing by infants and small children is very high. You should implement safety measures so that Renesas products may not be easily detached from your products. Renesas shall have no liability for damages arising out of such detachment.
- 12. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written approval from Renesas.
- 13. Please contact a Renesas sales office if you have any questions regarding the information contained in this document, Renesas semiconductor products, or if you have any other inquiries.

#### © 2009. Renesas Technology Corp., All rights reserved.