

RX66T Group

Renesas Starter Kit Sample Code (e² studio for CC-RX)

R01AN4589EJ0200 Rev.2.00 Oct 28, 2024

Introduction

Renesas Starter Kits (RSK) are supplied as complete development systems for the selected microcontroller. The kit includes an evaluation board, portable On-Chip Debugger, and a set of peripheral sample code.

Target Device

RX66T Group

Development Environment

IDE: e² studio 2024-10 Compiler: Renesas CC-RX v3.06.00 Hardware: Renesas Starter Kit for RX66T

Contents

1.	Installation	2
2.	Creating the Project Workspace	2
3.	Opening the Sample Code and Source Files	5
4.	Source Code Functionality	5



1. Installation

This section assumes that e² studio and the Renesas RXC toolchain are already installed.

Create a new folder, for example 'C:\Renesas\Workspace\RSK\RSK66T'. Copy the application note zip package 'an-r01an4589ej0200-rx66t-rsk.zip' downloaded from the website to this folder.

2. Creating the Project Workspace

Open e^2 studio by clicking the Windows Start button, select All Programs > Renesas Electronics e2studio > e2 studio.

elect a directory as workspace e ² studio uses the workspace directory	v to store its preferences and development artifac	ts.
Workspace: C:\Users\user_name\e2_	studio\workspace	✓ <u>B</u> rowse
Use this as the default and do not a		
	Launc	h Cancel
oolchain Integration New toolchains available for integra	ation	C
Toolchain Registry		
Toolchain Type	Installation Path	
Toolchain Type Toolchain Type Renesas CCRX	Installation Path C:\Program Files (d80)/Renesas Electronics//C3+	
Toolchain Type Toolchain Type Renesas CCRX		×00110X

In the 'Toolchain Registry' dialog select the 'Renesas CCRX' and 'Renesas CCRX – v3.06.00' checkboxes. Click <Register>.

Cancel

Register

The 'Information' dialog below appears. Click <OK>.





On the 'Welcome to e^2 studio' screen select the 'Workbench' icon as shown below.



1. Right click in the project explorer window and click <Import...>.

e ² works	pace - e ^z studio				
File Edit	t Source Refactor Na	avigate Search Project	t Renesas Views Run Window Help		
%	•••	∼ No Laur	nch Configurations 🗸 on:	· · · · · · · · · · · · · · · · · · ·	🚼 🖏 🕹 📲 🖋 🗖
1 🔂 🕶 🚳	3 • 🖸 • 🞯 • 🕸 •	• 💁 • 🙋 😂 🛷 •	[▶■■]♀ ◆ 补 ◆ ♥ ◆ ◆ ◆ ◆		Quick Access
Projec	t Explorer 🔀 🛛 🖡	∃\$; ▼□□		- 8	Build Targets
					An outline is not available.
	New	>			
	Show In	Alt+Shift+W >			
	Сору	Ctrl+C			
	Copy Qualified Name				
Ē	Paste	Ctrl+V			
~	Delete	Delete			
	Import				
87.8	Export			🧃 Memory Usage 🛚 🙀 Stack Analysis 🛛 🖓 Smart Browser	🖻 🖳 🕶 🔂 🕶 🗖
S.	Refresh	F5	No consoles to display at this time.		
			0 items selected	1	⑦ ♥ ♥ ◎
	= > 0 m m	= / 🙆 📓 🦔 🛛	m 🕿 🗶 🚳		



2. The 'Import - Select' dialog will now appear. Expand the "General" folder icon, and select "Existing Projects into Workspace", then click 'Next'.

e ² Import -		×
Select Create new projects from an archive file or directory.]
Select an import wizard:		
type filter text		
 ✓ Seneral 		
? ≤ Back Next > Einish	Cancel	

 The 'Import - Import Projects' dialog will now appear. Select 'Select archive file', click the <Browse> button and locate the directory: 'C:\Renesas\Workspace\RSK\RSKRX66T\an-r01an4589ej0200-rx66t-rsk.zip'. Click <Finish> to import the project.

e ² Import				
Import Projects Select a directory to search for exist	ing Eclipse projects.			
 ○ Select root directory: ⑥ Select archive file: C:\Reness Projects: 	as\Workspace\RSK\F	RSKRX66T\an-r01	∨ lan4589ej0100-p ∨	B <u>r</u> owse B <u>r</u> owse
Application (Application/) Async_Serial (Async_Serial/ Low_Power_Mode (Low_Po System_Bootloader (System System_loput_Capture (System Timer_PWM (Timer_PWM/ Tutorial (Tutorial/)	wer_Mode/) n_Bootloader/) ntion (System_Bootlo tem_Input_Capture/)		n/)	<u>S</u> elect All <u>D</u> eselect All R <u>e</u> fresh
Options Search for nested projects Copy projects into workspace Hide projects that already exist Working sets Add project to working sets Working sets:	in the workspace		[Ne <u>w</u> S <u>e</u> lect
0	< <u>B</u> ack	<u>N</u> ext >	<u> </u>	Cancel



3. Opening the Sample Code and Source Files

Once imported into e² studio select a project from the project list in the "Project Explorer". Click the arrow next to it to expand the folder contents.

description.txt in the 'doc' folder provides a functional description of the sample.

Clicking the arrow next to the 'src' folder will show the source files.



4. Source Code Functionality

Each source code project is specifically written to run on the appropriate RSK. However, this source code can be useful as an example of peripheral initialization even without the RSK.

Each sample project will contain a C source file that includes "main" in the name, for example "main.c". This source file will include the C function main().



Website and Support

Renesas Electronics Website <u>http://www.renesas.com/</u>

Inquiries

http://www.renesas.com/contact/

All trademarks and registered trademarks are the property of their respective owners.



Revision History

		Description		
Rev.	Date	Page	Summary	
1.00	Nov 20, 2018	-	First edition issued	
2.00	Oct.28.2024	-	Fix the "System_BootLoader" sample project. Update development environment. -IDE: e ² studio 2024-10	
			-Compiler: Renesas CC-RX v3.06.00	

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

— The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

 The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.

In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

The reserved addresses are provided for the possible future expansion of functions. Do not
access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.
- 5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

 The characteristics of Microprocessing unit or Microcontroller unit products in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.