

---

## RZ/G2L Evaluation Board Kit

---

This document provides quick-start instructions for setting up the RZ/G2L Evaluation Board Kit (EVK) and booting Linux.

### Contents

<b>1. EVK Information</b> .....	<b>2</b>
1.1 How to Get the EVK .....	2
1.2 EVK Contents .....	2
<b>2. Quick Start Procedure</b> .....	<b>3</b>
2.1 Quick Start with the HMI SDK .....	3
2.2 Advanced Linux Development Options .....	4
<b>3. Revision History</b> .....	<b>4</b>

## 1. EVK Information

### 1.1 How to Get the EVK

To obtain the RZ/G2L EVK, go to the RZ/G2L EVK [RTK9744L23S01000BE](#) product page and click *Buy/Quote* under *Product Options* ([Buy Direct](#)).

If inquiries about purchasing the RZ/G2L Secure Type, please contact us.

### 1.2 EVK Contents



**RZ/G2L Evaluation Board Kit**

The RZ/G2L Evaluation Board Kit consists of a module board (SOM) and a carrier board, ideal for evaluating the features of the RZ/G2L MPU. The module board complies with the SMARC v2.1 standard.

Main Contents:

- RZ/G2L Module Board (SMARC2.1)
- Common Carrier Board
- USB Cable (USB Type-A- Micro USB Type-B)

## 2. Quick Start Procedure

The **HMI SDK (Human Machine Interface Software Development Kit)**, **VLP (Verified Linux Package)**, and **BSP Plus (Board Support Package Plus)** are available for this guide, and you may choose based on your usage. If you are not sure of the differences, you can also refer to [Renesas RZ Linux Solutions](#) page for more information about the Linux software solutions we provide.

However, if you are new to the RZ/G platform, we recommend starting with the HMI SDK for initial evaluation, as it provides a quicker and easier setup and allows you to experience the basic HMI functionality.

### 2.1 Quick Start with the HMI SDK

For users who require a **quick evaluation and HMI development environment**, the **RZ/G HMI SDK** is available, providing a ready-to-use system and demo applications. In this section, refer to the [Renesas RZ/G HMI SDK](#) website.

The RZ/G HMI SDK is an all-in-one Linux-based development environment for the RZ/G EVK.

The HMI SDK provides a Yocto-based Linux environment with development tools, system libraries, graphics and multimedia support, and HMI frameworks such as HTML5, LVGL, or Flutter, making it easy to create and run HMI applications.

#### ➤Recommended:

We recommend starting with the [Getting Started](#) to begin using the **HMI SDK package**.

Using the pre-built image included in the package, you can create a bootable microSD card for the EVK and boot the Linux environment immediately. Demo applications and a toolchain installer are also included.

If you would like to further explore the HMI applications, refer to the [HMI Applications](#) section after completing all procedures in the [Getting Started](#).

Note: To run the HMI applications, the following equipment is also required. Please refer to [Hardware Setup](#) for more details.

- HDMI Display & HDMI Cable (to display the demo applications)
- USB Hub (to connect multiple USB devices)
- USB Keyboard & Mouse (to operate the demo applications)
- USB Camera (for video input)
- Audio Speaker (for audio output)

#### ➤Optional:

For users who require system customization, a **HMI SDK Yocto Build Package** is also available, allowing the Linux environment and HMI components to be built from source. For detailed procedures, refer to the [Building the HMI SDK with Yocto](#).

## 2.2 Advanced Linux Development Options

In addition to the HMI SDK quick start flow, the VLP and BSP Plus are also available for users who require further customization or prefer to build the Linux environment from source.

### ➤VLP:

For users who do not require the prebuilt HMI applications and need **long-term Linux kernel maintenance** as well as greater customization, the **RZ MPU VLP** is available, providing a validated and stable Linux environment.

You can download the latest VLP from the link below and follow the “*Linux Start-up Guide*” included in the downloaded **RZ MPU Verified Linux Package (ZIP)** to build the VLP.

[RZ MPU Verified Linux Package \[6.1-CIP\] | Renesas](#)

### ➤BSP Plus:

For expert users who want to start development with **the latest LTS kernel** and require a higher level of customization, the **RZ Linux BSP Plus** is available. Refer to the [Renesas RZ Linux BSP Plus](#) website and follow the provided procedures.

## 3. Revision History

Revision	Date	Description
1.00	Mar 28, 2024	Initial release.
1.01	Apr 24, 2024	Update for RZ/G VLP v3.0.6
1.02	May 15, 2024	Update the description in 2.1.1 and 2.1.2.4.
1.03	Jul 31, 2024	Modify the command of environment variables
1.04	Dec 2, 2024	Modifying typo
1.05	Apr 28, 2025	Update the new RZ/G VLP.
2.00	Mar 30, 2026	Updated the content to include the HMI SDK.