

RZ/A1H Group

JCU and PFV Driver Example

R01AN2060EJ0201
Rev.2.01
Feb.2, 2018

Introduction

This package contains the example driver of JPEG Codec Unit "JCU driver" and the example driver of Pixel Format Converter "PFV driver".

JCU driver uses JPEG codec function in RZ/A1H,M,LU, decodes /expands JPEG compressed image and encodes /compresses to JPEG image. PFV driver uses pixel format convert function in RZ/A1H,M and changes the pixel format of the image. PFV driver uses DMAC_RM driver inside. DMAC_RM driver uses the register mode of direct access controller in RZ/A1 group, inputs the image data to PFV and outputs the image from PFV. PFV can change to the pixel format which can be encoded by JCU.

This example is checked on GENMAI board.

Target Device

RZ/A1H Group
RZ/A1M Group
RZ/A1LU Group

The following list shows application notes of sample drivers and sample programs in this package.

- RZ/A1H Group JPEG Codec Unit "JCU" Sample Driver (R01AN1862EJ)
- RZ/A1H Group Pixel Format Converter "PFV" Sample Driver (R01AN1880EJ)
- RZ/A1H Group Direct Access Controller "DMAC_RM" Sample Driver (Attached to PFV) (R01AN1888EJ)
- RZ/A1H Group OS porting layer "OSPL" Sample Program (R01AN1887EJ)

When applying the sample program covered in this application note to another microcomputer, modify the program according to the specifications for the target microcomputer and conduct an extensive evaluation of the modified program.

Sample Program

This sample program operates the following processing.

- (1) R_JCU_SampleDecode function - Decodes JPEG data via JCU unit

decode_sample.c

[On-Chip RAM >> JCU decompression >> On-Chip RAM]

Source image is the global variable corresponding to the file

workspace\RZ_A1H_JCU_PFV_Sample\armcc\common\src\samples\jcu\Image\image01.jpg

Size of image is 800x480.

This function decodes to ARGB8888 format frame buffer in Large-Capacity On-Chip RAM.

The address of data before decompression is set to "buffer.source.address" variable.

The address of data after decompression is set to "buffer.destination.address" variable.

(2) R_JCU_SampleDecodeEncode function - Encodes and decodes JPEG data

decode_encode_sample.c

[On-Chip RAM >> JCU decompression >> On-Chip RAM >> JCU compression >> On-Chip RAM]

This is added JPEG decoding based on R_JCU_SampleDecode function.

Compressed data is output to Large-Capacity On-Chip RAM.

The address of data before decompression is set to "buffer.source.address" variable.

The address of data after decompression is set to "buffer.destination.address" variable.

If compressed data was saved as binary, it is the JPEG file.

You can set calculated quantization table (example) by input quality in "QuantizationTable_Generator.html" file.

(3) R_JCU_SampleDecodeAndShow function - Decodes and play Motion JPEG data and show on the display

decode_show_sample.c

[On-Chip RAM >> JCU decompression >> On-Chip RAM >> VDC5(OUT) >> Display]

The movie data is "g_MotionJPEG_Sample" variable which has data copied from attached "MotionJPEG.avi" file. The sample program picks up JPEG data as each frame from AVI format container.

Frames are decoded to YcbCr422 format and other format frame memory in On-Chip RAM and output to D-sub (Opposite RCA connector).

Size of screen is 800x600. Size of frame is 800x480.

Video output of VDC is used. Video signal input is not used.

(4) R_JCU_SampleVideoEncodeAndShowI function - Encodes and decodes video signal input

video_encode_decode_i_sample.c

[Camera >> VDC5(IN) >> On-Chip RAM >> JCU compression >> On-Chip RAM
>> JCU decompression >> On-Chip RAM >> VDC5(OUT) >> Display]

This function continues to encode and decode each top and bottom field of video signal input connected with RCA connector (at left up) by interlace at the same time (60fps). Decoded image is shown through D-sub (opposite to RCA connector).

This program receives events signaled from interrupt handlers at "R_OSPL_EVENT_Wait" function and responds as followings.

1. After external video image was put in the video buffer, JPEG compression is started.

2. After the compression was finished, the JPEG data is started to decompress to the back buffer.
3. After the decompression was finished, this program shows by swapping the back buffer for the front buffer.

The buffer put JPEG data has 1 frame only.

There is 1 frame delay because operations of compression, decompression and showing.

If compressed data was saved as binary, it is the JPEG file.

- (5) R_JCU_SampleVideoEncodeAndShowP function - Encodes and decodes video signal input

video_encode_decode_p_sample.c

[Camera >> VDC5(IN) >> On-Chip RAM >> JCU compression >> On-Chip RAM
>> JCU decompression >> On-Chip RAM >> VDC5(OUT) >> Display]

This function continues to encode and decode video signal input connected with RCA connector (at left up) by progressive at the same time (60fps). The other specifications are same as R_JCU_SampleVideoEncodeAndShowI function.

- (6) Sample_PFV_PIO function - Converts pixel format via PFV unit

pfv_sample.c

[On-Chip RAM >> PFV Conversion >> On-Chip RAM]

CPU transfers pixel data from the memory to PFV and transfers converted pixel data from PFV to the memory.
This function returns immediately and go to next sample program.

- (7) Sample_PFV_DMAM function - Converts pixel format via PFV unit with DMAM unit

pfv_sample.c

[On-Chip RAM >> DMAM >> PFV Conversion >> DMAM >> On-Chip RAM]

DMAM transfers pixel data from the memory to PFV and transfers converted pixel data from PFV to the memory.
This function returns immediately and go to next sample program.

- (8) Sample_PFV_DMAM_Image function - Shows and blinks a image on the display

pfv_sample.c

[On-Chip RAM >> DMAM >> PFV Conversion >> DMAM >> On-Chip RAM >> VDC5(OUT) >> Display]

This program changes gain parameter in PFV and change pixel format from ARGB8888 to YCbCr422.
Source image is the global variable corresponding to the file

workspace\RZ_A1H_JCU_PFV_Sample\armcc\common\src\samples\pfv\Image\PFV_Sample.bmp

This program outputs to D-sub (Opposite to RCA connector).

This function returns after several seconds and go to next sample program.

JCU and PFV are available without any display.

For example, Sample_PFV_DMAC function and R_JCU_SampleDecode function do not use VDC5.

Website and Support

Renesas Electronics website

<http://www.renesas.com>

Inquiries

<http://www.renesas.com/contact/>

Revision History

Rev.	Date	Description
2.01	Feb.2, 2018	Updated JCU version 2.01, PFV version 1.03.
1.02	Feb.29, 2016	Added explanation of sample program. Updated JCU version 1.03, PFV version 1.02.
1.01	Sep.5.2014	Adjust the byte order in JCU recorder example. Examples were adjusted to be able to run the JCU recorder example after running PFV examples. Only a source file was modified.
1.00	Jun.20.2014	First edition issued.

General Precautions in the Handling of MPU/MCU Products

The following usage notes are applicable to all MPU/MCU products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.
In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.
In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

- The characteristics of an MPU or MCU in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other disputes involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawing, chart, program, algorithm, application examples.
 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
 4. You shall not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics products.
 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (space and undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.
 6. When using the Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat radiation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions or failure or accident arising out of the use of Renesas Electronics products beyond such specified ranges.
 7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please ensure to implement safety measures to guard them against the possibility of bodily injury, injury or damage caused by fire, and social damage in the event of failure or malfunction of Renesas Electronics products, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures by your own responsibility as warranty for your products/system. Because the evaluation of microcomputer software alone is very difficult and not practical, please evaluate the safety of the final products or systems manufactured by you.
 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please investigate applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive carefully and sufficiently and use Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
 9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall not use Renesas Electronics products or technologies for (1) any purpose relating to the development, design, manufacture, use, stockpiling, etc., of weapons of mass destruction, such as nuclear weapons, chemical weapons, or biological weapons, or missiles (including unmanned aerial vehicles (UAVs)) for delivering such weapons, (2) any purpose relating to the development, design, manufacture, or use of conventional weapons, or (3) any other purpose of disturbing international peace and security, and you shall not sell, export, lease, transfer, or release Renesas Electronics products or technologies to any third party whether directly or indirectly with knowledge or reason to know that the third party or any other party will engage in the activities described above. When exporting, selling, transferring, etc., Renesas Electronics products or technologies, you shall comply with any applicable export control laws and regulations promulgated and administered by the governments of the countries asserting jurisdiction over the parties or transactions.
 10. Please acknowledge and agree that you shall bear all the losses and damages which are incurred from the misuse or violation of the terms and conditions described in this document, including this notice, and hold Renesas Electronics harmless, if such misuse or violation results from your resale or making Renesas Electronics products available any third party.
 11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.3.0-1 November 2016)



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics America Inc.

2801 Scott Boulevard Santa Clara, CA 95050-2549, U.S.A.
Tel: +1-408-588-6000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3
Tel: +1-905-237-2004

Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K
Tel: +44-1628-585-100, Fax: +44-1628-585-900

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.

Room 1709, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2265-6688, Fax: +852 2886-9022

Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949
Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HAL II Stage, Indiranagar, Bangalore, India
Tel: +91-80-67208700, Fax: +91-80-67208777

Renesas Electronics Korea Co., Ltd.

12F., 234 Teheran-ro, Gangnam-Gu, Seoul, 135-080, Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5141