# **Quick Start**

**Demonstration Board for ADC0808S** 

Rev. 2.0 — 2 July 2012

**Quick Start** 

# Document information Info Content Keywords PCB2050-1, Demonstration board, ADC, Converter, ADC0808S Abstract This document describes how to use the demonstration board for the analog-to-digital converter ADC0808S.

Overview



#### **Revision history**

Rev	Date	Description
2.0	20120702	Rebranded.
0.1	20081006	Initial version.

### 1. Quick start

#### 1.1 Setup overview

Figure Fig 1 presents the connections to measure ADC0808S.



#### 1.2 Power supply

The board is powered with a single 3.3  $V_{DC}$  power supply. A power supply regulator is used to supply all the circuitry on the board.

#### Table 1. General power supply

Name	Function	View
J4	+3.3V green connector – Power supply 3.3 $V_{\text{DC}}$ / 100 mA.	
J7	Do not connect, optional. Internal 1.8V regulator. +1.8V green connector – Power supply 1.8 V <sub>DC</sub> / 50 mA	
TP1	DGND test point – Digital ground	
TP2	AGND test point – Analog ground	

#### 1.3 Input signals (IN, CLK)

The ADC0808S clock inputs are selectable between 1.8 V Complementary Metal Oxide Semiconductor (CMOS) or Low-Voltage Differential Signals (LVDS).

To ensure a good evaluation of the device, the input signal and the input clock must be synchronized together.

Moreover, the input frequency (Fi, MHz) and the clock frequency (Fclk, Msps) should follow the formula:

$$\frac{Fi}{Fclk} = \frac{M}{N}$$

,where M is an odd number of period and N is the number of samples.

#### Table 2. Input signals, CMOS Clock

Name	Function	View
J1	IN connector – Analog input signal (50 $\Omega$ matching)	
J2	CLKP connector – Single ended 1.8V CMOS clock input signal	
J3	CLKN connector – Grounded on that demo board	
ST7	Clock input format selection. 0: 1.8V CMOS	

#### Table 3. Input signals, LVDS Clock

Name	Function	View
J1	IN connector – Analog input signal (50 $\Omega$ matching)	
J2	CLKP connector – LVDS Clock input, 50 ohms must be soldered on R7 footprint.	
J3	CLKN connector – LVDS complementary Clock input, 50 ohms must be soldered on R8 footprint.	
ST7	Clock input format selection. NC: LVDS	J1 R7 R7 R8 OC,1 J2 J3

## 1.4 Output signals (D0 to D7, IR, CCS)

The digital output signal is available in binary, 2's complement.

A Complete Conversion Signal output (CCS) is provided by the device for the data acquisition.

#### Table 4. Output signals

Name	Function	View
J8	Array connector – ADC digital output(D0 to D7), In Range output (IR) and Complete Conversion Signal (CCS)	

## 1.5 Configuration

The ADC0808S reference, output coding, timing and frequency of complete conversion signal can be adjusted thanks to PCB jumpers.

#### Table 5. Configuration

Name	Function	View
ST2	AGND: Internal reference selected	
	FSIN: External reference from J5 and J6	
J5	External reference ground	
J6	External reference voltage	
ST3	NC: CCS output is at F <sub>clk</sub> frequency	
	0: CCS output is at $F_{clk}/2$ frequency	
ST4	Output format selection: OTC and CEN	
&	00: binary	
ST5	10: 2's complement	
	X1: High impedance	
ST4	Delay control of CCS edge, see datasheet.	B ST9 0
&		
ST5		

# **Notes**