

BASICS OF THE RENESAS SYNERGY™ PLATFORM

Richard Oed



CHAPTER 10 SENDING DATA THROUGH USB USING A QUEUE

CONTENTS

10 SENDING DATA THROUGH USB USING A QUEUE	_03
10.1 Setting Up a USB Port in Synergy Platform	_03
10.2 Sending Messages	_05
10.3 Setting Up a Receiver On the Host Side	_06
Disclaimer	_08

10 SENDING DATA THROUGH USB USING A QUEUE

What you will learn in this chapter:

■ How to setup an USB-transfer using one of the Renesas SynergyTM Application Frameworks and how to receive the data on a host workstation.

In this chapter, we will use the communication framework inside the Application Frameworks to send the state of LED1 through an USB-port to the Windows[®] workstation. For this, you will to add a new thread and a queue to your project from the previous chapter 9 and modify the existing LED thread to send the state as a string to the queue. The new communications thread will then send the string to a terminal program on the host using USB. While programming this exercise, you will experience once again the simplicity the Synergy Software Package (SSP) provides to users, even when setting up complex communications like USB.

If you haven't done the exercise from chapter 9, you can download the project from the book's website (<u>www.renesas.com/synergy-book</u>). Import it according to the instructions given in chapter 5.1.3 and you are all set. Of course, you can download a full project for this chapter as well, if you just want to see how the goal is achieved. If you are using IAR Embedded Workbench[®] for Renesas Synergy[™] (IAR EW for Synergy), you can also download a complete project, if you do not want to follow the instructions below and adjust them as necessary.

10.1 Setting Up a USB Port in Synergy Platform

If you closed e² studio after the last exercise, re-open it and make sure that your project *MyRtosProject* is active. If not, just click on it and it will be displayed in bold. The first step for you is to switch to the *Synergy Configuration* perspective and to go to the *Synergy Configuration* [*MyRtosProject*] view. If this view was closed before, you can re-open it by double clicking on the *configuration.xml* file in the *Project* Explorer view, or by clicking on the *Gear* icon on the main menu bar. As you are a Synergy expert by now, I will not describe every step in detail, as it was already detailed in a previous exercise.

Select the *Threads* tab and add a new thread with the symbol *comms_thread* and the name *Comms Thread*. Also change the priority from the default 1 to 2. Having all threads running at the same priority is something to be avoided. With the newly added thread selected, add a communications framework instance to it. Click on the *New Stack* icon in the *Comms Thread Stack* pane and select *New Stack* \rightarrow *Framework* \rightarrow *Connectivity* \rightarrow *Communications Framework* on sf_el_ux_comms_v2.

Comms	Thread Stacks	🖹 New Stack > 🚽	Exter	nd Stack > 🔊 Rei	nove	P511 P512 P512 	
1	Add Supergy stacks to th	Driver	> .				
	toolbar button (above), c	Framework	>	Analog	>	176 176 177 177 177 177 177 177 177 177	
		X-Ware	>	Audio	>	P400 2 1	
		🔗 Search		Connectivity	>	Communications Framework on sf_comms_telnet	
				Crypto	> .	\bigoplus Communications Framework on sf_el_ux_comms_v2	
			File System	>	Communications Framework on sf_uart_comms		
				Graphics	>	I2C Framework Device on sf_i2c	
Input			Input	>	I2C Framework Shared Bus on sf_i2c		
LevelX			LevelX	>	SPI Framework Device on sf_spi		
Memory >			>	SPI Framework Shared Bus on sf_spi			
				Networking	> P705 2 13 P706 2 14		
				Services	>	P707 22 15 P800 22 16	



This will add the complete stack of the g_sf_comms0 Communications Framework on sf_el_ux_comms_v2 to the system, down to alevel where a user intervention is necessary. You might wonder what the meaning of different colour bars of the thread modules is. It is quite simple: Regular instances are marked in grey, common instances in blue (there is just one global per project) and pink marks options. And the small triangles in the colour bars let you expand or collapse the module trees.

For our project, one USBX port is needed. To add it, click on the optional *Add USBX Port DCD* module and select *New* and *USBX Port DCD on sf_el_ux* for *USBFS*. In the Properties for this module, change the *Full Speed Interrupt Priority* property to e.g. *Priority* 8 (see Figure 10-2).



You might also want to have a look at the USBX Pool Memory Size in the properties of the USBX on ux module. It default to 18 kBytes, which is sufficient for most tasks. If you want to use different transfer classes in the future, you have to adjust the pool size accordingly. The USBX documentation, which can be downloaded from the SSP-page on the Solutions Gallery has all the details for that.

With the *Comms Thread* still selected, add the queue we need for sending the data in the *Comms Thread Objects* pane. Name it *CDC Queue* and assign it the symbol g_cdc_queue in the Properties view. Also set the *Message Size* to 3, as we want to transmit 3 words with 4 bytes each in each transfer and the *Queue Size* to 24 bytes, meaning that the queue has space for two (12-byte) messages.

With this, the configuration of the SSP is complete. Save the configuration and click on the *Generate Project Content* button. Note that the file *comms_thread_entry.c* has been added to the *src-*folder of your project. You will add code to this file during the next steps.

Threads		🔊 New Thread 👔 Remove 😑	Comms Thread Stacks			New Stack	> 🚔 Extend Stack > 🛍 Remove			
♥ ♣ HAL/Common		g.st.comms0 Communications Framework on st.st.ux.somms_y2								
	g_icport I/O Port Driver on r_i	oport								
V © LED Thread		g_u_device_dass_cdc,_acm0 USBK Device Class CDC-ACM G								
					1					
			Class CDC-ACM Source (Optional)	USBX Device Confi		g_usb_interface_desc_c dcacm_0 USBX Interface Configuration				
				- The second sec		Compration				
Comms Th	aread Objects	🐑 New Object > 🕷 Remove		<pre> g_sf_el_ux_dcd_fs_0 USBFS </pre>	USBX Port DCD on sf_el_ux for	US8X on ux				
e g_cdc_c	queue Queue			0		0				
				S Add Transfer Modu for TX [Recommen but optional]	Ile ded for RX [Recommender but optional]	Add USBX Source [Optional]				
ummary B	ISP Clocks Pins Threads M	essaging Components		L						
Propertie	es 🖾 💽 Problems 👒 Sma	art Browser		1	The Conflicts					
cdc_qu	eue Queue				Synergy					
Settings	Property Name	Value CDC Queue								
	Symbol Message Size (Words) Queue Size (Buter)	g_cdc_queue 3								

Figure 10-3: With all additions and modifications made, the Threads tab should look like this

But before you add the code needed to transfer the state of the LED to the host work-station, you will have to add code to the LED Thread to actually copy the message into the queue. For this, switch back to the *C/C++ Perspective* and open the file *led_thread_entry.c.* At the top, add an include directive for the file *comms_thread.h* to share elements, like the g_cdc_queue, from the Comms Thread with the code in the LED Thread. As second step, add a global array of the type char named send_str with 12 characters. And finally, add the following lines just after the ioport write statement inside the while(1) loop in this file:

```
g ioport.p api->pinWrite(Leds.p leds[BSP LED LED1], led level);
if(led level == IOPORT LEVEL HIGH)
{
    strcpy(send_str, "LED off\n\r");
    led_level = IOPORT_LEVEL_LOW;
}
else
{
    strcpy(send_str, "LED on\n\r");
    led level = IOPORT LEVEL HIGH;
}
/* Send the message in the queue. Wait forever for space */
/* to be available in the queue for the message.
                                                           */
tx_queue_send(&g_cdc_queue, send_str, TX_WAIT_FOREVER);
tx_semaphore_get(&g_sw4_semaphore, TX_WAIT_FOREVER);
```

The final step is now to add code to the comms_thread_entry.c file. Open it from the Project Explorer.

Edit the comms_thread_entry.c file and add a global array of 12 elements of the type uint8_t named rx_msg. After that, replace the line tx_thread_sleep(1); inside the while(1) loop with the following:

This concludes all the coding necessary. You may ask now: "Wait a minute: Two lines of code is all what's needed to transfer a string received by a queue over USB? Isn't that too easy?" And the answer is: No, it is so easy. The SSP and the Application Frameworks will take care about everything else. Isn't that really simple. Remember the last time you coded a transfer on another platform? I would guess, there was a huge difference in the effort needed for that.

Now, all what is left, is to build the project. The first time you do that, it will take some time, as the code for the communications framework will need to be compiled as well. Once the project is built with zero errors, connect the S5D9 Promotion Kit and start the debug session. With the *Debug* perspective open, click on *Resume* twice to start the program. As a first test, press SW4 once to see if LED1 still toggles.

10.3 Setting Up a Receiver On the Host Side

With the program running, connect a second USB type A to micro B cable to the USB port labeled J5 at the bottom of the Promotion Kit. Insert the other end into your Windows[®] workstation and wait a couple of seconds until Windows[®] recognizes the board and installs the drivers for it.

Start a terminal emulator program. During the development of this exercise, we used Tera Term Pro, which can be downloaded from <u>https://ttssh2.osdn.jp/</u> and found it quite useful. In Tera Term, you will see the CDC serial port listed. In Figure 10-4 it is COM6, but it is likely to be different on other workstations. If you are not sure, use the Device Manager of Windows[®] to find out the port the board is connected to.

○ T CP/IP	Host:	myhost.exar	myhost.example.com				
	Service:	☑ History○ Telnet	TCP port#: 22				
		● SSH	SSH version:	SSH2			
		○ Other	Protocol:	UNSPEC	~		
Serial	Port	COM6: Serie	elles USB-Gerät (сомб)	~		

Figure 10-4: If $\mathsf{Windows}^{\otimes}$ recognized the board correctly, it will be listed in Tera Term as serial connection

In case, the board is not listed at all or the Device Manager indicates an error, there might be a problem with the driver. Please refer to the latest support entry for this topic in the Renesas Synergy[™] Knowledge Base to resolve this: https://en-support.renesas.com/knowledgeBase/18959077. With the connection made and Tera Term running, press SW4 a couple of times and you should see the LED1 toggling and the state of it output to the terminal as shown in Figure 10-5.

	COM6	- Tera Te	rm VT	- 🗆 X				
File	Edit	Setup	Control	Window	Help			
LED of LED on LED of LED of LED of LED of LED of LED of LED of	f f f						^	
							~	

Figure 10-5: With the transfer running, the terminal program will display the state of LED1 each time SW4 is pressed

CONGRATULATIONS!

You just finished this exercise. And what do you think now: Was this easy or not?

Points to take away from this chapter:

- Adding an USB transfer is easy if the Application Frameworks are used.
- Only very few lines are needed for the implementation.

Disclaimer:

This volume is provided for informational purposes without any warranty for correctness and completeness. The contents are not intended to be referred to as a design reference guide and no liability shall be accepted for any consequences arising from the use of this book.