

RA Family, RL78 Family, RX Family, Renesas Synergy[™] Platform

CTSU Self Test Software

Introduction

This application note explains the Functional safety solution for capacitive touch of Renesas Electronics.

Target Device

RA family

CTSU: RA2A1, RA4M1, RA4M2, RA4M3, RA4W1, RA6M1, RA6M2, RA6M3, RA6M4, RA6M5 Group CTSU2: RA2L1, RA2E1 Group

RL78 Family

CTSUb: RL78/G16 Group CTSU2L: RL78/G23 Group CTSU2La: RL78/G22 Group

RX Family

CTSU: RX113, RX130, RX230, RX231, RX23W, RX671 Group CTSU2SL: RX140 Group

Renesas Synergy™ Platform

Coming soon



Contents

| 1. | Overview | 3 |
|-----|--|----|
| 2. | CTSU Diagnosis | 4 |
| 2.1 | Output Voltage Test | 5 |
| 2.2 | Overvoltage Detection Test | 6 |
| 2.3 | Current Controlled Oscillator Test (19.2uA Correction Mode) | 7 |
| 2.4 | Current Controlled Oscillator Test (2.4uA Correction Mode) | 8 |
| 2.5 | SSCG Oscillator Test | 9 |
| 2.6 | Current Offset DAC Test | |
| 2.7 | Current Offset DAC Test (without TS) | |
| 3. | CTSU2 Diagnosis | 13 |
| 3.1 | Output Voltage Test | 14 |
| 3.2 | Overvoltage Detection Test | 15 |
| 3.3 | Over Current Detection Test | |
| 3.4 | Load Resistance Measurement Test | |
| 3.5 | Current Source Test | |
| 3.6 | SENSCLK Frequency Gain Test | 20 |
| 3.7 | SUCLK Frequency Gain Test | 21 |
| 3.8 | Clock Recovery Test | 22 |
| 3.9 | CFC Oscillator Gain Test | 23 |
| 4. | API specification | 24 |
| 5. | Flowchart of sample application | 25 |
| 6. | Procedure for creating a project using "QE for Capacitive Touch" | 26 |
| 6.1 | RA Family | |
| 6.2 | RL78 Family | |
| 6.3 | RX Family | |
| Rev | vision History | 35 |



1. Overview

Today, as automatic electronic controls systems continue to expand into many diverse applications, the requirement of reliability and safety are becoming an ever-increasing factor in system design. For example, the introduction of the IEC60730 safety standard for household appliances requires manufactures to design automatic electronic controls that ensure safe and reliable operation of their products.

1. Class A: Control functions, which are not intended to be relied upon for the safety of the equipment.

Examples: Room thermostats, humidity controls, lighting controls, timers, and switches.

2. Class B: Control functions, which are intended to prevent unsafe operation of the controlled equipment.

Examples: Thermal cut-offs and door locks for laundry equipment.

3. Class C: Control functions, which are intended to prevent special hazards.

Examples: Automatic burner controls and thermal cut-outs for closed.

Appliances such as washing machines, dishwashers, dryers, refrigerators, freezers, and Cookers / Stoves will tend to fall under the classification of Class B.

This application note describes the CTSU diagnosis software and provides to assist with compliance with IEC60730 class B safety standards.

CTSU hardware can diagnose own internal circuit. This software controls the internal circuit and provides API to diagnose. This software implemented to Renesas RA family Flexible Software Package (FSP) V3.0.0 or later in part of the CTSU module. The diagnosis content is different between CTSU and CTSU2 hardware. This software provides five types of diagnostics for CTSU and nine types for CTSU2. Refer to section <u>2.CTSU diagnosis</u> and section <u>3.CTSU2 diagnosis</u> for detail. The diagnosis can be performed by calling API functions. Diagnosis is performed in addition to normal measurements. Refer to section <u>4.API specification</u> and section <u>5.Flowchart of sample application</u> for detail. When using the diagnosis function, it is recommended to output the config using "QE for Capacitive Touch". By using QE, you can create a project, set a configuration, and output a sample application. Refer to section <u>6.Procedure for creating a project using "QE for Capacitive Touch"</u> for the setting procedure and its details.

In addition, it is possible to accelerate the acquisition of IEC/UL60730 certification for final products which support capacitive touch by using "<u>Renesas Functional Safety Solutions for Home Appliances</u>" together.(It can also use your own program instead of Renesas Functional Safety Solutions for Home Appliances.)



2. CTSU Diagnosis

This chapter describes the following seven types of tests.

- Output Voltage Test
- Overvoltage Detection test
- Current Controlled Oscillator Test (19.2uA Correction Mode)
- Current Controlled Oscillator Test (2.4uA Correction Mode)
- SSCG Oscillator Test
- Current Offset DAC Test
- Current Offset DAC Test (without TS)

CTSU also includes CTSUb.

Current Offset DAC test requires a TS terminal with capacitor: 27pF connected*. Note: CTSUb does not require a TS terminal with capacitor: 27pF connected.



Figure 2.1 Circuits of CTSU Diagnosis



2.1 Output Voltage Test

Diagnose "Low drop output voltage down converter" (VDC) output voltage. This test is for CTSUb other than CTSU.

Operation outline

- (1) ADC module to the scan setting.
- (2) Set CTSU power on.
- (3) Set Self scan mode.
- (4) Set SO value initialize.
- (5) TSCAP voltage measurement by ADC for 4 times with following conditions.
 - Set Load resistance 30k ohm and LDO output 40uA then measure TSCAP voltage by ADC.
 - Set Load resistance 15k ohm and LDO output 40uA then measure TSCAP voltage by ADC.
 - Set Load resistance 30k ohm and LDO output 80uA then measure TSCAP voltage by ADC.
 - Set Load resistance 15k ohm and LDO output 80uA then measure TSCAP voltage by ADC.
- (6) Store above measurement results to dedicated variables.

If stored measurement result is within the standard threshold value range, PASS the diagnosis.

If stored measurement result is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_OUTPUT_VOLTAGE.



2.2 Overvoltage Detection Test

Check ICOMP status while supplying current from Current Offset DAC for a certain period.



Figure 2.2 Circuits of Overvoltage Detection Test

CTSUICOMP: TSCAP Voltage Error Monitor BIT

CTSUSO0 : CTSU Sensor Offset Adjustment BIT

Operation outline

- (1) Set CTSU power on.
- (2) Synchronous Noise Reduction Setting.
- (3) Set High Pass Noise Reduction.
- (4) Set sensor Stabilization.
- (5) Set CLK division.
- (6) Set Self scan mode.
- (7) Normal output IO = L fixed, sensor drive pulse output = Hi-z fixed.
- (8) Start supplying a constant current from Current Offset DAC by setting "0x3FF" to CTSU register.
- (9) CTSU Scan.

If "CTSUICOMP" = 1 in CTSUFN interrupt PASS the diagnosis.

If "CTSUICOMP" = 0 in CTSUFN interrupt, FAIL the diagnosis and return the FSP_ERR_CTSU_DIAG_LDO_OVER_VOLTAGE.



2.3 Current Controlled Oscillator Test (19.2uA Correction Mode)

Diagnose the frequency of Current Controlled Oscillator when 19.2uA correction mode.



Figure 2.3 Circuits of Current Controlled Oscillator Test (19.2uA Correction Mode)

CTSUSPMD: Calibration Mode BIT (CTSUSPMD = 2 is Calibration Mode) CTSUTSOC: Calibration Setting 2 BIT (CTSUTSOC = 1 is Calibration setting 2)

Operation outline

- (1) Set CTSU power on.
- (2) Synchronous Noise Reduction Setting.
- (3) Set High Pass Noise Reduction.
- (4) Set sensor Stabilization.
- (5) Set CLK division.
- (6) Set Self scan mode.
- (7) Set CTSUSPMD = 2, CTSUTSOC = 1.
- (8) CTSU scan for fixed 19.2uA setting.
- (9) Store scan result to dedicated variables.
- (10) If stored scan result is within the standard threshold value range, PASS the diagnosis.

If stored scan result is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_CCO_HIGH.



2.4 Current Controlled Oscillator Test (2.4uA Correction Mode)

Diagnose the frequency of Current Controlled Oscillator when 2.4uA correction mode.



Figure 2.4 Circuits of Current Controlled Oscillator Test (2.4uA Correction Mode)

CTSUSPMD: Calibration Mode BIT (CTSUSPMD = 0 is Capacitance scan mode) CTSUTSOC: Calibration Setting 2 BIT (CTSUTSOC = 1 is Calibration setting 2)

Operation outline

- (1) Set CTSU power on.
- (2) Synchronous Noise Reduction Setting.
- (3) Set High Pass Noise Reduction.
- (4) Set sensor Stabilization.
- (5) Set CLK division.
- (6) Set Self scan mode.
- (7) Set CTSUSPMD = 0, CTSUTSOC = 1.
- (8) CTSU scan for fixed 2.4uA setting.
- (9) Store scan result to dedicated variables.
- (10) If stored scan result is within the standard threshold value range, PASS the diagnosis.

If stored scan result is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_OSCILLATOR_LOW.



2.5 SSCG Oscillator Test



Diagnose the output frequency of SSCG (Spread Spectrum) Oscillator.

Figure 2.5 Circuits of SSCG Oscillator Test

CTSUSPMD: Calibration Mode BIT (CTSUSPMD = 0 is Capacitance scan mode)

CTSUTSOC: Calibration Setting 2 BIT (CTSUTSOC = 1 is Calibration setting 2)

CTSUCLK1 : Spread clock count test BIT (CTSUCLK1 = 1 is spread clock test mode)

Operation outline

- (1) Set CTSU power on.
- (2) Synchronous Noise Reduction Setting.
- (3) Set High Pass Noise Reduction.
- (4) Set sensor Stabilization.
- (5) Set CLK division.
- (6) Set Self scan mode.
- (7) Set CTSUSPMD = 0, CTSUTSOC = 1, CTSUCLKSEL1 = 1.
- (8) CTSU scan.
- (9) Store reference value of scan result to dedicated variables.
- (10) If stored scan result is within the standard threshold value range, PASS the diagnosis.
- (11) If stored scan result is without the standard threshold value range, FAIL the diagnosis and return the FSP_ERR_CTSU_DIAG_SSCG.



2.6 Current Offset DAC Test

Diagnose the frequency of scan result when Current Offset DAC setting is changed. External capacitor of 27pF is necessary for this test.

This test is for CTSU other than CTSUb.



Figure 2.6.1 Circuits of Current Offset DAC Test



Figure 2.6.2 External circuits for Current Offset DAC Test

CTSUSO0: CTSU Sensor Offset Adjustment BIT



Operation outline

- (1) Connect lower limit specification capacitor: 27pF between a TS terminal and GND as Figure 2.5.2.
- (2) Coding into "qe_define.h" for the TS terminal number as following example.

Example: Connect capacitor with TS7.

#define CTSU_CFG_DIAG_DAC_TS (7)

- (3) Set CTSU power on.
- (4) Synchronous Noise Reduction Setting.
- (5) Set High Pass Noise Reduction.
- (6) Set sensor Stabilization.
- (7) Set CLK division.
- (8) Set Self scan mode.
- (9) 1 TS terminal connected with user electrode.
- (10) Set offset value to "CTSUSO0" as scan result becomes around theoretical value 10240 without touching the electrode.
- $\left(11\right)$ Repeat CTSU scan for 6 times with following conditions.
 - Set (2) offset value to "ctsuso0" then CTSU scan without touching the electrode.
 - Set (2) offset value 0x10 to "CTSUSO0" then CTSU scan without touching the electrode.
 - Set (2) offset value 0x20 to "CTSUSO0" then CTSU scan without touching the electrode.
 - Set (2) offset value 0x40 to "CTSUSO0" then CTSU scan without touching the electrode.
 - Set (2) offset value 0x80 to "CTSUSO0" then CTSU scan without touching the electrode.
 - Set (2) offset value 0x100 to "CTSUSO0" then CTSU scan without touching the electrode.
- (12) Store above 6 scan results to dedicated variables.

If stored correction value is within the standard threshold value range, PASS the diagnosis. If stored scan result is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_DAC.



2.7 Current Offset DAC Test (without TS)

Check the frequency of scan result when Current Offset DAC setting is changed. **This test is for CTSUb other than CTSU.**

- (1) ADC module to the scan setting.
- (2) Set CTSU power on.
- (3) TSCAP voltage measurement by ADC for 8 times with following conditions.

Set Load resistance 15k ohm and CTSUSO is 0x200 then measure TSCAP voltage by ADC. Set Load resistance 30k ohm and CTSUSO is 0x100 then measure TSCAP voltage by ADC. Set Load resistance 60k ohm and CTSUSO is 0x080 then measure TSCAP voltage by ADC. Set Load resistance 60k ohm and CTSUSO is 0x070 then measure TSCAP voltage by ADC. Set Load resistance 60k ohm and CTSUSO is 0x060 then measure TSCAP voltage by ADC. Set Load resistance 60k ohm and CTSUSO is 0x060 then measure TSCAP voltage by ADC. Set Load resistance 60k ohm and CTSUSO is 0x050 then measure TSCAP voltage by ADC. Set Load resistance 60k ohm and CTSUSO is 0x030 then measure TSCAP voltage by ADC. Set Load resistance 60k ohm and CTSUSO is 0x030 then measure TSCAP voltage by ADC.

(4) Store above 8 scan results to dedicated variables.

If stored correction value is within the standard threshold value range, PASS the diagnosis.

If stored scan result is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_DAC.



3. CTSU2 Diagnosis

This chapter describes the following nine types of tests.

- Output Voltage Test
- · Overvoltage Detection Test
- Over Current Detection Test
- Load Resistance Measurement Test
- Current Source Test
- SENSCLK Frequency Gain Test
- SUCLK Frequency Gain Test
- · Clock Recovery Test
- · CFC Oscillator Gain Test

CTSU2 also includes CTSU2L, CTSU2La, CTSU2SL.

Output Voltage Test requires the ADC module.



Figure 3.1 Circuits of CTSU2 Diagnosis



3.1 Output Voltage Test

Diagnose "Low drop output voltage down converter" (VDC) output voltage.

Operation outline

- (1) Set 16ch of the ADC module to the scan setting.
- (2) Set CTSU power on.
- (3) Set Self scan mode.
- (4) Set SO value initialize.
- (5) TSCAP voltage measurement by ADC for 8 times with following conditions.
 - Set Load resistance 60k ohm then measure TSCAP voltage by ADC.
 - Set Load resistance 30k ohm then measure TSCAP voltage by ADC.
 - Set Load resistance 15k ohm then measure TSCAP voltage by ADC.
 - Set Load resistance 7.5k ohm then measure TSCAP voltage by ADC.
 - Set VDC gain 20uA then measure TSCAP voltage by ADC.
 - Set VDC gain 40uA then measure TSCAP voltage by ADC.
 - Set VDC gain 80uA then measure TSCAP voltage by ADC.
 - · Set VDC gain 160uA then measure TSCAP voltage by ADC.
- (6) Store above measurement results to dedicated variables.

If stored measurement result is within the standard threshold value range, PASS the diagnosis.

If stored measurement result is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_OUTPUT_VOLTAGE.



3.2 Overvoltage Detection Test

Diagnose overvoltage detection circuit.



Figure 3.2 Circuits of Overvoltage Detection Test

- ICOMP0 : TSCAP Voltage Error Monitor This bit monitors the error status of the TSCAP voltage. (ICOMP0 = 0: Normal TSCAP voltage ICOMP0 = 1: Abnormal TSCAP voltage)
- ICOMPRST: CTSU CTSUICOMP1 Flag Reset. When 1 is written to the ICOMPRST bit, the ICOMP0 and ICOMP1 bits are cleared.



Operation outline (1) Set CTSU power on. (2) Set to internal calibration mode. (3) Set internal voltage as less than 1.65V. ICOMP0 = 0: PASS ICOMP0 = 1: FAIL, return FSP ERR CTSU DIAG OVER VOLTAGE (4) Set internal voltage as equal or greater than 1.65V. ICOMP0 = 1: PASS ICOMP0 = 0: FAIL, return FSP_ERR_CTSU_DIAG_OVER_VOLTAGE (5) Set "ICOMPRST" =1 (Since internal voltage is equal or greater than 1.65V). ICOMP0 = 1: PASS ICOMP0 = 0: FAIL, return FSP_ERR_CTSU_DIAG_OVER_VOLTAGE (6) Set internal voltage as less than 1.65V (Since it doesn't execute "ICOMPRST"=1). ICOMP0 = 1: PASS ICOMP0 = 0: FAIL, return FSP_ERR_CTSU_DIAG_OVER_VOLTAGE (7) Set "ICOMPRST" =1 (It is reset).

ICOMP0 = 0: PASS ICOMP0 = 1: FAIL, return FSP_ERR_CTSU_DIAG_OVER_VOLTAGE



3.3 Over Current Detection Test

Diagnose over current detection circuit.



Figure 3.3 Circuits of Over Current Detection Test

CTSUPON: CTSU Power Supply Enable

Operation outline

- (1) Discharge TSCAP Capacitor.
- (2) Charge TSCAP Capacitor by CTSUPON.
- (3) CTSU scan start.
- (4) If "ICOMP1" =1 in CTSUFN interrupt, PASS the diagnosis.

If "ICOMP1" =0 in CTSUFN interrupt, FAIL the diagnosis, and return FSP_ERR_CTSU_DIAG_OVER_CURRENT.



ICOMP1: CTSU Sense Current Error Monitor. This bit monitors the error status of the sensor current (ICOMP0 = 0: Normal TSCAP current ICOMP0 = 1: Abnormal TSCAP current)

3.4 Load Resistance Measurement Test

Diagnose VDC internal resistance.



Figure 3.4 Circuits of Load Resistance Measurement Test

Operation outline

- (1) Set CTSU power on.
- (2) Set high resolution pulse mode.
- (3) Scan the current input to the ICO by passing current through the internal resistance in each range. Scan CTSU under the following conditions.
 - Set Load resistance 60k ohm, then CTSU scan.
 - · Set Load resistance 30k ohm, then CTSU scan.
 - · Set Load resistance 15k ohm, then CTSU scan.
 - Set Load resistance 7.5k ohm, then CTSU scan.
- (4) Correct the above 4 scan results by Load resistance variation (Trimming Register) coefficient.
- (5) Store above correcting value to dedicated variables.
- (6) If stored correcting value is within the standard threshold value range, PASS the diagnosis.

If stored correcting value is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_LOAD_RESISTANCE.



3.5 Current Source Test

Diagnose Current Offset DAC Current source.



Figure 3.5 Circuits of Current Source Test

Operation outline

- (1) Set CTSU power on.
- (2) Set high resolution pulse mode.
- (3) Set Self scan mode.
- (4) Set SO value initialization.
- (5) VDC N-ch setting (40uA mode)
- (6) DAC initial setting.
- (7) Scan CTSU under the following conditions.
 - 7-1) Scan the upper current source 16 times.
 - DAC: Upper current source 1 unit ON [10uA]
 - 7-2) All combinations of lower current source 8/10 units Scan 10 times each. (1 unit = 1.25uA)

DAC: 8 units of lower current source ON [total 10uA]

- (8) Store above correcting value to dedicated variables.
- (9) If the calculation values of ("scan value with setting Load resistance 30k ohm" in "Load Resistance Scan Test") (stored scan values) is within range of standard threshold value range, PASS the diagnosis.

If the value is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_CURRENT_SORCE.



3.6 SENSCLK Frequency Gain Test

Diagnose SENSCLK gain for Current Controlled Oscillator DAC current source from 1 to 12 units ON.



Figure 3.6 Circuits of SENSCLK Frequency Gain Test

SUADJ0 : CCO-DAC current setting BIT

SUCARRY: CCO-DAC current setting BIT

SUCNT : CCO-DAC current setting BIT

CCOCALIB: Calibration Selection of Current Controlled Oscillator for Scan.

Operation outline

- (1) Set CTSU power on.
- (2) Set high resolution pulse mode.
- (3) Set Self scan mode.
- (4) CCOCALB = 1; setting.
- (5) Set "CTSUSUCLKA.SUADJ0[7:0]" as Current Controlled Oscillator Current DAC current source is set ON from 1 to 12 units.
- (6) Scan by inputting each constant current from internal DAC to ICO scan count value of "SENSCLK".
- (7) Store above scan value to dedicated variables.
- (8) Repeat above from 1 to 12 units of DAC current source.
- (9) If stored scan value is within the standard threshold value range, PASS the diagnosis.

If stored scan value is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_SENSCLK_GAIN.



3.7 SUCLK Frequency Gain Test

Diagnose SUCLK gain for Current Controlled Oscillator DAC current source from 1 to 12 units ON.



Figure 3.7 Circuits of SUCLK Frequency Gain Test

- SUADJ0 : CCO-DAC current setting BIT
- SUCARRY : CCO-DAC current setting BIT
- SUCNT : CCO-DAC current setting BIT
- CCOCALIB : Calibration Selection of Current Controlled Oscillator for Scan.

Operation outline

- $(1) \quad \text{Set CTSU power on}.$
- (2) Set high resolution pulse mode.
- (3) Set Self scan mode.
- (4) CCOCALB = 0; setting.
- (5) Set SUADJ0, SUCARRY, SUCNT as Current Controlled Oscillator Current DAC current source is set ON from 1 to 12 units.
- (6) Scan by inputting each constant current from internal DAC to ICO scan count value of "SUCLK".
- (7) Scan count value of "SUCLK".
- (8) Store above scan value to dedicated variables.
- (9) Repeat above from 1 to 12 units of DAC current source.

If stored scan value is within the standard threshold value range, PASS the diagnosis.

If stored scan value is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_SUCLK_GAIN.



3.8 Clock Recovery Test

Diagnose SUCLK Clock Recovery function.



Figure 3.8 Circuits of Clock Recovery Test

Operation outline

- (1) Set Normal scan settings in the CTSUCRA register.
- (2) Set Normal scan settings in the CTSUCRB register.
- (3) SUCLK operation mode.
- (4) Set Self scan mode.
- (5) Set SO value initialize.
- (6) Set 3 frequencies multi scan setting.
- (7) CTSU scan.
- (8) Store above scan value to dedicated variables.
- (9) Calculates SUCLK frequency.
- (10) If the result compared stored scan value and calculated frequency is within the standard threshold value range, PASS the diagnosis.

If the compared value is without the standard threshold value range, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_CLOCK_RECOVERY.



3.9 CFC Oscillator Gain Test

Diagnose CFC Oscillator Gain.



Figure 3.9 Circuits of CFC Oscillator Gain Test

SUADJ0: CCO-DAC current setting BIT

Operation outline

- (1) Set CFC power on.
- (2) Set CFC self-capacity mode.
- (3) Set high resolution pulse mode.
- (4) Set CFC external current scan mode.
- (5) Set SUADJ0 as current source of Current Controlled Oscillator Current DAC enabled from 1 to 5 sources.
- (6) Scan CFC counter value.
- (7) Store above scan value to dedicated variables.
- (8) Repeat above scan for 1 to 5 sources.
- (9) Compare scan count result and target value.
- (10) If the compared result becomes larger as the number of DAC current sources increase, PASS the diagnosis.

If the compared result becomes lower as the number of DAC current sources increase, FAIL the diagnosis and return FSP_ERR_CTSU_DIAG_CFC_GAIN.



4. API specification

| Syntax | | | | |
|--------------------------------------|---|--|--|--|
| fsp_err_t R_CTSU_Dia | gnosis (ctsu_ctrl_t * const p_ctrl) | | | |
| Description | | | | |
| This API is called when FSP_SUCCESS. | the return value of R_CTSU_DataGet for the diagnostic instance is | | | |
| Diagnostic processing i | is performed using the measured results, and the result is notified as return values. | | | |
| Arguments | | | | |
| ctsu_ctrl_t * const p_ctrl | ctsu_instance_ctrl_t g_ctsu_ctrl_diagnosis; | | | |
| Return Values | | | | |
| | If all measurement for diagnoses is completed without any issue, return FSP_SUCCESS. | | | |
| | If there was FAIL, return error code of each diagnosis as follows. | | | |
| | For CTSU MCU | | | |
| | FSP_ERR_CTSU_DIAG_LDO_OVER_VOLTAGE | | | |
| | FSP_ERR_CTSU_DIAG_CCO_HIGH | | | |
| | FSP_ERR_CTSU_DIAG_CCO_LOW | | | |
| | FSP_ERR_CTSU_DIAG_SSCG | | | |
| | FSP_ERR_CTSU_DIAG_DAC | | | |
| fsp_err_t | | | | |
| | For CTSU2 MCU | | | |
| | FSP_ERR_CTSU_DIAG_OUTPUT_VOLTAGE | | | |
| | FSP_ERR_CTSU_DIAG_OVER_VOLTAGE | | | |
| | FSP_ERR_CTSU_DIAG_OVER_CURRENT | | | |
| | FSP_ERR_CTSU_DIAG_LOAD_RESISTANCE | | | |
| | FSP_ERR_CTSU_DIAG_CURRENT_SOURCE | | | |
| | FSP_ERR_CTSU_DIAG_SENSCLK_GAIN | | | |
| | FSP_ERR_CTSU_DIAG_SUCLK_GAIN | | | |
| | FSP_ERR_CTSU_DIAG_CLOCK_RECOVERY | | | |
| | FSP_ERR_CTSU_DIAG_CFC_GAIN | | | |



5. Flowchart of sample application

Flowchart of sample application is shown Figure 5.1.



Figure 5.1 Flowchart of sample application for CTSU diagnosis



6. Procedure for creating a project using "QE for Capacitive Touch"

The procedure for creating a project using QE for Capacitive Touch is shown below.

6.1 RA Family

1) Create a new project.

2) Add a stack in the configurator.

Add touch middleware stack.

* Additional settings required when using CTSU2

Add ADC driver stack (Figure 6.1), and change the name "g_adc0" to "g_adc_ctsu". (Figure 6.2) (Click "FSP Configuration in the upper right corner, change the name in Properties.)

| Stacks Configuration | | | | Generate Project Content |
|---|-------------------|---|----------|---|
| Threads New Thread Remove □ ✓ | HAL/Common Stacks | TOUCH Driver on rm_touch CTSU Driver on r_ctsu CTSU Driver on r_ctsu CTSU Driver for Transmission [Recommended but optional] CTSU Driver for [Recommended but optional] | New Stac | ★ ≥ <u>Extend Stack > </u> Remove ♥ g_adc0 ADC Driver on r_adc |
| Objects New Object > Remove | | | | |

Figure 6.1 Stacks Configurations view

| Proper | ties 🛛 | | 1 8 - 0 |
|----------|---|---------------|---------|
| g_adc_c | tsu ADC Driver on r_adc | | |
| Settings | Property | Value | ^ |
| API Info | ✓ Common | | |
| AFLING | Parameter Checking | Default (BSP) | |
| | Module g_adc_ctsu ADC Driver on r_adc | | |
| | ✓ General | | |
| | Name | g_adc_ctsu | |
| | Unit | 0 | |
| | Resolution | 12-Bit | |
| | Alignment | Right | |
| | Clear after read | On | |
| | Mode | Single Scan | |
| | Double-trigger | Disabled | |
| | > Input | | |
| | > Interrupts | | |
| | > Extra | | |
| | ✓ Pins | | |
| | | 2.11 | |

Figure 6.2 Change the name of "g_adc0"



3) Select the channel 16 checkbox in the ADC properties of Channel Scan Mask (Figure 6.3).



Figure 6.3 Select the "channel 16" checkbox in property of ADC

4) Set the pin in the configurator.

Select check box of TS terminal you want to use with CTSU scan. For CTSU, need to select the TS terminal for "Current Offset DAC Test".

5) Generate code.

Click "Generate Project Content" in the upper right corner of the Configurator. (Figure 6.1)

6) Create a configuration with QE.

For QE ver3.2 or later, proceed to (A). For QE ver3.1 or before, please proceed to (B).



(A) QE ver3.2 or later

(A-1) Open the "Cap Touch Workflow (QE)" from Renesas views.

Click "Modify Configuration" as shown in Figure 6.4. Create element for CTSU scan. For CTSU, select to "Diagnosis Pin" for "Current Offset DAC Test". as shown in Figure 6.5

| Prepara |
|--------------|
| 1.Preparatio |
| 🕑 Select a P |
| |
| Prepare a |
| |

Figure 6.4 Modify Configuration in "Cap Touch Workflow (QE)

| File Name of Touch I/F: | Diagnosis | Setup Configuration | Import / Re-edit |
|-------------------------|-----------------------------------|---------------------|--------------------------|
| Description: | | | |
| Button00 Button01 | Button02 | | Touch I/F |
| | | | Capacitance Type |
| TS01 TS02 | TS03 | | Self Capacitance |
| | Pin00 | | Button |
| | TSOD | | Slider (horizontal) |
| | | | Slider (vertical) |
| | | | Wheel |
| | | | Key pad |
| | | | 3D Gesture (AI) |
| | | | Touch pad |
| | | | Shield Pin |
| | | | TC Pin |
| | | | Capacitance Sensor |
| | | | Current Sensor |
| | | | Diagnosis Pin |
| | | | Remove Touch I/F |
| Setting | | | Configuratoins (Methods) |
| Setup Touch I/F | Setup Resistance Value Clear Assi | and TSy | |

Figure 6.5 Select to "Diagnosis Pin" in Configuration of Touch Interfaces



(A-2) Complete tuning.

Click "Start Tuning" as shown in Figure 6.6. Follow the instructions from QE to complete the tuning operation. After that, check "Use Diagnostic Code" as shown in Figure 6.6, and Click "Output Parameter Files".

Figure 6.6 Modify Configuration in "Cap Touch Workflow (QE)"

(A-3) Output sample code.

Click "Show Sample" and open "Show Sample Code" view. Then click "Output to a File" and generate "qe_touch_sample.c" as shown in Figure 6.7.



| Show Sample Code | \times |
|---|----------|
| Sample code of main() function: | |
| /*************** | ^ |
| * | |
| * FILE : qe_sample_main.c | |
| * DATE : 2022-03-09 | |
| * DESCRIPTION : Main Program for RX | |
| * NOTE:THIS IS A TYPICAL EXAMPLE. | |
| * | |
| *************************************** | |
| #include "qe_touch_config.h" | |
| #if ((TOUCH_CFG_UART_MONITOR_SUPPORT == 1) (TOUCH_CFG_UART_TUNING_SUPPORT == | 1)) |
| #include "r_sci_rx_pinset.h" | |
| | |
| #define TOUCH_SCAN_INTERVAL_EXAMPLE (20) /* milliseconds */ | |
| void R CTSU PinSetInit(void); | |
| void qe_touch_main(void); | |
| | |
| | |
| | 40 |
| <pre>#if ((TOUCH_CFG_UART_MONITOR_SUPPORT == 1) (TOUCH_CFG_UART_TUNING_SUPPORT == #if (TOUCH_CFG_UART_NUMBER == 0)</pre> | 1)) |
| #II (TOCH_CR_OART_NOMBER == 0) #define OE SCI PIN SET R SCI PinSet SCI0 | ~ |
| < | > |
| Copy to the Clipboard Output to a File Show the Applicati | on Note |
| | |
| ОК | Help |

Figure 6.7 Modify Configuration in "Cap Touch Workflow (QE)"

(B) QE ver3.1 or before

(B-1) Open the "Cap Touch Main (QE)" from Renesas views.

Click "Modify Configuration" as shown in Figure 6.8. Create element for CTSU scan. For CTSU, select to "Diagnosis Pin" for "Current Offset DAC Test". as shown in Figure 6.9

(B-2) Complete tuning.

Click "Start Tuning" as shown in Figure 6.8. Follow the instructions from QE to complete the tuning operation. After that, check "Use Diagnostic Code" as shown in Figure 6.8, and Click "Output Parameter Files".

(B-3) Output sample code.

Click "Show Sample" and open "Show Sample Code" view. Then click "Output to a File" and generate "qe_touch_sample.c" as shown in Figure 6.10.





Figure 6.8 "Cap Touch Main (QE)"



| PACMO | Setup Configuration | Import / Re-edit |
|---------------------------------|---------------------|---------------------|
| KA0M2 | Setup Conngulation | import/ Re-edit |
| | | Touch I/F * |
| on02 | | Capacitance Type |
| i10 | | Self Capacitance |
| Pin00 | | Button |
| TSOO | | Slider (horizontal) |
| | | Slider (vertical) |
| | | Wheel |
| | | Key pad |
| | | 3D Gesture (AI) |
| | | Touch pad |
| | | Shield Pin |
| | | TC Pin |
| | | Capacitance Sensor |
| | | Current Sensor |
| p Resistance Value Clear Assign | ned TSx | Diagnosis Pin |
| | Pin00 | on02 10 Pin00 |

Figure 6.9 "Cap Touch Main (QE)"

| 💽 Show Sample Code | | : | × |
|--|--|-----------------------------|---|
| Sample code of main() fun | ction: | | |
| /************************************* | ************************************** | *******/ | ^ |
| uint64_t button_status; #if (TOUCH_CFG_NUM_SLI uint16_t slider_position[TC #endif | DERS != 0) /UCH_CFG_NUM_SLIDERS]; | > | ~ |
| Consulta the Clinthe and | Output to a File | Character Annalization Nata | |
| Copy to the Clipboard | Output to a File | Show the Application Note | • |
| | (| DK Help | |
| | | | |

Figure 6.10 "Cap Touch Main (QE)"



6.2 RL78 Family

1) Create a new project.

2) Add a component in the configurator.

Add TOUCH middleware and CTSU Driver as shown in Figure 6.11.

3) Set the pin in the configurator.

Select check box of TS terminal you want to use with CTSU scan.

4) Generate code.

Click "Generate Code" in the upper right corner of the Configurator. (Figure 6.11)

5) Create a configuration with QE.

Same as "6.1 RA Family" [(6) Create a configuration with QE].

| mponents 🔛 | | Configure | |
|-----------------|-----|---|--------------------|
| /pe filter text | ۍ پ | Property @ Configurations | Value |
| 🗁 Startup | ^ | # Parameter check | Use system default |
| 🗸 🗁 Generic | | # Data transfer of INTCTSUWR and INTCTSURD | Interrupt handler |
| 💣 r_bsp | | # DTC setting | Setting in r_ctsu |
| 🗁 Middleware | | # Auto-judgment function in Snooze mode using SMS | Disable |
| 🗸 🗁 Generic | | # Data storage address setting for CTSURD | 0xFF800 |
| 💣 r_ctsu | | # Data storage address setting for CTSUWR | 0xFFB00 |
| 💣 rm_touch | | # Interrupt level for INTCTSUWR | Level 2 |
| | | # Interrupt level for INTCTSURD | Level 2 |
| | | # Interrupt level for INTCTSUFN | Level 2 |
| | | v 🚇 Resources | |
| | | V 🖲 CTSU | |
| | | 🛰 TSCAP Pin | Vsed |
| | | 🛰 TS00 Pin | Vsed |
| | | 🛰 TS01 Pin | ✓ Used |
| | | 🛰 TS02 Pin | ✓ Used |
| | | 🔨 TS03 Pin | Used |

Figure 6.11 Software component configuration view



6.3 RX Family

1) Create a new project.

2) Add a component in the configurator.

Add touch middleware as shown in Figure 6.12.

* Additional settings required when using CTSU2

Add ADC driver "r_s12ad_rx" as shown in Figure 6.13. Also, don't need to select an ADC pin (ANxxx).

3) Generate code.

Click Generate Project Content in the upper right corner of the Configurator.

4) Create a configuration with QE.

Same as "6.1 RA Family" [(6) Create a configuration with QE].

| | | Generate Code Generate Re |
|--|--|---|
| Components 🚵 🛃 🎘 🕒 🕀 莽 | ✓ Configure | |
| 10 T | Property | Value |
| type filter text | 💙 🦃 Configurations | |
| ✓ Startup | # Parameter check | Use system default |
| 🗸 🗁 Generic | # Support for QE monitoring using UART | Sensor monitor not used |
| 💣 r_bsp | # Support for Serial tuning using UART | Serial tuning not used |
| ✓ | # UART channel | UARTO |
| Capacitive Touch | # UART boadrate | |
| r_ctsu_qe | # UART priority | Level 1 |
| ✓ ➢ Middleware ✓ ☑ Genetities Touch ✓ ☑ m_touch_qe | # Type of chattering suppression | TypeA : Counter of exceed threshold is hold within hysteresis range |
| | | |

Figure 6.12 Add touch middleware in Software component configuration



| Software component confi | guration | Generat | Code Generate Repor |
|--------------------------|--------------------|--------------------|---------------------|
| Components 🚵 🛃 📮 🕀 🛱 | ➡ Configure | | (i |
| ٠ | Property P | Value | ^ |
| type filter text | 💙 🌼 Configurations | | |
| ✓ → Startup | # Parameter check | Use system default | |
| ✓ 🧁 Generic | ✓ I Resources | | |
| r_bsp | ✓ □ S12AD | | |
| ✓ ➢ Drivers | ✓ 10 S12AD0 | | |
| | 🛰 AN000 Pin | Used | |
| 😫 r_s12ad_rx | 🛰 AN001 Pin | Used | |
| Constitue Touch | 🛰 AN002 Pin | Used | |
| r_ctsu_qe | 🛰 AN003 Pin | Used | |
| ✓ ➢ Middleware | 🛰 AN004 Pin | Used | |
| ✓ Capacitive Touch | 🛰 AN005 Pin | Used | ~ |
| rm_touch_ge | A NIOO6 Dip | Llood | ~ |
| ini_touch_de | | | \sim |
| | | | |
| | | | ~ |

Figure 6.13 Add ADC driver "r_s12ad_rx" in Software component configuration

Revision History

| | | Description | | |
|------|-----------|-------------|-------------------------|--|
| Rev. | Date | Page | Summary | |
| 1.00 | Oct.25.21 | - | First edition issued | |
| 1.10 | Mar.31.23 | - | Added target device | |
| 1.20 | Oct.16.23 | - | Added target device | |
| | | 5 | Added test for CTSUb | |
| | | 8 | Corrected current value | |
| | | 10 | Corrected CTSU figures | |
| | | 12 | Added test for CTSUb | |



General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power is supplied until the power is supplied until the power reaches the level at which resetting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

- Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
- 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
- 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
- 5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
- 6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
 - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

- 7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
- 8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
- 12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
- 13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
- (Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit: <u>www.renesas.com/contact/</u>.