

Quick start ADC1415S, ADC1215S, ADC1115S, ADC1015S series

Demonstration board for ADC1415S, ADC1215S, ADC1115S,
ADC1015S series


Rev. 06 — July 2012

Quick start

Document information

Info	Content
Keywords	PCB2001-2, demonstration board, ADC, converter, input buffer
Abstract	This document describes how to use the demonstration board for the analog-to-digital converter ADC1415S, ADC1215S, ADC1115S and ADC1015S series.

Overview



Revision history

Rev	Date	Description
1	20081001	Initial version.
2	20090518	Update to PCB2001-2.
3	20090610	Add SPI software description.
4	20100519	Add HSDC extension module acquisition system description.
5	20110120	Update with latest software tool.
6	20120702	Rebranded.

1. Overview of the ADC1415S, ADC1215S, ADC1015S demo board

1.1 ADC1415S series

Figure below presents the connections to measure ADC1415S.




Fig 1. ADC1415S series typical configuration set-up

Rev. 06 — 2 July 2012

4 of 28



1.3 ADC1115S series

Figure below presents the connections to measure ADC1415S.




Fig 3. ADC1115S series typical configuration set-up

1.4 ADC1015S series

Figure below presents the connections to measure ADC1015S.





Fig 4. ADC1015S series typical configuration set-up

1.5 Power supply

The board is powered with a 3 V_{DC} and 1.8/3 V_{DC} power supplies. A power supply regulator is used to supply all the circuitry on the board.

Table 1. General power supply

Name	Function	View
J10	+3V green connector – Power supply 3 V _{DC} / 250 mA.	
J9	+1.8V green connector – Power supply 1.8 V _{DC} / 100 mA	
J8	+5V green connector – Power supply 5 V _{DC} / 100 mA	
TP1	AGND test point – Digital ground	
TP2	DGND test point – Analog ground	

1.6 Input signals (IN, CLK)

The input clock signal can be either a sine-wave or a LVCMOS signal.


To ensure a good evaluation of the device, the input signal and the input clock must be synchronized together.

Moreover, the input frequency (F_i, MHz) and the clock frequency (F_{clk}, Mps) should follow the formula:

$$\frac{F_i}{F_{clk}} = \frac{M}{N}$$

Where M is an odd number of period and N is the number of samples.


Table 2. Input signals

Name	Function	View
J1	IN connector – Analog input signal (50Ω matching)	
J2	CLKP connector – Single ended clock input signal (50Ω matching), with a transformer.	
J3	CLKN connector – Grounded on that demoboard	

1.7 Output signals (D0 to D13, OTR, DAV)

The digital output signal is available in binary, 2's complement or gray format.
A Data Valid Output clock (DAV) is provided by the device for the data acquisition.

Table 3. Output signals


Name	Function	View
J4	Array connector – ADC digital output(D0 to D13), Out of range signal (OTR) and Data Valid (DAV)	

1.8 SPI Mode

The ADC1x15S can be **controlled** either by a Serial Peripheral Interface (SPI) or by PIN.

Table 4. SPI Interface

Name	Function	View
J5	Array connector – SPI daughter board interface	



1.9 SPI program

For more details on how to control device with SPI, refer to [section 3.3](#).

2. HSDC extension module: acquisition board

The [figure 4](#) shows an overview of the extension module HSDC-EXTMOD01/DB acquisition board:




Fig 5. HSDC extension module: acquisition board

The HSDC extension module is intended for acquisition/generation and clock generation purpose. When connected to an ADC demo-board it is intended as an acquisition system for digital output bits delivered by ADC, either CMOS (HE14 P1 connector) or LVDS DDR (SAMTEC QTH_060_02 P2 connector).

The board brief specification is shown below:

- 32 MB memory size for acquisition pattern;
- 2 16-bit channels CMOS up to 200 MHz;
- 16-bit LVDS DDR input data stream up to 320 MHz;
- On-board or external reference for signal generation.

In this section the specific requirement for the use with ADC1115S demo-board will be shown.

For more details on the HSDC-EXTMOD01/DB, please visit: <http://www.idt.com>.

2.1 HSDC extension module: hardware initialization

Before using the generation board, make sure that you connect the USB cable **prior to** the supply.

When USB and power cable are connected, the HSDC-EXTMOD will light 3 red LEDs.

The green LED close to the PLL is only when it is locked (see [section 3.3](#)).

The red LED close to FPGA reports normal behavior when flashing $\frac{1}{4}$ on, $\frac{3}{4}$ off. Any other flashing behavior reports a failure at initialization (see [section 3.3](#)).

2.2 HSDC extension module: CMOS connector description

The [figure 5](#) shows a brief description of the hardware connection on the HE14 connector.

For proper use of the acquisition board, make sure that resistor R86 (0 Ω) is connected while R84 is removed.





Fig 6. HSDC extension module: HE14 CMOS hardware schematic overview

3.Combo ADC1415S and HSDC extension module

3.1 ADC1x15S CMOS outputs

The [figure 24](#) below shows an overview of the whole system ADC1x15S+HSDC extension module with CMOS outputs configuration for which connection is straightforward, together with a supply extension module (release A) for the ADC1x15S demo-board:



3.2 ADC Software tool

Run the application “SW_ADC_1_r02.exe”. This application will allow:

- the user to control features on our high speed ADC through the SPI interface available on any ADC1415S, ADC1215S, ADC1115S and ADC1015S series;
- As well as performing any online data acquisition to evaluate the performances of the ADC1415S, ADC1215S, ADC1115S and ADC1015S series.

At start-up, the program will detect any board connected to your system and display information as can be seen on following window:




Fig 8. SW_ADC_1_r02: start-up screen

- ①: “IDT Banner Button” will display your default internet browser to the IDT data converter home page;
- ②: “REFRESH” allows you to poll your system for any hardware change. It will reset any board connected to your system;
- ③: “QUIT” allows you quit the application;
- ④: “INITIALIZATION” allow you to initialize the HSDC-EXTMOD board prior to any acquisition task.

In the example above, the HSDC-EXTMOD has been detected, as well as ADC1015S125.

At this moment, make sure that 4 LEDs are visible on the HSDC-EXTMOD (2 close to power plug, 1 for USB and 1 close to FPGA).

The “Info” page gives more details on the current hardware configuration for the HSDC-EXTMOD board:




Fig 9. SW_ADC_1_r02: "Info" page

The HSDC-EXTMOD is not yet initialized, so the embedded PLL (LMK03001 in this example) is not locked. Initialization is only required for acquisition purpose.

3.2.1 ADC SPI programming Functional Registers page

The page displays all SPI registers for ADC1415S, ADC1215S, ADC1115S and ADC1015S series:




Fig 10. SW_ADC_1_r02: “ADC - Functional Registers” page

Perform any settings and then click on the “Send data to device” button to update the device registers.

3.2.2 ADC SPI programming Read Registers page

This page can be used to read all registers by clicking on the “Read all registers” button and will display the result in the table below:




Fig 11. SW_ADC_1_r02: “ADC - Read Registers” page

When all registers have been read, it is possible to save the data to a text file. The settings are saved in a table-like format as shown below:

Table 5. Typical saving on text file
Content of file is shown as table format

Column 1	Column 2
Address	Value
05	00
06	01
08	00
10	03
11	00
12	09
13	00
14	00
15	00
16	00
17	00
20	0e
21	00

Column 1	Column 2
22	00

Note that all data are saved in hexadecimal format.

Click on the “Save registers read to file” button to select the file to store data to. Make sure that you store your file with “.txt” extension, this will allow you to re-use the file on the “ADC - Load Registers” page.

3.2.3 ADC SPI programming Load Registers page

This page allows downloading configuration data to the device registers:




Fig 12. SW_ADC_1_r02: “ADC - Load Registers” page

It is not necessary to have a file that has the whole set of registers listed. The only restriction is regarding the formatting of the file as given in [section 3.3.2](#).

Note: this page can not be used to download data saved during the comparison process.

To download settings onto device registers, follow the procedure below:

- Browse to select your file (button ①);
- Click on “Load data” button ②.

A message on field ③ and a progress bar will inform about the status of the operation until message “download done!” is seen. The table ④ is updated with the current values downloaded at the fly as can be seen on [figure 13](#).

3.2.4 Tools page

This page allows the user to calculate the coherent frequencies values involved of the acquisition process. It gives an indication where the 6 first harmonics are located in the Nyquist zone.

Enter your analog and sampling frequencies in field①. Indicate the number of samples to be acquired②, as well as the fixed parameter for the coherency calculation (F_s in our example above③). Press “UPDATE GRAPH” to look at the frequency plan, it gives also the real F_{in} frequency (Refer to [appendix A.1](#) for more details on coherency calculation):




Fig 13. SW_ADC_1_r02: “Tools” page

Note: The level of the harmonics shown does not reproduce the behavior of the ADC; they are only given as indication for location.

3.2.5 Acquisition page

This page will acquire data to evaluate the high dynamic performance of the device:




Fig 14. SW_ADC_1_r02: “Acquisition” page

Before proceeding to any acquisition, the user needs to do the following entries:

- the sampling frequency F_s : 122.88 Msps in our example (field ①);
- the input frequency F_{in} : 5 MHz in our example (field ①);
- the number of samples to be acquired 65536 in our example (field ②);
- indicate whether it is CMOS or LVDS DDR (field ③);
- press the “INITIALIZATION” button ④. It will initialize the HSDC-EXTMOD board:
 - FPGA is ready (red LED is flashing $\frac{1}{4}$ on and $\frac{3}{4}$ off);
 - PLL embedded is locked (green LED is on);
- indicate whether F_{in} or F_s are coherent or not (field ⑤):
 - if signals are coherent, selected which F_{in} or F_s are fixed for the calculation (see [appendix A.1](#));
 - if signals are not coherent, select the window for FFT processing to apply (the Blackman window gives better results).
- press the “ACQUIRE” button ⑥ to display the results from the FFT processing. The results fields ⑦ will be updated automatically.
- press “STOP” ⑦ button to stop acquisition;
- field ⑧ allows to do FFT averaging over up to 255 trials, suitable for small signal analysis;
- field ⑨ allows to store dynamic results to text file. Click on the check box, enter a header as a comment and browse to indicate where to store data file. [Table 7](#) shows how data are stored:

Table 6. Dynamic results as stored in a text file
Content of file is shown as table format

Name	Fin	Fs	Vin	ENOB	SINAD_C	SNR_C	SNR_FS	SFDR_C	SFDR_FS	THD	H2	H3	H4	H5	H6
	(MHz)	(MHz)	(dBFS)	-	(dBc)	(dBc)	(dBFS)	(dBc)	(dBFS)	(dBc)	(dBc)	(dBc)	(dBc)	(dBc)	(dBc)
ADC1115S test															
ADC0	5.00	122.86	-0.93	10.53	65.30	65.18	66.23	81.82	82.75	-81.02	-98.65	-82.75	-102.1	-90.69	-108.6

Note that while acquisition is running, any other action (ADC SPI programming, quit or refresh) is not possible. Stop acquisition first before proceeding to any other task.

3.2.5.1 FFT spectrum

The first graph to be displayed is the FFT spectrum of the digital pattern acquired:




Fig 15. SW_ADC_1_r02: “Acquisition” page, FFT graph

Press the “Autoscale” button to display the whole content.

3.2.5.2 Reorganized signal

The reorganized signal displays the reconstructed sine wave from coherency calculation corresponding to 1 period of the input signal:




Fig 16. SW_ADC_1_r02: “Acquisition” page, reorganized signal graph

Press the “Autoscale” button to display the whole content.

3.2.5.3 Unreconstructed signal

The unreconstructed signal displays the unreconstructed sine wave corresponding to the whole number of period being acquired following the coherency rule:




Fig 17. SW_ADC_1_r02: “Acquisition” page, unreconstructed signal graph

Press the “Autoscale” button to display the whole content.
Use the zoom tool to observe in more details all the captured data.

3.2.5.4 Histogram

The histogram graph shows the distribution of output codes. This graph shows which code is present and if there is any missing code in the conversion range:




Fig 18. SW_ADC_1_r02: “Acquisition” page, code histogram graph

Press the “Autoscale” button to display the whole content.
The table shows the range of output codes.

3.2.6 Info page

This page will give practical information related to software and hardware settings:




Fig 19. SW_ADC_1_r02: “Info” page

The information visible on this page are:

- board serial number ①;
- HSDC software release number ②;
- HSDC-EXTMOD dll version ③;
- HSDC-EXTMOD vhdl version ④;
- HSDC-EXTMOD supply status ⑤;
- HSDC-EXTMOD clock capability and status version ⑥;
- HSDC-EXTMOD memory capability ⑦.

4. Appendix A.1: coherency calculation

The coherency relies on the fact that clock and analog input signal are synchronized and the first and last samples being captured are adjoining samples: it ensures a continuous digitized time process for the FFT processing.

To achieve this, one has to follow the equation:

$$\frac{F_{in}}{F_s} = \frac{M}{N}$$

where M is an odd integer equal to the number of periods being acquired and N the number of samples acquired.

With F_{in} , F_s and N known, M has to be chosen such that it follows the equation above. To do this iterative calculation, one has to decide whether F_{in} or F_s is fixed.

To illustrate this process, let's consider our current example with $F_{in} = 5$ MHz, $F_s = 122.88$ Msps and $N = 65536$ samples acquired:

- if F_{in} is fixed, this leads to $M = 2667$ periods of input signal to be acquired and a real sampling frequency to be $F_s = 122.864642$ MHz;
- If F_s is fixed, this leads to $M = 2667$ periods of input signal to be acquired and a real input frequency to be $F_{in} = 5.000625$ MHz.

Those values needs to be programmed in the signal generator and clock generator before capture is done, otherwise the FFT calculation will lead to a non-coherent result as shown below:




Fig 20. SW_ADC_1_r02: "Acquisition" page, non-coherent capture example

The numbers given for SNR, SFDR are completely wrong if coherency is not respected.

5. Notes

For more information or sales office addresses, please visit: <http://www.idt.com>.

6. Contents

1.	Overview of the ADC1415S, ADC1215S, ADC1015S demo board	3
1.1	ADC1415S series.....	3
1.2	ADC1215S series.....	4
1.3	ADC1115S series.....	5
1.4	ADC1015S series.....	6
1.5	Power supply	7
1.6	Input signals (IN, CLK)	7
1.7	Output signals (D0 to D13, OTR, DAV)	8
1.8	SPI Mode	9
1.9	SPI program.....	9
2.	HSDC extension module: acquisition board	10
2.1	HSDC extension module: hardware initialization	11
2.2	HSDC extension module: CMOS connector description	11
3.	Combo ADC1415S and HSDC extension module.....	13
3.1	ADC1x15S CMOS outputs	13
3.2	ADC Software tool.....	14
3.2.1	ADC SPI programming Functional Registers page.....	16
3.2.2	ADC SPI programming Read Registers page	17
3.2.3	ADC SPI programming Load Registers page	18
3.2.4	Tools page	19
3.2.5	Acquisition page.....	20
3.2.5.1	FFT spectrum.....	21
3.2.5.2	Reorganized signal.....	22
3.2.5.3	Unreconstructed signal.....	23
3.2.5.4	Histogram	24
3.2.6	Info page.....	25
4.	Appendix A.1: coherency calculation.....	26
5.	Notes.....	27
6.	Contents	28