

4-20mA Current Receiver Board Firmware

Operation Manual

1. Operation Environment

Table 1-1 Operation Environment

Environment		Description
Hardware	Main board	4-20 mA current receiver isolated board (REIN) 4-20 mA current receiver non-isolated board (REIN)
	Firmware	e ² studio GCC compiler FSP Firmware project
		Ver 7.6.0 Ver 8.3.1 Ver 0.8.0 US110_4_20mA_Rcvr_20200306.zip




Figure 1-1 Operation Board

2. Operation Procedure

- 2.1 Import firmware project "US110_4_20mA_Rcvr" to e² studio and download executable file to 4-20 mA current receiver board by J-Link debugger (J3 connector for Isolated version or J6 connector for Non-isolated version).
- 2.2 Connect a current measurement circuit.
e.g.




Figure 2-1 Current Measurement Circuit Example

- 2.3 Power on the board when DC source is off. The LCD will display "On" for one second.



- 2.4 And then, "NoV" is displayed on the LCD because the bus voltage is less than 3V.



- 2.5 Turn on the DC source. The LCD will display the current value in mA.



3. LCD Display Instructions

Table 3-2 LCD Display Instructions

Display Content		Description
On		The system is powered on.
NoV		No bus voltage status
OV		Overvoltage status
UU		Undervoltage status
OC		Overcurrent status
Ot		Over-temperature status
Err1		Communication with DPM over I2C fails.
Err2		The current is out of the range (4mA ~ 20mA).
Err3		Other errors