

RAJ240055

R16AN0073EJ0101

Rev.1.01

May 16, 2025

R-BMS F Quick Start Guide

Introduction

The RAJ240055 R-BMS F evaluation kit consists of an evaluation module (EVM), a USB System Management Bus (SMBus) and an interface adaptor which allow users to evaluate their battery management system using Renesas RAJ240055 Li-ion battery Fuel Gauge IC (FGIC).

Additionally, the kit comes with R-BMS F firmware, which is fixed and easy to use software requiring no additional development with user configurable settings for determining the different thresholds of the device.

This User's Manual provides detailed information of the evaluation kit and how to set it up to construct 2 - 4 Li-ion battery cell series to start operation and performance evaluation.

Target Device

RAJ240055

Note:

Default cell count setting of each EVM is as follows. To amend the cell count, full package is needed.

- RAJ240055 R-BMS F: 4 cell

Windows Decimal Symbol setting must be a period "." in order for the GUI to launch.

Refer to the URL below and download the package for more details.

<https://www.renesas.com/en/products/power-management/battery-management/battery-fuel-gauges/rtk0ef0163dk0002bu-raj240055-fixed-firmware-evaluation-kit-battery-management?queryID=b9dc5a565b1928dc40b743b67ae7347a>

Contents

1. Evaluation Kit Features & Contents	3
1.1 Features	3
1.2 Hardware Contents.....	3
1.3 Performance Specification Summary	3
1.4 Required Equipment.....	3
1.5 Evaluating with a Load Current	エラー! ブックマークが定義されていません。
2. Function Outline	5
2.1 Features	5
2.2 Function outline	5
3. SMBus Commands.....	6
4. Quick Bootup/Start.....	7
4.1 Reducing the Cell Count	7
5. R-BMS F_Tool.....	8
5.1 Software Requirements	8
Revision History	9

1. Evaluation Kit Features & Contents

This chapter overviews the EVM features and hardware contents.

1.1 Features

- A complete evaluation system for the RAJ240055 with 2-4 cell Li-ion battery.
- An optimized circuit module for 2-cell to 4-cell configuration for quick setup.
- SMBus I/F communication.
- A built-in resistor cell simulator for quick setup and minimum wire connections.
- A GUI based PC software for configuration.

1.2 Hardware Contents

The R-BMS F evaluation kit comes with the hardware items shown in [Table 1-1](#) below.

Table 1-1 R-BMS F Evaluation Kit Contents

Item	Description
R-BMS F EVM	EVM for evaluating R-BMS F with RAJ240055 FGIC.
USB SMBus Converter (I/F)	USB SMBus interface adapter.
Cables	A USB cable for connecting the SMBus I/F to the PC. A serial cable to connect the SMBus I/F to the EVM.

1.3 Performance Specification Summary

The R-BMS F evaluation kit specifications are shown in [Table 1-2](#) below.

Table 1-2 Performance Specification Summary

Specification	Min	TYP	Max	Unit
Input voltage Pack+ to Pack-			25	V
Battery voltage V1/V2/V3/V4	2.5		4.2	V
Charge and discharge current	0		15	A

Note: Board cooling may be required for continuous operation at or below the maximum current.

1.4 Required Equipment


The following equipment is required to operate the EVM.

Table 1-3 Required Equipment List

Item	Symbol	Description
DC power supply 1	PS#1	For Battery simulation Bipolar DC power supply will be needed for charger test.
DC power supply 2	PS#2	Optional and may be needed to simulate the charger.
DC load or assorted resistors	DCL	Optional and may be needed to simulate the system load. A bipolar DC power supply can be used instead.
Computer with a USB port	-	Windows operating system is required.

Note: Additional equipment may be needed to operate the EVM with a more extensive test.

1.5 EVM Connection with Minimum Configuration (4 cells)



2. Function Outline

2.1 Features

- High accuracy Voltage, Current, and Temperature detection and safety protection.
- Safety and outperformed charging controlling.
- Accurate capacity calculation
- Make less power consumption by power saving control.
- Supports the Smart Battery Data specification V1.1
- Supports various system by parameter of FlashROM (Fixed data / Own data / Flexible data)
- Supports on-board firmware updating via SMBus
- Current Range: -32768 mA to 32767 mA ^{Note}

Note: Allowable current of EVB is 15A. Refer to Section 1.3 for more details.

2.2 Function outline

- Voltage, Current, Temperature measurement
- Remaining Capacity (RC) Calculation
- Relative State Of Charge (RSOC) Calculation
- Full Charge Capacity (FCC) update
- Initial Calibration mode for accurate measurement
- Capacity correction by Lookup table
- Mode transition: Normal, Sleep, Shutdown, Fail
- Over Current, Over / Under Voltage, and Over Temperature protection
- Fuse Blow
- RMA Data & Fault Logging
- LED Display Module (optional)
- JEITA Charging (optional)
- Master Communication (optional)

3. SMBus Commands

Some commands are not listed. Refer to firmware specification for more details.

Function	Code	Access	Unit	Description																														
<i>Temperature()</i>	0x08	RW	0.1K	The cell-pack's internal temperature																														
<i>Voltage()</i>	0x09	RW	mV	The cell-pack voltage																														
<i>Current()</i>	0x0A	RW	mA	The current being supplied through the battery's terminals																														
<i>RelativeStateOfCharge()</i>	0x0D	RW	%	The predicted remaining battery capacity expressed as a percentage																														
<i>RemainingCapacity()</i>	0x0F	RW	mAh	The predicted remaining battery capacity																														
<i>FullChargeCapacity()</i>	0x10	RW	mAh	The predicted pack capacity when it is fully charged																														
<i>ChargingCurrent()</i>	0x14	RW	mA	Desired charging rate to the Smart Battery Charger																														
<i>ChargingVoltage()</i>	0x15	RW	mV	Desired charging voltage to the Smart Battery Charger																														
<i>BatteryStatus()</i>	0x16	RW	Bit flags	The Smart Battery's status with Alarm and Status <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Bit</th> <th>Field</th> </tr> </thead> <tbody> <tr><td>15</td><td>OVER_CHARGED_ALARM</td></tr> <tr><td>14</td><td>TERMINATE_CHARGE_ALARM</td></tr> <tr><td>13</td><td>Reserved</td></tr> <tr><td>12</td><td>OVER_TEMP_ALARM</td></tr> <tr><td>11</td><td>TERMINATE_DISCHARGE_ALARM</td></tr> <tr><td>10-8</td><td>Reserved</td></tr> <tr><td>7</td><td>INITIALIZED</td></tr> <tr><td>6</td><td>DISCHARGING</td></tr> <tr><td>5</td><td>FULLY_CHARGED</td></tr> <tr><td>4</td><td>FULLY_DISCHARGED</td></tr> <tr><td>3-0</td><td>Reserved</td></tr> </tbody> </table>	Bit	Field	15	OVER_CHARGED_ALARM	14	TERMINATE_CHARGE_ALARM	13	Reserved	12	OVER_TEMP_ALARM	11	TERMINATE_DISCHARGE_ALARM	10-8	Reserved	7	INITIALIZED	6	DISCHARGING	5	FULLY_CHARGED	4	FULLY_DISCHARGED	3-0	Reserved						
Bit	Field																																	
15	OVER_CHARGED_ALARM																																	
14	TERMINATE_CHARGE_ALARM																																	
13	Reserved																																	
12	OVER_TEMP_ALARM																																	
11	TERMINATE_DISCHARGE_ALARM																																	
10-8	Reserved																																	
7	INITIALIZED																																	
6	DISCHARGING																																	
5	FULLY_CHARGED																																	
4	FULLY_DISCHARGED																																	
3-0	Reserved																																	
<i>CycleCount()</i>	0x17	RW	cycle	The number of cycles the battery has experienced																														
<i>DesignCapacity()</i>	0x18	RW	mAh	The theoretical capacity of a new pack																														
<i>ManufactureDate()</i>	0x1B	RW/WW	-	The date the cell pack was manufactured in a packed																														
<i>SerialNumber()</i>	0x1C	RW/WW	-	The serial number																														
<i>ManufacturerName()</i>	0x20	BR	String	The character array containing the battery's manufacturer's name																														
<i>DeviceName()</i>	0x21	BR	String	The character string that contains the battery's name																														
<i>DeviceChemistry()</i>	0x22	BR	String	The partial list of chemistries and their expected abbreviations																														
<i>ManufacturerData()</i>	0x23	BR	String	The manufacturer data contained in the battery																														
<i>OperationStatus()</i>	0x41	RW	-	The cell-pack's operation status <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Mode number</th> <th>Mode name</th> </tr> </thead> <tbody> <tr><td>0x00</td><td>INIT</td></tr> <tr><td>0x01</td><td>WAKEUP</td></tr> <tr><td>0x02</td><td>DISCHARGE</td></tr> <tr><td>0x03</td><td>CHARGE</td></tr> <tr><td>0x05</td><td>CHG TERM</td></tr> <tr><td>0x06</td><td>CHG WAIT</td></tr> <tr><td>0x07</td><td>PRE CHG</td></tr> <tr><td>0x09</td><td>SLEEP</td></tr> <tr><td>0x17</td><td>TEMPORARY FAIL</td></tr> <tr><td>0x1E</td><td>POWER DOWN</td></tr> <tr><td>0x1F</td><td>PERM FAIL</td></tr> <tr><td>0x20</td><td>INIT CALIB</td></tr> <tr><td>0x99</td><td>FIXED DATA ERROR</td></tr> <tr><td>0xFF</td><td>(Reset)</td></tr> </tbody> </table>	Mode number	Mode name	0x00	INIT	0x01	WAKEUP	0x02	DISCHARGE	0x03	CHARGE	0x05	CHG TERM	0x06	CHG WAIT	0x07	PRE CHG	0x09	SLEEP	0x17	TEMPORARY FAIL	0x1E	POWER DOWN	0x1F	PERM FAIL	0x20	INIT CALIB	0x99	FIXED DATA ERROR	0xFF	(Reset)
Mode number	Mode name																																	
0x00	INIT																																	
0x01	WAKEUP																																	
0x02	DISCHARGE																																	
0x03	CHARGE																																	
0x05	CHG TERM																																	
0x06	CHG WAIT																																	
0x07	PRE CHG																																	
0x09	SLEEP																																	
0x17	TEMPORARY FAIL																																	
0x1E	POWER DOWN																																	
0x1F	PERM FAIL																																	
0x20	INIT CALIB																																	
0x99	FIXED DATA ERROR																																	
0xFF	(Reset)																																	
<i>FETTemp()</i>	0x44	RW	0.1K	The FET temperature																														
<i>PACKVoltage()</i>	0x47	RW	mV	The cell-pack output voltage																														
<i>StateOfHealth()</i>	0x48	RW	%	The predicted percentage of cell aging																														
<i>VoltageOfCellx()</i>	0x60-0x63	RW	mV	Each cell voltage (0x60 is the bottom, 0x63 is the top)																														
<i>FirmwareVersion()</i>	0xF1	RW	-	The firmware version																														
<i>FirmwareSubVersion()</i>	0xF2	RW	-	The firmware subversion																														


4. Quick Bootup/Start

Refer to user’s manual in the package for more details. To use SMBus I/F, package would be needed.

1. Configure the cell count. For more details, refer to in section 4.1.
2. Connect the power supply (PS#1) between BAT+ and BAT- terminals.
3. Adjust the DC power supply (PS#1) setting to a value between 3V to 4.2V per cell.
4. Default series number of cell setting is 4 cell.
5. Apply voltage between BAT+ and BAT- terminals using the DC power supply (PS#1).
6. Press the “PON” switch (SW1) to boot-up the system from power down mode.
7. Confirm the LED status. LED1 (PWR) will turn on (green) when it succeeds in booting up.

Note: if JP3 is not connected, LED1 will not turn ON.

8. The battery pack status can be monitored via SMBus connector (CN1).



4.1 Reducing the Cell Count

The R-BMS F solution supports 2 to 4 cells. The EVM utilizes the Jumpers JP9 and JP10 to specify the number of cells to be used when applying voltage to the battery terminals. see Table 4-1 below.

Table 4-1 Reducing the Cell Count

Cell Count	JP9	JP10
2 cells	closed	closed
3 cells	closed	open
4 cells	open	open

5. R-BMS F_Tool

The R-BMS F_Tool is a GUI software used for monitoring and evaluating the R-BMS F EVM. It provides the features shown in [Table 5-1](#). For more details, refer to the R-BMS F_Tool manual in the package.

Table 5-1 Function Overview

Menu Name	Function/Description
HOME	Home Screen.
SYSTEM MONITOR	Read/Log the SMBus register data.
FIXED DATA	Battery Parameter read/write.
FLEXIBLE DATA	Latest system data read/write.
OWN DATA	Board level calibration read/write.
CALIBRATION	Perform board level calibration.
FLASH UPDATE	Firmware flash memory (Fixed/Own, Flexible) data update
FACTORY DEFAULT	EVM roll back function
FUNCTION CONFIG	Easy battery parameter setting function



Figure 5-1 R-BMS F TOOL Overview.

5.1 Software Requirements

The R-BMS F_Tool requires a Windows 10 or later system.

Revision History

Rev.	Date	Description	
		Page	Summary
1.00	Mar. 3, 2025		First release
1.01	May 16, 2025		Add SMBus Commands Add Quick Bootup/start

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity.

Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/.