



EXTERNAL DC POWER SUPPLY INPUT MAX 48V, 3A




INSULATING BARRIER

uP AREA | USB AREA



	EXT. POWER SUPPLY	USB POWER SUPPLY
JP1	1-3	4-6
JP2	1-3	4-6





© Renesas Electronics Corporation 2014

Title RX111 Low Cost Motor Control Starter Kit (YROTATE-IT-RX111)




Size A4 Document Number YROTATE-IT-RX111 Rev. 2.0


Date SEP, 13, 2014 Sheet 4 .2 OF .11






	ZIGBEE/ PROG.	COMM.
JP3	1-2	2-3
JP4	1-2	2-3





INTERNAL POWER STAGE: JP11, ..., JP16 CLOSED
EXTERNAL POWER STAGE: JP11, ..., JP16 OPEN



D

C

B


A






D

C


B

A






© Renesas Electronics Corporation 2014			
Title RX111 Low Cost Motor Control Starter Kit (YROTATE-IT-RX111)			
Size A4	Document Number YROTATE-IT-RX111		Rev. 2.0
Date SEP, 13, 2014	Sheet 4	.8 OF	.11



EXTERNAL POWER STAGE CONNECTOR

WARNING: JP7, ..., JP16 MUST BE OPEN BEFORE CONNECTING J6



© Renesas Electronics Corporation 2014

Title RX111 Low Cost Motor Control Starter Kit (YROTATE-IT-RX111)

Size A4 Document Number YROTATE-IT-RX111 Rev. 2.0

Date SEP, 13, 2014 Sheet 4 .10 OF .11

