



# LQFP, TQFP

## Mount Pad Dimensions



$$l_2 = L + \beta_1 + \beta_2$$

$$b \leq b_2 \leq e - \gamma$$

$l_2$  and  $b_2$  can get by following formula and value  $e$  and  $b$  from package drawing figure and below parameter table.

• Dimension parameter

(Unit: mm)

| e         | 0.80         | 0.65 | 0.50 | 0.40 |
|-----------|--------------|------|------|------|
| $\alpha$  | 0.10 to 0.30 | ←    | ←    | ←    |
| $\beta_1$ | 0.20 to 0.40 | ←    | ←    | ←    |
| $\beta_2$ | 0.20 to 0.40 | ←    | ←    | ←    |
| $\gamma$  | 0.30         | ←    | 0.25 | 0.20 |

(Reference values based on the former EIAJ ED-7404 standard)