



QFP Mount Pad Dimensions



$$l_2 = L + \beta_1 + \beta_2$$

$$b \leq b_2 \leq e - \gamma$$

l_2 and b_2 can get by following formula and value e and b from package drawing figure and below parameter table.

• Dimension parameter

(Unit: mm)

| e | 0.80 | 0.65 | 0.50 | 0.40 |
|-----------|--------------|------|--------------|------|
| α | 0.30 | ← | 0.10 to 0.30 | ← |
| β_1 | 0.50 | ← | 0.20 to 0.40 | ← |
| β_2 | 0.20 to 0.40 | ← | ← | ← |
| γ | 0.30 | ← | 0.25 | 0.20 |

(Reference values based on the former EIAJ ED-7404 standard)